





Cancel a print job

How do I?	Steps to perform
<p>Stop the current print job from the control panel</p>	<p>Press the Cancel button  on the control panel.</p> 
<p>Stop the current print job from the software program</p>	<p>When you send the print job, a dialog box appears briefly on the screen, giving you the option to cancel the print job.</p> <p>If a print job is waiting in a print queue or print spooler, delete the print job there.</p> <ol style="list-style-type: none">1 Windows XP and Windows Server 2003 (using the default Start menu view): Click Start, click Settings, and then click Printers and Faxes.-or-Windows 2000, Windows XP, and Windows Server 2003 (using the Classic Start menu view): Click Start, click Settings, and then click Printers.-or-Windows Vista: Click Start, click Control Panel, and then in the category for Hardware and Sound click Printer. <ol style="list-style-type: none">2 In the list of printers, double-click the name of this product to open the print queue or spooler.3 Select the print job that you want to cancel, and then press Delete.

