

AutoCAD 2010

Driver & Peripheral Guide

The Autodesk logo is displayed in white text on a black rectangular background. The text is oriented vertically, reading from bottom to top.

January 2009

© 2009 Autodesk, Inc. All Rights Reserved. Except as otherwise permitted by Autodesk, Inc., this publication, or parts thereof, may not be reproduced in any form, by any method, for any purpose.

Certain materials included in this publication are reprinted with the permission of the copyright holder.

Trademarks

The following are registered trademarks or trademarks of Autodesk, Inc., in the USA and other countries: 3DEC (design/logo), 3December, 3December.com, 3ds Max, ADI, Alias, Alias (swirl design/logo), AliasStudio, AliasWavefront (design/logo), ATC, AUGI, AutoCAD, AutoCAD Learning Assistance, AutoCAD LT, AutoCAD Simulator, AutoCAD SQL Extension, AutoCAD SQL Interface, Autodesk, Autodesk Envision, Autodesk Insight, Autodesk Intent, Autodesk Inventor, Autodesk Map, Autodesk MapGuide, Autodesk Streamline, AutoLISP, AutoSnap, AutoSketch, AutoTrack, Backdraft, Built with ObjectARX (logo), Burn, Buzzsaw, CAiCE, Can You Imagine, Character Studio, Cinestream, Civil 3D, Cleaner, Cleaner Central, ClearScale, Colour Warper, Combustion, Communication Specification, Constructware, Content Explorer, Create>what's>Next> (design/logo), Dancing Baby (image), DesignCenter, Design Doctor, Designer's Toolkit, DesignKids, DesignProf, DesignServer, DesignStudio, DesignStudio (design/logo), Design Web Format, Discreet, DWF, DWG, DWG (logo), DWG Extreme, DWG TrueConvert, DWG TrueView, DXF, Ecotect, Exposure, Extending the Design Team, Face Robot, FBX, Filmbox, Fire, Flame, Flint, FMDesktop, Freewheel, Frost, GDX Driver, Gmax, Green Building Studio, Heads-up Design, Heidi, HumanIK, IDEA Server, i-drop, ImageModeler, iMOUT, Incinerator, Inferno, Inventor, Inventor LT, Kaydara, Kaydara (design/logo), Kynapse, Kynogon, LandXplorer, LocationLogic, Lustre, Matchmover, Maya, Mechanical Desktop, Moonbox, MotionBuilder, Movimento, Mudbox, NavisWorks, ObjectARX, ObjectDBX, Open Reality, Opticore, Opticore Opus, PolarSnap, PortfolioWall, Powered with Autodesk Technology, Productstream, ProjectPoint, ProMaterials, RasterDWG, Reactor, RealDWG, Real-time Roto, REALVIZ, Recognize, Render Queue, Retimer,Reveal, Revit, Showcase, ShowMotion, SketchBook, Smoke, Softimage, Softimage|XSI (design/logo), SteeringWheels, Stitcher, Stone, StudioTools, Topobase, Toxik, TrustedDWG, ViewCube, Visual, Visual Construction, Visual Drainage, Visual Landscape, Visual Survey, Visual Toolbox, Visual LISP, Voice Reality, Volo, Vtour, Wire, Wiretap, WiretapCentral, XSI, and XSI (design/logo).

The following are registered trademarks or trademarks of Autodesk Canada Co. in the USA and/or Canada and other countries: Backburner,Multi-Master Editing, River, and Sparks.

The following are registered trademarks or trademarks of MoldflowCorp. in the USA and/or other countries: Moldflow, MPA, MPA (design/logo),Moldflow Plastics Advisers, MPI, MPI (design/logo), Moldflow Plastics Insight,MPX, MPX (design/logo), Moldflow Plastics Xpert.

All other brand names, product names or trademarks belong to their respective holders.

Disclaimer

THIS PUBLICATION AND THE INFORMATION CONTAINED HEREIN IS MADE AVAILABLE BY AUTODESK, INC. "AS IS." AUTODESK, INC. DISCLAIMS ALL WARRANTIES, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE REGARDING THESE MATERIALS.

Published by:
Autodesk, Inc.
111 McInnis Parkway
San Rafael, CA 94903, USA

Contents

Chapter 1	Pointing Devices	1
	Pointing Device Buttons	1
	Digitizing Tablets	5
Chapter 2	Graphics System	7
	Hardware Acceleration Troubleshooting	7
Chapter 3	Use Plotters and Printers	9
	Supported Plotters	9
	Set Up Plotters and Printers	10
	Use the Plotter Configuration Editor	15
	Modify General PC3 File Information	17
	Control PC3 File Device and Document Settings	18
	Adjust Media Settings (For Nonsystem Plotters Only)	18
	Specify Physical Pen Configuration (For Pen Plotters Only)	20
	Specify Settings for Graphical Output	22
	Adjust Custom Properties	23
	Use Initialization Strings	25
	Calibrate Plotters and Work with Custom Paper Sizes	26
	Resolve Conflicts with the Windows Print Manager	34
	Port Settings	35
	Adjust Port Settings	36
	Use AutoSpool	38

	Set the Timeout Value for Devices	44
	Configure Serial Ports	45
Chapter 4	Set Device-Specific Configurations	49
	Configure Hewlett-Packard DesignJets	49
	Configure Hewlett-Packard HP-GL Plotters	50
	Configure Hewlett-Packard HP-GL/2 Devices	53
	Configure Xerox Devices	55
	Configure CalComp Plotters	57
	Configure Houston Instruments Plotters	58
	Use the Autodesk HDI System Printer Driver	59
Chapter 5	Configure for File Output	63
	Configure for File Output	63
Chapter 6	Configure External Databases	69
	Configure External Databases	69
Chapter 7	Driver Custom Properties Reference	81
	Autodesk-Supplied Plotter Drivers	81
	DWF Driver Custom Properties	81
	Overview of the DWF Driver Custom Properties	81
	Vector and Gradient Resolution (DWF)	82
	Raster Image Resolution (DWF)	83
	Font Handling (DWF)	84
	Additional Output Settings (DWF)	85
	Virtual Pen Set (DWF)	86
	Configure a DWF6 Driver (Advanced)	88
	DWFx Driver Custom Properties	102
	Overview of the DWFx Driver Custom Properties	102
	DWFx Driver Graphics Properties	102
	DWFx Driver Custom Properties	103
	Configure a DWFx Driver (Advanced)	106
	DXB Driver Custom Properties	113
	HP-GL Driver Custom Properties	114
	HP-GL Configuration Information (HP-GL)	114
	Long Plotting (HP-GL)	117
	Simplified HPGL (HP-GL)	118
	Request Hard Clip Limits from Plotter (HP-GL)	118
	Handshaking Instructions for Network Plotting and Plotting to a File (HP-GL)	119
	HP-GL/2 Driver Custom Properties	120
	HP-GL/2 Configuration Information (HP-GL/2)	120
	Plot Quality (HP-GL/2)	127

Long Plotting (HP-GL/2)	128
Merge Control (HP-GL/2)	128
Gamma Correction (HP-GL/2)	128
Nonsystem Driver Custom Properties	129
PDF Driver Custom Properties	129
Vector and Gradient Resolution (PDF)	130
Raster Image Resolution (PDF)	131
PostScript Driver Custom Properties	132
Overview of PostScript Driver Custom Properties	132
Printer Control (PostScript)	133
Preview Thumbnail in EPS Files (PostScript)	133
Default Plot to File Extension and Format (PostScript)	134
Raster Image Compression (PostScript)	134
Custom PostScript Error Handler (PostScript)	135
Raster Driver Custom Properties	135
Raster Configuration Information (Raster)	135
Background Color (Raster)	139
Rotate Raster Scanlines 90 Degrees (Raster)	139
System Driver Custom Properties	140
Third-Party Plotter Drivers	140
CalComp Driver Custom Properties	140
Supported Plotter Families (CalComp)	141
Configuring the Plotters (CalComp)	145
Setting Custom Properties (CalComp)	149
Plot Cutting (CalComp)	152
Virtual Pens(CalComp)	153
Xerox Driver Custom Properties	154
Xerox Wide Format Plotter Configuration Information (Xerox)	155
Xerox Wide Format Custom Properties Dialog Box (Xerox)	159
XES Synergix 8825/8830/8855 Driver Custom Properties	168
Use the AccXES Optimized System Printer Driver (XES)	169
What's New in the AccXES Optimized System Printer Driver (XES)	170
File Changes in the AccXES Optimized System Printer Driver (XES)	170
Benefits of Using the AccXES Optimized System Printer Driver (XES)	171
Available Settings for the AccXES Optimized Printer (XES)	171
Troubleshooting Hints (XES)	172
Index	173

Pointing Devices

1

You can control this program with a pointing device such as a mouse, digitizing puck, or stylus. A pointing device may have a number of buttons. The first 10 buttons are automatically assigned by the program, but you can reassign all but button 1, the pick button, by modifying the menu file. You can change how mouse buttons function by choosing the Mouse icon in the Windows Control Panel.

Pointing Device Buttons

The first 10 pointing device buttons are automatically assigned; you can reassign all except button 1, the pick button.

On a two-button mouse, the left button is the pick button used to

- Specify locations
- Select objects for editing
- Choose menu options and dialog box buttons and fields

The operation of the right button on a mouse depends on context; it can be used to

- End a command in progress
- Display a shortcut menu
- Display the Object Snap menu
- Display the Toolbars dialog box

Right-click operation can be modified in the Options dialog box (*OPTIONS*). The operation of additional buttons on a pointing device is defined in the menu file.

The Wheel Mouse

The wheel mouse has a small wheel between the buttons. The left and right buttons behave the same as they do on a standard mouse. You can rotate the wheel by discrete values. You can use the wheel to zoom and pan in your drawing without using any commands.

By default, the zoom factor is set to 10 percent; each increment in the wheel rotation changes the zoom level by 10 percent. The *ZOOMFACTOR* system variable controls the incremental change, whether forward or backward. The higher the number, the larger the change.

The following table lists the wheel mouse actions supported in this program.

To...	Do this...
Zoom in or out	Rotate the wheel forward to zoom in, backward to zoom out
Zoom to drawing extents	Double-click the wheel button
Pan	Hold down the wheel button and drag the mouse
Pan (joystick)	Hold down CTRL and the wheel button, and drag the mouse
Display the Object Snap menu	With the MBUTTONPAN system variable set to 0, click the wheel button

See also:

- “Mouse Buttons” in the *Customization Guide*

To practice using several features of the mouse

- 1 Move your mouse and notice that the pointer on the screen changes from crosshairs while the pointer is in the drawing area, to an arrow when it's not over the drawing area, and to an I-beam when it's in the text window.
- 2 As you continue to move the mouse, notice that the numbers in the coordinate display on the status bar change. These numbers indicate the exact location, or coordinate, of the crosshairs on the screen. Click in the coordinate display to turn it off. Notice that the coordinates are updated only when you click in the drawing area.
- 3 Find the Snap button on the status bar and click it with the pick button on your mouse (usually the left button). Notice that the button darkens to indicate that Snap mode has been turned on.
- 4 Move the pointer around the screen and observe that it seems to adhere, or "snap," to points at predetermined and equivalent intervals on the screen. You can change the size of these intervals.
- 5 Click the Snap button again to turn Snap mode off.
- 6 Move the pointer over the Standard toolbar at the top of the drawing area. As you leave the pointer over a button for a few moments, notice a pop-up label, called a tooltip, that identifies the button.
- 7 Move the pointer over double bars at the end of a toolbar. Then, as you hold down the pick button, drag the toolbar around the screen to reposition it.
- 8 Dock the toolbar by dragging it to a docking location at the top, bottom, or either side of the drawing area. When the outline of the toolbar appears in the docking area, release the pick button.

To turn off all shortcut menus in the drawing area

- 1 Click Tools menu ► Options.
- 2 In the Options dialog box, User Preferences tab, under Windows Standard Behavior, clear Shortcut Menus in Drawing Area.
- 3 Click OK to record the current options settings in the system registry and close the Options dialog box.

 **Command entry:** *OPTIONS*

To turn off shortcut menus individually

- 1 Click Tools menu ► Options.
- 2 In the Options dialog box, User Preferences tab, select Shortcut Menus in Drawing Area, and then click Right-Click Customization.
- 3 In the Right-Click Customization dialog box, under Default Mode, Edit Mode, or Command Mode, select the options to control what happens when you right-click in the drawing area.
- 4 Click Apply & Close to close the dialog box.
- 5 Click OK to record the current options settings in the system registry and close the Options dialog box.

 **Command entry:** *OPTIONS*

Quick Reference

Commands

OPTIONS

Customizes the program settings.

PAN

Moves the view in the current viewport.

ZOOM

Increases or decreases the magnification of the view in the current viewport.

System Variables

MBUTTONPAN

Controls the behavior of the third button or wheel on the pointing device.

SHORTCUTMENU

Controls whether Default, Edit, and Command mode shortcut menus are available in the drawing area.

ZOOMFACTOR

Controls how much the magnification changes when the mouse wheel moves forward or backward.

Utilities

No entries

Command Modifiers

No entries

Digitizing Tablets

You can use the puck or stylus of a digitizing tablet as a pointing device, or you can trace a paper drawing into a file.

A digitizing tablet, or digitizer, is a peripheral device that can be used to trace paper drawings into a drawing file or to choose commands from a digitizing tablet overlay. With the Wintab driver, the tablet pointer can also be used instead of a mouse as a system pointer to choose menu items and drawing objects or to interact with the operating system. The tablet pointer can be a *puck* or a *stylus*.

The digitizing tablet must first be configured and then can optionally be calibrated.

- When the tablet is *configured*, portions of the tablet surface are designated as menu areas and a screen-pointing area.
- When the tablet is *calibrated*, it can be used to trace geometry from an existing paper drawing or photograph into a drawing.

You can easily switch between using the tablet uncalibrated as a system pointer (Tablet mode off) or calibrated for digitizing a drawing (Tablet mode on). Click the Tablet button on the status bar. If a screen-pointing area has been designated, a Float button is displayed on the status bar and toggles the screen-pointing area on and off.

NOTE A sample digitizing tablet overlay, *tablet.dwg*, is included in the *Sample* folder, which is located in the product installation directory.

See also:

- “Create Tablet Menus” in the *Customization Guide*

Quick Reference

Commands

OPTIONS

Customizes the program settings.

REINIT

Reinitializes the digitizer, digitizer input/output port, and program parameters file

TABLET

Calibrates, configures, and turns on and off an attached digitizing tablet.

System Variables

TABMODE

Controls the use of the tablet.

Utilities

No entries

Command Modifiers

No entries

Graphics System

2

You can configure the graphics system to use either software or hardware acceleration. Enabling hardware acceleration may help to improve the performance of AutoCAD over using software acceleration.

Hardware Acceleration Troubleshooting

This chapter provides solutions to some of the most common problems when trying to use hardware acceleration with AutoCAD.

After starting Windows Netmeeting, hardware acceleration in AutoCAD disabled or unavailable. Is it possible to re-enable hardware acceleration? To re-enable hardware acceleration, turn off Remote Desktop Sharing or close Netmeeting. Then restart AutoCAD and hardware acceleration should be available.

After running a remote access application such as Remote Desktop, VMware, or Citrix hardware acceleration in AutoCAD is unavailable. Is it possible to use hardware acceleration with these applications? To use hardware acceleration, AutoCAD needs to be run locally from the computer. Hardware acceleration remains unavailable while any remote access application is running on the computer.

Why is hardware acceleration unavailable? The most common reason why hardware acceleration is unavailable is that a graphics display driver cannot be located on the system. To use hardware acceleration, visit the video card manufacturer's website or the AutoCAD Certification website (<http://www.autodesk.com/autocad-graphicscard>) to download and install the latest driver available for your system.

Why does hardware acceleration seem to disable on its own at times? There are some situations when AutoCAD drops out of hardware acceleration. The

following is a list of the known conditions when an error or driver failure commonly occur:

- You lock and unlock the workstation while AutoCAD is currently running.
- Screen saver was activated and AutoCAD is restored.
- You enable/disable the second monitor on the system.
- System returns from hibernation/standby.
- AutoCAD runs out of video memory.

Why is the Direct3D driver unavailable to use with hardware acceleration? To use the Direct3D driver for hardware acceleration, DirectX 9.0 must be installed on the system. To install DirectX 9.0c, insert the product's original installation media (DVD/CD) in your drive. Execute *DXSETUP.exe* from the Support\DirectX folder and follow the displayed prompts.

At times when I am using hardware acceleration, I encounter an error that prevents hardware acceleration from operating correctly and then it becomes unavailable. What should I do? To help ensure that hardware acceleration operates correctly, verify that you are running the latest service pack of the product and video graphics card driver before attempting to re-enable hardware acceleration.

Quick Reference

Commands

3DCONFIG

Sets options that affect 3D display performance.

System Variables

No entries

Utilities

No entries

Command Modifiers

No entries

Use Plotters and Printers

3

You can produce hard copy output of your drawings using many different types of plotters and printers. You can send output to files using a variety of formats.

Supported Plotters

HDI (Heidi® Device Interface) drivers are used to communicate with hard copy devices. These drivers fall into three categories: file format drivers, HDI nonsystem drivers, and HDI system printer drivers.

HDI drivers should be used for older 'legacy' devices that can't be set up through the Operating System (OS). Newer devices that can be configured through the OS should be used by AutoCAD as a system printer instead of a nonsystem printer.

Please check with your vendor to see if there is compatibility with the plotter and AutoCAD.

NOTE It is highly recommended that you update your drivers regularly to avoid plotting problems.

Quick Reference

Commands

PLOT

Plots a drawing to a plotter, printer, or file.

PLOTTERMANAGER

Displays the Plotter Manager, where you can add or edit a plotter configuration.

System Variables

No entries

Utilities

No entries

Command Modifiers

No entries

Set Up Plotters and Printers

Each plotter configuration contains information such as the device driver and model, the output port to which the device is connected, and various device-specific settings.

AutoCAD lists printers or plotters configured for use with Windows in the Plot and Page Setup dialog boxes. You do not need to configure these devices with the system printer driver unless the AutoCAD defaults differ from the Windows values.

NOTE Nonsystem devices are referred to as plotters and Windows system devices are referred to as printers.

If a plotter is supported by AutoCAD, but not by Windows, you can use one of the HDI nonsystem printer drivers. You can also use a nonsystem driver to create PostScript, raster, or Design Web format (DWF) files and Portable Document Format (PDF) files

You must configure local or network nonsystem plotters and Windows system printers with nondefault settings. You do not need to configure system printers if you change only the paper size.

AutoCAD stores information about the media and plotting device in configured plot (PC3) files. Plot configurations are portable and can be shared in an office or on a project as long as they are for the same driver, model, and driver version. Shared plot configurations for Windows system printers may also need to be for the same version of Windows. If you calibrate a plotter, the calibration information is stored in a plot model parameter (PMP) file that you can attach to any PC3 files you create for the calibrated plotter.

You can configure AutoCAD for many devices, and store multiple configurations for a single device. Each plotter configuration contains information such as the device driver and model, the output port to which the device is connected, and various device-specific settings. You can create several PC3 files with different output options for the same plotter. After you create a PC3 file, it's available in the list of plotter configuration names in the Plot dialog box.

To create these PC3 files, use the Add-a-Plotter wizard in the Autodesk Plotter Manager. The Plotter Manager is a Windows Explorer window. The Add-a-Plotter wizard is modeled after the Windows Add Printer wizard. Using the Add-a-Plotter wizard, you can specify whether you want to configure a nonsystem, local, or network plotter, or a system printer. You can create any number of plotter device configurations that use either the Windows system printer drivers or Autodesk nonsystem plotter drivers. Your configurations are stored in your user profile.

There are a number of ways to modify the default settings for a Windows system printer without creating a PC3 file. For example, you can modify the properties systemwide from the Control Panel. You can also choose Properties in the Plot dialog box and plot without saving the properties.

NOTE If you upgrade a driver, try using your existing PC3 file. If it does not work, then you need to create a new PC3 file. In many cases, it may be possible to copy and paste some of the settings from the old PC3 file to a new one created with the new driver.

See also:

- [Use the Plotter Configuration Editor](#) on page 15
- [Calibrate Plotters and Work with Custom Paper Sizes](#) on page 26

To open the Autodesk Plotter Manager

You can also use any of the following methods to open the Autodesk Plotter Manager:

- From the File menu, choose Plotter Manager.
- At the command prompt, enter **plottermanager**.
- From the Tools menu, choose Options. On the Plot and Publish tab, choose Add or Configure Plotters.

To create a PC3 file for a Windows system printer

- 1 Open the Autodesk Plotter Manager.
- 2 In the Autodesk Plotter Manager, double-click the Add-a-Plotter Wizard shortcut icon.
- 3 In the Add-a-Plotter wizard, read the Introduction, and then choose Next to advance to the Add Plotter - Begin page.
- 4 On the Add Plotter - Begin page, choose System Printer. Choose Next.
- 5 On the Add Plotter - System Printer page, select the system printer that you want to configure.

The list includes all printers known to the operating system. If you want to connect to a printer that is not in the list, you must first add the printer using the Windows Add Printer wizard in the Control Panel.

(Optional)The Import PCP or PC2 screen enables you to use configuration information from a PCP or PC2 file created with an earlier version of AutoCAD.
- 6 On the Add Plotter - Plotter Name page, enter a name to identify the currently configured plotter. Choose Next.
- 7 When you reach the Add Plotter - Finish page, you can choose Finish to exit the Add-a-Plotter wizard.

A PC3 file for the newly configured plotter appears in the Plotters window and the plotter is available for plotting in the list of devices.

At this time, you can change the default settings for the plotter by choosing Edit Plotter Configuration on the Add Plotter - Finish page. You can also perform a plot calibration test on your newly configured plotter by choosing Calibrate Plotter on the Add Plotter - Finish page.

To configure a local, nonsystem plotter

- 1 Open the Autodesk Plotter Manager.
- 2 In the Autodesk Plotter Manager, double-click the Add-a-Plotter Wizard shortcut.
- 3 In the Add-a-Plotter wizard, read the Introduction, and then choose Next to advance to the Add Plotter - Begin page.
- 4 On the Add Plotter - Begin page, choose My Computer. Choose Next.

- 5 On the Add Plotter - Plotter Model page, select a manufacturer and model. Choose Next.

If you are configuring a PostScript device, select Adobe from the Manufacturers list.

If your plotter is not in the list of available plotters, and you have a driver disk for your plotter, choose Have Disk to locate the HIF file on that driver disk, and install the driver supplied with your plotter.

(Optional) The Import PCP or PC2 screen enables you to use configuration information from a PCP or PC2 file created with an earlier version of AutoCAD.

- 6 On the Add Plotter - Ports page, select the port to use when plotting. Choose Next. The ports available for the specified device are displayed.
- 7 On the Add Plotter - Plotter Name page, enter a name to identify the currently configured plotter. Choose Next.
- 8 When you reach the Add Plotter - Finish page, you can choose Finish to exit the Add-a-Plotter wizard.

A PC3 file for the newly configured plotter appears in the Plotters window, and the plotter is available for plotting in the list of devices.

At this time, you can change the default settings for the plotter by choosing Edit Plotter Configuration on the Add Plotter - Finish page. You can also perform a plot calibration test on your newly configured plotter by choosing Calibrate Plotter on the Add Plotter - Finish page.

To configure a network, nonsystem plotter

- 1 Open the Autodesk Plotter Manager.
- 2 Double-click the Add-a-Plotter Wizard shortcut icon.
- 3 In the Add-a-Plotter wizard, read the Introduction, and then choose Next to advance to the Add Plotter - Begin page.
- 4 On the Add Plotter - Begin page, choose Network Plotter Server. Choose Next.
- 5 On the Add Plotter - Network Plotter page, enter the share name of the network plotter server that you want to use.

The server must already exist on the network. For more information, see your system administrator.

You must use the universal naming convention (UNC). The correct format of a UNC path is `\\server name\share name`. You can select an existing share name on your network by choosing Browse.

- 6 On the Add Plotter - Plotter Model page, select a manufacturer and model. Choose Next.

If you are configuring a PostScript device, select Adobe from the Manufacturers list.

If your plotter isn't in the list of available plotters and you have a driver disk for your plotter, choose Have Disk to locate the HIF file on that driver disk, and install the driver supplied with your plotter.

(Optional) The Import PCP or PC2 screen enables you to use configuration information from a PCP or PC2 file created with an earlier version of AutoCAD.

- 7 On the Add Plotter - Plotter Name page, enter a name to identify the currently configured plotter. Choose Next.
- 8 When you reach the Add Plotter - Finish page, you can choose Finish to exit the Add-a-Plotter wizard.

A PC3 file for the newly configured plotter appears in the Plotters window and the plotter is available for plotting in the list of devices.

At this time, you can change the default settings for the plotter by choosing Edit Plotter Configuration on the Add Plotter - Finish page. You can also perform a plot calibration test on your newly configured plotter by choosing Calibrate Plotter on the Add Plotter - Finish page.

Quick Reference

Commands

PAGESETUP

Controls the page layout, plotting device, paper size, and other settings for each new layout.

PCINWIZARD

Displays a wizard to import PCP and PC2 configuration file plot settings into the Model tab or current layout.

PLOT

Plots a drawing to a plotter, printer, or file.

PLOTTERMANAGER

Displays the Plotter Manager, where you can add or edit a plotter configuration.

System Variables

No entries

Utilities

No entries

Command Modifiers

No entries

Use the Plotter Configuration Editor

After you create a configured plotter (PC3) file using the Add-a-Plotter wizard, you can edit the file using the Plotter Configuration Editor.

The Plotter Configuration Editor provides options for modifying a plotter's port connections and output settings including media, graphics, physical pen configuration, custom properties, initialization strings, calibration, and user-defined paper sizes. You can drag and drop these options from one PC3 file to another.

NOTE When dragging and dropping one leaf, the whole branch will come over with the leaf. If you drag from a Windows system driver, in most cases, the Custom branch will also be copied. For nonsystem drivers, the Custom leaf is copied only if it is explicitly selected.

The Plotter Configuration Editor contains three tabs. The General tab contains basic information about the configured plotter. The Ports tab contains information about the communication between the plotting device and your computer. The Device and Document Settings tab contains plotting options. Depending on your configured plotting device, additional options are available on the Device and Document Settings tab. For example, when you configure a nonsystem pen plotter you have the option to modify the physical pen characteristics.

You can edit the plotter configuration files for both nonsystem and system plotters. You can also modify the default settings for a Windows system printer

without creating a PC3 file. For example, you can modify the properties systemwide in the Windows Control Panel. You can also choose Properties in the Plot dialog box and plot without saving the properties.

To start the Plotter Configuration Editor

Use one of the following methods:

- Double-click a PC3 file from Windows Explorer or right-click the file and choose Open. (By default, PC3 files are stored in the user profile folder.)
- Choose Edit Plotter Configuration on the Add Plotter - Finish page in the Add-a-Plotter wizard.
- On the File menu, click Plot. In the Plot dialog box, under Printer/Plotter select a device, and then click Properties.
- On the File menu, click Page Setup. In Page Setup Manager, select a page setup, and then click Modify. In the Page Setup dialog box, under Printer/Plotter select a device and then click Properties.

To save a PC3 file under a new file name

- 1 From the File menu, choose Plotter Manager.
- 2 In the Autodesk Plotter Manager, double-click to open the PC3 file you want to use.
- 3 In the Plotter Configuration Editor, choose the Device and Document Settings tab.
- 4 Choose Save As.
- 5 In the Save As dialog box, enter a new file name for the PC3 file.
- 6 Choose Save.

Quick Reference

Commands

PLOTTERMANAGER

Displays the Plotter Manager, where you can add or edit a plotter configuration.

System Variables

No entries

Utilities

No entries

Command Modifiers

No entries

Modify General PC3 File Information

The General tab of the Plotter Configuration Editor contains basic information about the PC3 file. You can add or modify the information in the Description area.

The rest of the tab is read-only. The information on the General tab includes

- Configured plotter file name
- Description or other information you want to include about the plotter
- Plotter driver type (system or nonsystem), name, model, and location
- HDI driver file version number (AutoCAD specialized driver files)
- UNC name of the network server (if the plotter is connected to a network server), the input/output port (if the plotter is connected locally), or the name of the system printer (if the configured plotter is the system printer)
- PMP file name and location (if a plotter calibration file [PMP] is attached to the PC3 file)

To add or modify the PC3 file description

- 1 From the File menu, choose Plotter Manager.
- 2 Double-click the plotter configuration (PC3) file whose settings you want to change.
- 3 In the Plotter Configuration Editor, choose the General tab.
- 4 Insert the cursor in the Description area.

- 5 Add a description or modify the existing description for the PC3 file.

Quick Reference

Commands

PLOTTERMANAGER

Displays the Plotter Manager, where you can add or edit a plotter configuration.

System Variables

No entries

Utilities

No entries

Command Modifiers

No entries

Control PC3 File Device and Document Settings

In the Plotter Configuration Editor, on the Device and Document Settings tab, you can change many of the settings in the configured plot (PC3) file.

NOTE Only the settings available for the configured device are displayed in the tree view. In addition, you might not be able to edit some settings if the device handles the setting through the Custom Properties option or doesn't support the capability.

Adjust Media Settings (For Nonsystem Plotters Only)

Depending on the features supported by your configured plotter, you can modify the paper source, type, and size of your paper.

You can specify whether you want to print on both sides or just one side. If your printer supports cutting, collating, and stapling, you can specify your

choice under the Media Destination option. For Windows system printers, you must configure the Media settings using the Custom Properties option.

To adjust media settings

- 1 From the File menu, choose Plotter Manager.
- 2 Double-click the plotter configuration (PC3) file whose media settings you want to change.
- 3 In the Plotter Configuration Editor, choose the Device and Document Settings tab.
- 4 Double-click Media to view the media settings.
- 5 Do one of the following:
 - **Select Source and Size.** Under Media Source and Size, select a paper source from the Source list. If appropriate, select a roll width from the Width list or a tray from the Tray Type list. Under Size, select the paper size you want to use. Select Automatic to tell the printer to select the appropriate paper source.
 - **Select Media Type.** Under Media Type, select one of the available media types.
 - **Select Duplex Printing.** Under Print on Both Sides (Duplex Printing), select Short Side or Long Side. This setting may not be available for your plotter.
 - **Select Media Destination.** Under Media Destination, specify one of the available options, for example, cutting. This setting may not be available for your plotter.
- 6 When finished, choose OK.

 **Command entry:** *PLOTTERMANAGER*

Quick Reference

Commands

PLOTTERMANAGER

Displays the Plotter Manager, where you can add or edit a plotter configuration.

System Variables

No entries

Utilities

No entries

Command Modifiers

No entries

Specify Physical Pen Configuration (For Pen Plotters Only)

In the Plotter Configuration Editor, the Physical Pen Configuration setting controls the pens in the pen plotter.

You can specify pen swapping on a single pen plotter, adjust the polygon area for pen width, and set pen optimization if the configured plotter supports these features. The lower pane of the Device and Document Settings tab displays a table that describes the color, width, and speed of each pen in the plotter.

NOTE Physical pen information cannot be detected automatically. You must provide this information for your pen plotter under the Physical Pen Characteristics option.

You must specify the pen settings even if you don't plan to use plot style tables. If you choose not to create a plot style table, AutoCAD automatically assigns pens, using the pen color and width information you provide. AutoCAD uses the pen whose color is closest to the color assigned to the object. If more than one pen matches, then the pen with the closest width is used. If the best pen is narrower than the object's width, several strokes are used to draw the object. If you use a plot style table, you can assign a physical pen number to each plot style.

See also:

- “Switch the Type of Plot Style Table” in the User's Guide

To configure pens

- 1 From the File menu, choose Plotter Manager.
- 2 Double-click the plotter configuration (PC3) file whose pen settings you want to change.
- 3 In the Plotter Configuration Editor, choose the Device and Document Settings tab.
- 4 Double-click Physical Pen Configuration to view the pen configuration settings.
- 5 Select Pen Configuration. Under Pen Configuration, do one of the following:
 - If you use a single-pen plotter and want to use different pens when you plot, select Prompt for Pen Swapping.
 - For greater accuracy when plotting filled areas and wide polylines, choose Area Fill Correction. AutoCAD moves the pen inward by half a pen width.
 - Under Pen Optimization Level, select one of the available methods. Each method in the list includes the optimization methods preceding it in the list (except for No Optimization).
- 6 Select Physical Pen Characteristics. For each pen in your plotter, specify the color, speed, and width. This step is required.

NOTE Use the Plot Style Table Editor to assign specific colors and pen widths to your objects that correspond to the plotted colors and widths for your plotting device.

- 7 When finished, choose OK.

 **Command entry:** *PLOTTERMANAGER*

Quick Reference

Commands

PLOTTERMANAGER

Displays the Plotter Manager, where you can add or edit a plotter configuration.

System Variables

No entries

Utilities

No entries

Command Modifiers

No entries

Specify Settings for Graphical Output

Depending on the capabilities of your configured plotter, you can modify the plotter's color depth, resolution, or dithering and specify whether the output is color or monochrome for vector drawings.

When printing raster images on a plotter with limited memory, you can specify some image-quality trade-offs to improve performance. If you use a nonsystem plotter that supports varying amounts of installed RAM, you can provide AutoCAD with that information to improve performance.

To specify graphics settings

- 1 From the File menu, choose Plotter Manager.
- 2 Double-click the plotter configuration (PC3) file whose pen settings you want to change.
- 3 In the Plotter Configuration Editor, choose the Device and Document Settings tab.
- 4 Double-click Graphics to view the graphical output settings.
- 5 Do one of the following:
 - Select Installed Memory and enter the amount of memory available in the plotter.
 - Select Vector Graphics and select color depth, resolution, and dithering.
 - Select Raster Graphics and specify a balance between output quality and performance.

- Select TrueType Text and select the way you want to print TrueType text.
- Select Merge control and specify whether crossing lines should overwrite the lines beneath them or merge.

6 When finished, choose OK.

 **Command entry:** *PLOTTERMANAGER*

Quick Reference

Commands

PLOTTERMANAGER

Displays the Plotter Manager, where you can add or edit a plotter configuration.

System Variables

No entries

Utilities

No entries

Command Modifiers

No entries

Adjust Custom Properties

In the Plotter Configuration Editor, you can modify the device-specific properties for the configured plotter by selecting Custom Properties from the tree view on the Device and Document Settings tab.

The settings for each plotter vary. If the plotter manufacturer has not included a Custom Properties dialog box for the device driver, the Custom Properties option is unavailable. For other drivers, the Customs Properties option is the only tree view option available. For Windows system printers, most of the device-specific settings are made in this dialog box.

For device-specific information, choose Help in the Custom Properties dialog box for the driver you have configured.

To specify custom properties

- 1 From the File menu, choose Plotter Manager.
- 2 Double-click the plotter configuration (PC3) file whose custom properties you want to change.
- 3 In the Plotter Configuration Editor, choose the Device and Document Settings tab.
- 4 In the tree view, select Custom Properties. Under Access Custom Dialog, choose the Custom Properties button.
- 5 Set the properties for the printer or plotter. The properties vary depending on the plotter and manufacturer.
- 6 Choose OK to exit each dialog box.

 **Command entry:** *PLOTTERMANAGER*

Quick Reference

Commands

PLOTTERMANAGER

Displays the Plotter Manager, where you can add or edit a plotter configuration.

System Variables

No entries

Utilities

No entries

Command Modifiers

No entries

Use Initialization Strings

You can use ASCII text initialization strings to prepare the plotter for printing.

If you're plotting to an unsupported, nonsystem plotter in Emulation mode, you can use ASCII text initialization strings to prepare the plotter for printing, set device-specific options, and restore the plotter to its original state. Only advanced users should use initialization strings.

To set initialization strings

- 1 From the File menu, choose Plotter Manager.
- 2 Double-click the plotter configuration (PC3) file whose initialization string settings you want to change.
- 3 In the Plotter Configuration Editor, choose the Device and Document Settings tab.
- 4 In the tree view, select Initialization Strings to view the initialization string settings.
- 5 Enter a Pre-Initialization string, Post-Initialization string, and Termination string as required.
- 6 Choose OK.

 **Command entry:** *PLOTTERMANAGER*

Quick Reference

Commands

PLOTTERMANAGER

Displays the Plotter Manager, where you can add or edit a plotter configuration.

System Variables

No entries

Utilities

No entries

Command Modifiers

No entries

Calibrate Plotters and Work with Custom Paper Sizes

You should perform a plotter calibration only if your drawings must be exactly to scale and your plotter or printer produces inaccurate plots.

You can adjust plotter calibration to correct scaling discrepancies, and you can add custom paper sizes for nonsystem plotters.

Calibration Files

Plotter calibration is an optional process. If your plotter meets the manufacturer's specifications for accuracy of scale, a 10-inch line in a drawing plotted at a scale of 1:1 should be exactly 10 inches long on paper. If you need to correct scaling discrepancies, you can adjust the plotter calibration. If your plotter provides a calibration utility, use that utility instead of the AutoCAD calibration utility so the calibration is available for all applications using the plotter.

To calibrate a plotter, you must specify the dimensions of a test rectangle, print the test rectangle, measure actual dimensions, and enter the actual measurements in the Calibrate Plotter wizard. AutoCAD calculates the necessary calibration for the plotter.

When you complete the Calibrate Plotter wizard, AutoCAD creates a plot model parameter (PMP) file to store the results of the calibration for each plot device. AutoCAD automatically attaches the resulting PMP file to the plotter configuration (PC3) file that you used to perform the calibration test.

Calibrating a plotter creates a plotter model parameter (PMP) file that contains calibration information. If the PMP file is not already attached to the plotter configuration file (PC3) you are editing, you must create that association so you can use the PMP file. If the plotter was calibrated from within the Add-a-Plotter wizard, the PMP file is already attached. You can use the Calibration and User Defined Paper Sizes option to add PMP files to and detach PMP files from the PC3 file. If you have more than one PC3 file for a device, you can attach the same PMP file to them using the Plotter Configuration Editor. Because PMP files are plotter specific, it's appropriate to attach only one PMP file to a PC3 file.

NOTE You should perform a plotter calibration only if your drawings must be exactly to scale and your plotter or printer produces inaccurate plots. Plotter calibration causes AutoCAD to rescale all plots sent to your plotter to correct errors in its hardware scaling. It is recommended that you use any calibration setting provided by your plotter instead of the AutoCAD setting.

Custom Paper Sizes

For a nonsystem plotter, you can choose the Add option to create a custom paper size or change the printable area of a standard or nonstandard paper size. Using the Custom Paper Size wizard, you can create a new paper size or select from a list of available paper sizes (from a PMP file). For a Windows system printer, use the Custom Properties option to adjust paper settings.

You can modify standard paper sizes to adjust the printable area to match a printer's capabilities. In the Plotter Configuration Editor, you cannot create custom paper sizes for Windows system printers, but you can correct errors in the printable area of standard paper sizes.

To calibrate a plotter

- 1 From the File menu, choose Plotter Manager.
- 2 Double-click the Add-a-Plotter wizard icon.
- 3 Start the Add-a-Plotter wizard and configure the device you want to add.
- 4 When you reach the Add Plotter - Finish page, choose Calibrate Plotter.

You can also calibrate a plotter by running the Plotter Configuration Editor on an existing PC3 file for the device you want to calibrate.

- 5 In the Paper Size list, select a paper size for the test plot. Choose Next.
- 6 On the Calibrate Plotter - Rectangle Size page, in the Units list, select the measurement units.
- 7 In the Length and Width boxes, enter the dimensions of the test rectangle. Choose Next. AutoCAD plots the test rectangle.
- 8 Retrieve the plot and measure the test rectangle. On the Calibrate Plotter - Measured Plot page, in the Measured Length and Measured Width boxes, enter the actual dimensions of the plotted test rectangle. Choose Next.
AutoCAD compares the actual plotted measurements to the size you specified in the preceding screen and computes the correction needed to accurately calibrate the plotter.
- 9 On the Calibrate Plotter - File name page, enter a file name. Choose Next.
The resulting PMP file is stored in the AutoCAD *Drv* folder.
- 10 On the Calibrate Plotter - Finish page, choose Check Calibration.
AutoCAD plots the text rectangle again. Measure the sides again to verify that the calibration is correct.
- 11 Choose Finish to return to the Add-a-Plotter wizard or Plotter Configuration Editor.

 **Command entry:** *PLOTTERMANAGER*

To attach a PMP file to a PC3 file

After you create a PMP file, that file is attached to the PC3 file from which you started the Calibrate Plotter wizard. You can attach an existing PMP file to a different PC3 file using the Plotter Configuration Editor.

- 1 From the File menu, choose Plotter Manager.
- 2 Double-click the plotter configuration to which you want to attach a PMP file.
- 3 On the Device and Document Settings tab, from User-Defined Paper Sizes & Calibration, select PMP File Name *<file name>*.
If this PC3 file doesn't have an attached PMP file, the PMP File Name setting doesn't show an attached file. Choose Attach.

- 4 Locate the PMP file you want to attach to this PC3 file and choose Open.
- 5 Choose OK to close the Plotter Configuration Editor.
The PMP File Name setting is updated.

 **Command entry:** *PLOTTERMANAGER*

To detach a PMP file from a PC3 file

After you create a PMP file, that file is attached to the PC3 file from which you started the Calibrate Plotter wizard. You can detach a PMP from a PC3 file using the Plotter Configuration Editor.

- 1 From the File menu, choose Plotter Manager.
- 2 Double-click the plotter configuration from which you want to detach a PMP file.
- 3 On the Device and Document Settings tab, select User-defined Paper Sizes & Calibration and then select the PMP File Name *<file name>*.
- 4 Choose Detach. (If this PC3 file doesn't have an attached PMP file, the Detach option is unavailable.)
- 5 Choose OK to close the Plotter Configuration Editor.

 **Command entry:** *PLOTTERMANAGER*

To save a PMP file to a new file name

After you create a PMP file, that file is attached to the PC3 file from which you started the Calibrate Plotter wizard. You can save the PMP file with a new file name using the Plotter Configuration Editor.

- 1 From the File menu, choose Plotter Manager.
- 2 Double-click the plotter configuration from which you want to save a PMP file.
- 3 In the Plotter Configuration Editor, choose the Device and Document Settings tab.
- 4 Double-click User-Defined Paper Sizes & Calibration to display the calibration and paper size options.
- 5 Under PMP File, choose Save PMP.

- 6 In the Save As dialog box, enter a new file name for the PMP file that's attached to the PC3 file you're editing.
- 7 Choose Save.
The new file name is displayed in angle brackets beside the PMP File Name option in the tree view.
- 8 Choose OK to close the Plotter Configuration Editor.

 **Command entry:** *PLOTTERMANAGER*

To add a new custom paper size from scratch (nonsystem HDI drivers only)

- 1 From the File menu, choose Plotter Manager.
- 2 Double-click the plotter configuration you want to modify.
- 3 In the Plotter Configuration Editor, choose the Device and Document Settings tab.
- 4 Double-click User-Defined Paper Sizes & Calibration to display the calibration and paper size options. Then select Custom Paper Sizes.
- 5 Under Custom Paper Sizes, choose Add.
- 6 In the Custom Paper Size Wizard, on the Begin page, select Start from Scratch. Choose Next.
- 7 On the Media Bounds page, in the Units list, select either Inches or Millimeters for paper size.
When you plot a nondimensional raster image, such as BMP or TIFF, the size of the plot is specified in pixels, not inches or millimeters.
- 8 From the Width and Length lists, select the paper width and length. Choose Next.
Each plotter has a maximum printable area determined by where it grips the paper and how far the pen shuttle reaches. Verify that the plotter is capable of plotting the new dimensions.
- 9 On the Printable Area page, in the Top, Bottom, Left, and Right boxes, specify the printable area. Choose Next.
- 10 On the Paper Size Name page, enter a name for the paper size. Choose Next.
- 11 On the File Name page, enter a name for the PMP file.

- 12 On the Finish page, specify whether the paper source is Sheet-Fed or Roll-Fed. Choose Print Test Page to verify the custom size.
AutoCAD prints a cross that defines the paper size and a rectangle that defines the printable area. If all four sides of the rectangle are not printed, increase the printable area.
- 13 Choose Finish to exit the Custom Paper Size wizard.

 **Command entry:** *PLOTTERMANAGER*

To add a new custom paper size from scratch (system printers only)

- 1 From the File menu, choose Plotter Manager.
- 2 Double-click the plotter configuration you want to modify.
- 3 In the Plotter Configuration Editor, choose the Device and Document Settings tab.
- 4 Select Custom Properties.
- 5 Choose Custom Properties in the Access Custom Dialog area.
The device driver-specific user interface opens.
- 6 Follow the manufacturer's instructions to add a custom paper size.
You may need to choose the Help button for more information.

 **Command entry:** *PLOTTERMANAGER*

To add a new custom paper size starting from an existing paper size

- 1 From the File menu, choose Plotter Manager.
- 2 Double-click the plotter configuration you want to modify.
- 3 In the Plotter Configuration Editor, choose the Device and Document Settings tab.
- 4 Double-click User-Defined Paper Sizes & Calibration to display the calibration and paper size options. Then select Custom Paper Sizes.
- 5 Under Custom Paper Sizes, choose Add.
- 6 In the Custom Paper Size wizard, on the Begin page, select Use Existing.
- 7 From the list of existing standard paper sizes, select a paper size on which to base the custom paper size you are creating.

- 8 On the Media Bounds page, select either Inches or Millimeters for paper size and specify the paper width and length. Choose Next.
Each plotter has a maximum printable area determined by where it grips the paper and how far the pen shuttle reaches. Verify that the plotter is capable of plotting the new dimensions.
- 9 On the Printable Area page, in the Top, Bottom, Left, and Right boxes, specify the printable area. Choose Next.
- 10 On the Paper Size Name page, enter a name for the paper size. Choose Next.
- 11 On the File Name page, enter a name for the PMP file.
- 12 On the Finish page, specify whether the paper source is Sheet-Fed or Roll-Fed. Choose Print Test Page to verify the custom size.
AutoCAD prints a cross that defines the paper size and a rectangle that defines the printable area. If all four sides of the rectangle are not printed, increase the printable area.
- 13 Choose Finish to exit the Custom Paper Size wizard.

 **Command entry:** *PLOTTERMANAGER*

To edit a custom paper size

- 1 From the File menu, choose Plotter Manager.
- 2 Double-click the plotter configuration you want to modify.
- 3 In the Plotter Configuration Editor, choose the Device and Document Settings tab.
- 4 Double-click User-Defined Paper Sizes & Calibration to display the calibration and paper size settings.
- 5 Select Custom Paper Sizes.
- 6 Under Custom Paper Sizes, select a paper size from the list. Choose Edit.
- 7 In the Custom Paper Size wizard, make changes to the paper size, printable area, custom paper size name, and source.
- 8 Choose Finish to exit the Custom Paper Size wizard.
- 9 Choose OK.

 **Command entry:** *PLOTTERMANAGER*

To delete a custom paper size

- 1 From the File menu, choose Plotter Manager.
- 2 Double-click the plotter configuration you want to modify.
- 3 In the Plotter Configuration Editor, choose the Device and Document Settings tab.
- 4 Double-click User-Defined Paper Sizes & Calibration to display the calibration and paper size settings.
- 5 Select Custom Paper Sizes.
- 6 Under Custom Paper Sizes, select a paper size from the list.
- 7 Choose Delete.
- 8 Choose OK.

 **Command entry:** *PLOTTERMANAGER*

To modify a standard paper size

- 1 From the File menu, choose Plotter Manager.
- 2 Double-click the plotter configuration you want to modify.
- 3 In the Plotter Configuration Editor, choose the Device and Document Settings tab.
- 4 Double-click User-Defined Paper Sizes & Calibration to display the calibration and paper size settings.
- 5 Select Modify Standard Paper Sizes.
- 6 Under Modify Standard Paper Sizes, select the paper size you want to adjust. Then choose Modify.
- 7 In the Custom Paper Size wizard, adjust the printable area as necessary. Then choose Finish to exit the Custom Paper Size wizard.

 **Command entry:** *PLOTTERMANAGER*

To filter paper sizes

- 1 From the File menu, choose Plotter Manager.
- 2 Double-click the plotter configuration you want to modify.

- 3 In the Plotter Configuration Editor, choose the Device and Document Settings tab.
- 4 Double-click User-Defined Paper Sizes & Calibration to display the calibration and paper size settings.
- 5 Select Filter Paper Sizes.
- 6 In the Size list in the Filter Paper Sizes area, check the paper sizes you want to appear in the Paper Size lists in the Plot and Page Setup dialog boxes.

 **Command entry:** *PLOTTERMANAGER*

Quick Reference

Commands

PLOTTERMANAGER

Displays the Plotter Manager, where you can add or edit a plotter configuration.

System Variables

No entries

Utilities

No entries

Command Modifiers

No entries

Resolve Conflicts with the Windows Print Manager

You need to use the appropriate driver for a locally connected plotter.

If you configure an HDI hardcopy driver for a locally connected plotter and configure a Windows system printer for the same locally connected plotter, the HDI driver is unable to connect directly to the local port because the

Windows system printer driver has control over it. The driver output is rerouted to the Windows print spooler.

If the plotter is connected to a serial port, make sure that the Windows Control Panel settings for that serial port are correct. The settings should match the settings of the plotter and should be appropriate for the cabling you have used. You can verify that these settings are correct by printing to the conflicting Windows system printer.

Plotting from an HDI driver through the spooler is similar to plotting to a file because there is only one-way communication with the plotter. Performance varies depending on the device.

Quick Reference

Commands

PLOTTERMANAGER

Displays the Plotter Manager, where you can add or edit a plotter configuration.

System Variables

No entries

Utilities

No entries

Command Modifiers

No entries

Port Settings

The Ports tab in the Plotter Configuration Editor contains information about the plotter's port configuration.

Adjust Port Settings

There are three possible places to configure your computer's port settings, depending on how your plotter is connected.

The Ports tab in the Plotter Configuration Editor contains information about the plotter's port configuration. If you configure a local, nonsystem plotter, you must specify the port to which the device is connected. You can choose a serial (local), parallel (local), or network port. For parallel ports, the default is LPT1. For serial ports, the default is COM1. Change the port name if your device is connected to a different port.

If you use a serial port, the settings within AutoCAD must match the plotter settings. Choose Configure Ports to make the AutoCAD settings match your plotter settings. The available protocols for your plotter are displayed.

NOTE If you are using a device that emulates the configured device and has additional port options, select Show All Ports.

You can also change settings for communication between the PC3 file and your computer or network system. You can plot through a port, plot to a file, or use the AutoSpool feature to plot in the background while you continue working. If you plot through a parallel port, you can specify the timeout value. If you plot through a serial port, you can change the baud rate, protocol, flow control, and input and output timeout values.

There are three possible places to configure your computer's port settings, depending on how your plotter is connected.

Locally Connected Spooling

Your plotter is locally connected if it's plugged in to a port on the computer that's running AutoCAD. AutoCAD spools the plot (sends it through the Windows system spooler) if you also have configured a Windows system printer to print to the same plotter using the same local port. You are notified if your plot is being spooled due to a port conflict of this type, although you can use a setting on the Plot and Publish tab in the Options dialog box to turn off this warning.

Plotting through the system spooler is quicker. However, this method puts the conflicting Windows system printer in control of the input/output port configuration. The AutoCAD-configured port settings are ignored in this case. To view or adjust the port settings, go to the Windows Print Manager in the Control Panel and activate the printer that is configured for your plotter. You can adjust port settings in the Windows system printer's Properties dialog box.

You can print a test page from the Properties dialog box to verify that the plotter and computer are communicating correctly.

Locally Connected, But Not Spooling

If your plotter is locally connected and there is no conflicting system printer, AutoCAD can directly control the input/output port settings.

Across a Network

If you're running AutoCAD on one computer and plotting to a device connected to another computer on the network, the remote computer is in control of the port settings, and the AutoCAD configured port settings are ignored. A Windows system printer must be configured on the remote computer. (This is how the plotter was shared on the network and made available to you.) The remote system printer controls the port settings; you can view and change these settings in each system printer file's Properties dialog box, on the remote computer.

See also:

- [Use AutoSpool](#) on page 38

To adjust port settings

- 1 From the File menu, choose Plotter Manager.
- 2 Double-click the plotter configuration (PC3) file whose port settings you want to change.
- 3 In the Plotter Configuration Editor, choose the Ports tab.
- 4 Select one of the following options:
 - **Plot to the Following Port.** Sends the drawing to the printer through the specified port.
 - **Plot to File.** Sends the drawing to the file name specified on the File tab in the Options dialog box.
 - **AutoSpool.** Uses the AutoSpool utility specified on the File tab in the Options dialog box to plot the drawing.
- 5 For a device that emulates the configured device and has additional port options, select Show All Ports.

- 6 To connect a nonsystem plotter to another instance of the device, choose Browse Network. In the Browse for Printer dialog box, select the device and choose OK.
- 7 Choose OK.

 **Command entry:** *PLOTTERMANAGER*

Quick Reference

Commands

PLOTTERMANAGER

Displays the Plotter Manager, where you can add or edit a plotter configuration.

System Variables

No entries

Utilities

No entries

Command Modifiers

No entries

Use AutoSpool

With AutoSpool you can plot to an automatically generated file name in the folder you designate in the Options dialog box.

Once the file has been created, the spooler application specified in the Options dialog box is executed.

Although it is not necessary to use AutoSpool to print to Windows network printers and plotters, AutoSpool is available for users of other networks and for users who want to start another application at plot time using the AutoSpool mechanism.

When you add printers or plotters in the Add-a-Plotter wizard, select a network port, which meets most printer and plotter network connectivity requirements.

With AutoSpool, you can send a plot file to an assigned device for printing while you continue working. AutoSpool accommodates special plotting and printing requirements such as log files or nonstandard networks. You can also use most plotting routines developed for previous versions of AutoCAD.

When you run AutoSpool, AutoCAD writes the plot job to a random file name in a folder you specify. Next, AutoCAD runs a print queue submission program along with a user-specified parameter list. At a minimum, the parameter list must include the random file name AutoCAD assigned to the plot job. The parameter list is represented by the %s variable. Other parameters can be used, for example, to improve resolution at the destination device or generate log files.

To set up AutoSpool, you must provide the executable file AutoCAD invokes and specify that executable name and parameter list in the Options dialog box. The executable file is usually a batch program that you create, but it can also be a third-party program. If you use a third-party program, the setup is essentially the same. To determine the parameter variables required for the third-party program, refer to the documentation for that program.

You can use several methods for configuring plot spooling:

- A Windows system printer driver and the Print Manager to enable spooling
- An HDI driver and a Windows system printer driver configured for the same I/O port to force the HDI driver's output to the system spooler
- AutoSpool

If you configure AutoCAD for plot spooling using AutoSpool, you must configure your printer, specify the AutoSpool executable file, and specify the print file location.

Create a Batch File for AutoSpool

The following sample *plot.bat* file shows some of the functions that can be included in a batch file. This batch file determines the destination hard copy device, submits the print job through the operating system Copy command, and then deletes the temporary plot file created by AutoCAD.

This batch file requires two parameters to be passed from AutoCAD, %s and %c, which are referenced internally in the batch program as %1 and %2, respectively. The imaginary devices in this example are attached to the local workstation and two different network printer servers. See the following table

for an explanation of the device names and connections. Note that the order in which parameters are passed to the AutoSpool executable file determines how the variable is referenced in the program or batch file. For example, the first variable becomes %1 and so forth.

Device names and connections

Description	Server	Network share name	AutoCAD configuration name
Local laser printer			<i>my_laser</i>
Network-attached plotter	milana	\\milana\hp755cm	<i>hp755cm</i>
Network-attached laser printer	kilo	\\kilo\laser	<i>net_laser</i>

```

Rem PLOT.BAT
@echo off
Rem determine the destination
if %2 == my_laser goto PlotA
if %2 == hp755cm goto PlotB
if %2 == net_laser goto PlotC
Rem trap for undefined devices
echo *****Warning*****
echo %2 is not defined to the Plot Script, PLOT.BAT
echo The plot job has been canceled.
echo *****
pause
goto END
Rem send the job
:PlotA
copy %1 /b LPT1
goto END
:PlotB
copy %1 /b \\milana\hp755cm
goto END
:PlotC
copy %1 /b \\kilo\laser
goto END
Rem clean up and exit
:END
erase %1
exit

```

NOTE Device names are case-sensitive. Make sure that the name configured for the device in AutoCAD exactly matches the name in your batch program.

To use AutoSpool

- 1 Start the Add-a-Plotter wizard.
- 2 On the Ports page, select AutoSpool.
- 3 From the Tools menu, choose Options. Then choose the Files tab.
- 4 Double-click Print file, Spooler, and Prolog Section Names to display the options in this section.
- 5 Double-click Print Spool Executable.
- 6 Double-click the arrow. In the Select a File dialog box, locate the program you want to execute when the plot file has been created. Add any

command line arguments you want to use. For example, enter **myspool.bat %s**.

When AutoCAD plots to a file, it substitutes a unique plot file name for “%s” in the Print Spool Executable name and sends the generated command to DOS.

Print spool executable command line options

Option	Function
%d or %D	Specifies the AutoCAD drawing name, including the full path and -extension
%e or %E	Specifies the equal sign (=)
%h or %H	Returns the height of the plot area in the selected plotting units
%i or %I	Becomes the first letter of the plot units
%l or %L	Designates the login name; the login name is stored in the LOGINNAME system variable
%m or %M	Returns the AutoCAD plotter model; AutoCAD lists the model name during configuration
%n or %N	Becomes the plotter name; AutoCAD uses the plotter name to identify the manufacturer and type of plotter
%p or %P	Designates the plotter number; AutoCAD assigns a number to a configured plotter and lists the plotters in this order
%s or %S	Specifies the plot spool file name, including the path and extension
%u or %U	Specifies the user name entered during installation
%w or %W	Returns the width of the plotter area in the selected units

Print spool executable command line options

Option	Function
%%	Specifies the percent sign (%)
%c or %C	Specifies the description for the device (This is the description entered on the General tab of the Plotter Configuration Editor. This description should not contain spaces if you want to use it with AutoSpool.)

To specify the location for AutoSpool print files

- 1 From the Tools menu, choose Options. Choose the Files tab.
- 2 Double-click Print Support File Path.
- 3 Double-click the Print Spooler File Location.
- 4 Double-click the arrow.
- 5 In the Select a File dialog box, enter the path to the directory where you want AutoSpool to send its print files.

Quick Reference

Commands

PLOTTERMANAGER

Displays the Plotter Manager, where you can add or edit a plotter configuration.

System Variables

FULLPLOTPATH

Controls whether the full path of the drawing file is sent to the plot spooler.

Utilities

No entries

Command Modifiers

No entries

Set the Timeout Value for Devices

Some plotters support a timeout value, which specifies how much time elapses while the plotter empties its buffer before more data is sent to the plotter.

After the plotter empties its buffer, it accepts more data from AutoCAD. Enter the amount of time you want to elapse before AutoCAD prompts you to abort the plot. If your drawings are complex or your pen speed is very slow, set the timeout value higher than the default (30 seconds). If you begin to receive numerous timeout messages, your timeout setting is probably too low. For plotters that support a timeout value, you can also set the timeout value by choosing Configure Port on the Ports page during the initial configuration in the Add-a-Plotter wizard.

To set the timeout value for a local, nonsystem plotter

- 1 From the File menu, choose Plotter Manager.
- 2 Double-click the plotter configuration (PC3) file whose timeout value you want to change.
- 3 In the Plotter Configuration Editor, choose the Ports tab.
- 4 On the Ports tab, select the port that you want to use.
- 5 Choose Configure Port and do one of the following:
 - For a parallel port, in the Transmission Retry box, enter the timeout value in milliseconds.
 - For a serial port, in the Input Timeout and Output Timeout boxes, enter the timeout values in milliseconds.
- 6 Choose OK.

 **Command entry:** *PLOTTERMANAGER*

To set the timeout value for network or Windows system printers

- 1 From the Start menu, choose Settings. Then choose Printers.
- 2 Right-click the printer you want, and then choose Properties.
- 3 In the Properties dialog box, choose the Ports tab.
- 4 On the Ports tab, select the LPT port that the printer uses, and then choose Configure Port.
- 5 In the Transmission Retry box, enter the number of seconds.
- 6 Choose OK to exit each dialog box.

Quick Reference

Commands

PLOTTERMANAGER

Displays the Plotter Manager, where you can add or edit a plotter configuration.

System Variables

No entries

Utilities

No entries

Command Modifiers

No entries

Configure Serial Ports

You can adjust baud rate, protocol, flow control, and hardware handshaking for serial ports on devices that support these settings.

You should use the fastest available baud rate and the protocol recommended by your device manufacturer. See the documentation that accompanies your device.

NOTE The settings on your plotter must match the settings in AutoCAD or you will not be able to plot.

Flow Control and Handshaking

Your computer can produce a plot file faster than most plotters can process it. Plotters have a limited amount of memory and as this memory fills up, the plotter must be able to tell your computer to stop sending data temporarily. Then, when plotter memory is freed up as the plot is processed, the plotter must be able to tell the computer to resume sending the plot file. This communication is called *flow control* or *handshaking*.

There are two methods of handshaking: *hardware* and *software*. Hardware handshaking uses additional wires in the cable between the plotter and computer. These wires are dedicated to handshaking signals or *on/off voltages*. Software handshaking uses a single wire to send streams of commands that include start/stop handshaking signals. The most common type of software handshaking is XON/XOFF. You must provide different cables for hardware and software handshaking.

To adjust serial port settings

- 1 From the File menu, choose Plotter Manager.
- 2 Double-click the plotter configuration (PC3) file whose serial port settings you want to change.
- 3 In the Plotter Configuration Editor, choose the Ports tab and select the serial port that you want to use.
- 4 Choose Configure Port.
- 5 In the Settings for COM Port dialog box, select a baud rate and protocol for your device.
The protocol settings available for the current device are displayed. You cannot set an invalid protocol.
- 6 Select a Flow Control method.
The default flow control setting is XON/XOFF (software handshaking) for compatibility with previous versions of AutoCAD. If you select Hardware handshaking, you can specify additional settings by choosing Advanced.

In the Advanced Settings for COM Port dialog box, the following settings correspond to different pins on the serial port:

- **CTS.** Enables Clear to Send handshaking. This monitors pin 5 of a 25-pin serial port or pin 8 of a 9-pin serial port. CTS is an input bit, monitored for an output from the plotter or printer.
 - **DSR.** Enables Data Set Ready handshaking. This monitors pin 6 of a 25-pin serial port, or pin 6 of a 9-pin serial port. DSR is an input bit, monitored for an output from the printer or plotter.
 - **RLSD.** Enables Received Line Signal Detector handshaking. This is sometimes called Data Carrier Detect or DCD. It's an input pin that can be monitored for an output from the plotter. It's on pin 8 of a 25-pin serial port and on pin 1 of a 9-pin serial port.
 - **RTS.** Controls the Request to Send output bit. This sends a signal to the printer or plotter on pin 4 of a 25-pin serial port or on pin 7 of a 9-pin serial port.
 - Disabled.** Disables the RTS line when the device is opened.
 - Enabled.** Enables the RTS line when the device is opened.
 - Handshake.** Enables RTS handshaking. The driver raises the RTS line when the "type-ahead" (input) buffer is less than one-half full and lowers the RTS line when the buffer is more than three-quarters full.
 - Toggle.** Specifies that the RTS line will be high if bytes are available for transmission. After all buffered bytes have been sent, the RTS line will be low.
 - **DTR.** Controls the Data Terminal Ready output pin. This sends a signal to the printer or plotter on pin 20 of a 25-pin serial port or on pin 4 of a 9-pin serial port.
 - Disabled.** Disables the DTR line when the device is opened.
 - Enabled.** Enables the DTR line when the device is opened.
 - Handshake.** Enables DTR handshaking.
- 7 Choose OK to close the Advanced Settings for COM Port dialog box.
Choose OK to close the Settings for COM Port dialog box.

Quick Reference

Commands

PLOTTERMANAGER

Displays the Plotter Manager, where you can add or edit a plotter configuration.

System Variables

No entries

Utilities

No entries

Command Modifiers

No entries

Set Device-Specific Configurations

4

You can set device-specific configurations in the Autodesk Plotter Manager.

Configure Hewlett-Packard DesignJets

Hewlett-Packard DesignJet plotters are supported by a Windows system printer driver developed by Hewlett-Packard. Visit to check for the latest HP DesignJet drivers.

Plotters from other manufacturers that emulate HP DesignJets are supported through the HP-GL/2 HDI driver.

AutoCAD® supports the Hewlett-Packard DesignJet plotter models through a serial or a parallel port. Using the parallel port is recommended. If you use a serial port, set the DesignJet at 9600 baud, with 8 data bits, 1 stop bit, no parity, and hardware handshaking XON/XOFF.

All DesignJet roll-feed models can produce long-axis plots. Both the 600 and 650C have an optional expanded mode for page formats and margins. You set the Expanded mode on the plotter's front panel.

NOTE If you experience plotting problems, such as resolution degradation for lines and shaded solids, when plotting to an Hewlett-Packard DesignJet plotter, contact Hewlett-Packard for support.

Quick Reference

Commands

PLOTTERMANAGER

Displays the Plotter Manager, where you can add or edit a plotter configuration.

System Variables

No entries

Utilities

No entries

Command Modifiers

No entries

Configure Hewlett-Packard HP-GL Plotters

Hewlett-Packard HP-GL plotters are supported through an RS-232C serial I/O port.

Set the Hewlett-Packard plotters at 9600 baud with 7 data bits, 1 stop bit, and even parity.

For detailed cabling, switch setting, and other information related to using the HP-GL driver, see HP-GL Custom Properties Dialog Box.

For more information about using this driver, see the topic [HP-GL Driver Custom Properties](#) on page 114.

Hard Clip Limits

The 7580, 7585, 7586, DraftPro DXL/EXL, DraftMaster I, 7586B, and 7596A plotters return hard clip limits to AutoCAD. These limits require two-way communication between AutoCAD and the plotter. The plotter sends AutoCAD the installed paper's exact plot area so that AutoCAD can position the plot on the paper based on the actual sheet size. If you turn off the AutoCAD request for hard clip limits, AutoCAD positions the plot based on the configured paper size. In most cases, if you turn off hard clip limits, you must adjust the

configured paper size to reflect the actual printable area of the device. Otherwise, your plot may be clipped. You can adjust the location of the plot on the paper by changing the plot origin.

If your plot is sent through the Windows print spooler, the AutoCAD request for hard clip limits is turned off because of a conflict with a Windows system printer or because you're plotting to a network port. If you see a warning message, you may have to adjust your configured paper size and plot origin.

AutoCAD sends the plot to the currently configured port in the same manner that it sends the plot to a file. After the plot is sent, you can plot directly to plotter buffers or over networks.

HP-GL Long-Axis Plots

For roll-fed media, HP-GL devices limit the frame height. Frame height varies with roll width. You must perform a long-axis plot to plot more than the frame height.

AutoCAD determines whether a long-axis plot is necessary when you configure to use a long-axis paper size and when you create a long-axis plot paper size using the Add Paper Size wizard in the Plotter Configuration Editor.

The driver sends all vectors to the plotter buffer or hard disk. The pen plotters automatically advance the page to plot each frame.

Follow the instructions in the Hewlett-Packard user's guide. For long-axis, multiframe plotting, you need a black 0.3 mm fiber-tip pen (for plotter paper) or a 0.35 mm drafting pen (for vellum or polyester film) in pen stall 8. Only these pens enable the plotter to detect the registration marks used for frame-to-frame alignment.

When you create a long-axis plot with the 7586B roll-feed plotter, the Out of Limit light comes on occasionally. Generally this is a result of the interaction between AutoCAD and the plotter when plotting very large drawings.

To configure an HP-GL plotter driver

- 1** From the File menu, choose Plotter Manager.
- 2** Double-click the Add-a-Plotter Wizard shortcut icon.
- 3** On the Begin page, choose My Computer if the plotter is connected to your computer. Select Network Plotter Server if the plotter is available through a network. Choose Next.

- 4 On the Network Plotter page, enter the UNC name of the networked plotter. Choose Next. This page is not displayed if you selected My Computer in step 3.
- 5 On the Plotter Model page, under Manufacturers, select Hewlett-Packard. Under Model, select the type of Hewlett-Packard plotter that you are using or emulating. Choose Next.
- 6 On the Import PCP or PC2 page, select a PCP or PC2 file to import (optional). Choose Next.
- 7 On the Ports page, select the port that the printer is attached to. This page is not displayed if you selected Network Plotter Server in step 3. Choose Next.
- 8 On the Plotter Name page, enter a name for the plotter configuration file. Choose Next.
- 9 On the Finish page, choose Finish.
A new plotter configuration file (PC3) is created.

 **Command entry:** *PLOTTERMANAGER*

To stop the long-axis plot after all vectors have been sent

- Press Cancel on the plotter Control Panel to clear the plotter memory.

To stop the long-axis plot while vectors are being sent to the plotter

- Press ESC. Read your Hewlett-Packard manual for information about canceling the plot and clearing its memory buffer.

You must reset your plotter after canceling a plot, otherwise portions of the plot may overlay the next plot.

Quick Reference

Commands

PLOTTERMANAGER

Displays the Plotter Manager, where you can add or edit a plotter configuration.

System Variables

No entries

Utilities

No entries

Command Modifiers

No entries

Configure Hewlett-Packard HP-GL/2 Devices

The HP-GL/2 nonsystem driver supports a variety of HP-GL/2 pen plotters and ink jet plotters.

This is a generic HP-GL/2 driver; it is not optimized for a particular manufacturer's devices. This driver is intended to support obsolete pen plotters and newer devices made by manufacturers other than HP.

The DesignJet, DraftPro Plus, and the DraftMaster with roll feed can perform long-axis plots.

For more information about using this driver, see the topic [HP-GL/2 Driver Custom Properties](#) on page 120.

To configure an HP-GL/2 plotter driver

- 1 From the File menu, choose Plotter Manager.
- 2 Double-click the Add-a-Plotter Wizard shortcut icon.
- 3 On the Begin page, select My Computer if the plotter is connected to your computer. Select Network Plotter Server if the plotter is available through a network. Choose Next.
- 4 On the Network Plotter page, enter the UNC name of the networked plotter. Choose Next. This page is not displayed if you selected My Computer in step 3.
- 5 On the Plotter Model page under Manufacturers, select Hewlett-Packard. Under Model, select the type of Hewlett-Packard plotter that you are using or emulating. Choose Next.

- 6 On the Import PCP or PC2 page, select a PCP or PC2 file to import (optional). Choose Next.
- 7 On the Ports page, select the port that the printer is attached to. This page is not displayed if you selected Network Plotter Server in step 3. Choose Next.
- 8 On the Plotter Name page, enter a name for the plotter configuration file. Choose Next.
- 9 On the Finish page, choose Finish.
A new plotter configuration file (PC3) is created.

 **Command entry:** *PLOTTERMANAGER*

To perform a long plot

- 1 Plot in the normal manner. For best results, plot to extents, don't rotate the plot. Use an explicit one-to-one scale (not Scale to Fit).
- 2 To stop your plotter after AutoCAD has finished sending all the vectors, clear the plotter memory using the plotter Control Panel.
- 3 To stop a long-axis plot while AutoCAD is sending vectors to the plotter, press ESC.
- 4 Clear the plotter memory as indicated for the following devices:
 - **DraftMaster X series.** Press the Cancel button.
 - **HP 7600 240D/E.** Press the plotter Reset button.
 - **HP 7600 250/255/355.** Press the Plot Management button. Select Queuing Operations, and then select the plot and delete it from the queue.
 - **HP DesignJet Series.** Press the Cancel button.
 - **HP DraftPro Plus.** Press the Cancel button.

Quick Reference

Commands

PLOTTERMANAGER

Displays the Plotter Manager, where you can add or edit a plotter configuration.

System Variables

No entries

Utilities

No entries

Command Modifiers

No entries

Configure Xerox Devices

It is highly recommended that you use the Xerox HDI driver.

It is highly recommended that you use the Xerox HDI driver for AutoCAD. Along with improved performance, this new driver provides the same settings that now exist in the Windows system driver as well as the ability to get information from the printer in a bi-directional environment, such as roll status and what raster stamps are installed in the printer.

For more information on the latest Xerox devices and drivers, see the Xerox website.

For more information about using this driver, see the topic [Xerox Driver Custom Properties](#) on page 154.

To configure an HDI Xerox plotter driver

- 1 From the File menu, choose Plotter Manager.
- 2 Double-click the Add-a-Plotter Wizard shortcut icon.

- 3 On the Begin page, select My Computer if the plotter is connected to your computer. Select Network Plotter Server if the plotter is available through a network. Choose Next.
- 4 On the Network Plotter page, enter the UNC name of the networked plotter. Choose Next. This page is not displayed if you selected My Computer in step 3.
- 5 On the Plotter Model page under Manufacturers, select Xerox Engineering Systems. Under Model, select the type of Xerox plotter that you are using. Choose Next.
- 6 On the Import PCP or PC2 page, select a PCP or PC2 file to import (optional). Choose Next.
- 7 On the Ports page, select the port that the printer is attached to. This page is not displayed if you selected Network Plotter Server in step 3. Choose Next.
- 8 On the Plotter Name page, enter a name for the plotter configuration file. Choose Next.
- 9 On the Finish page, choose Finish.
A new plotter configuration file (PC3) is created.

 **Command entry:** *PLOTTERMANAGER*

Quick Reference

Commands

PLOTTERMANAGER

Displays the Plotter Manager, where you can add or edit a plotter configuration.

System Variables

No entries

Utilities

No entries

Command Modifiers

No entries

Configure CalComp Plotters

If you are using a CalComp plotter, you can use the Windows system printer.

For more information about using this driver, see the topic [CalComp Driver Custom Properties](#) on page 140.

Quick Reference

Commands

PLOTTERMANAGER

Displays the Plotter Manager, where you can add or edit a plotter configuration.

System Variables

No entries

Utilities

No entries

Command Modifiers

No entries

Configure Houston Instruments Plotters

If you are using a newer Houston Instruments plotter, use the generic HP-GL or HP-GL/2 HDI drivers and configure your plotter in HP-GL or HP-GL/2 emulation mode.

Quick Reference**Commands**

PLOTTERMANAGER

Displays the Plotter Manager, where you can add or edit a plotter configuration.

System Variables

No entries

Utilities

No entries

Command Modifiers

No entries

Use the Autodesk HDI System Printer Driver

With the HDI system printer driver, you can use the plotter or printer you have configured with Windows.

You can use any printing device supported by Windows (Windows system printer).

You can use the HDI system printer driver to choose printer defaults for AutoCAD that differ from the defaults for other Windows applications.

The Autodesk system printer driver supports raster output. However, the amount of memory in the printing device limits the ability of the device connected as the system printer to output raster and vector data sent by AutoCAD.

If you have multiple Windows system printers, you can select the device used to plot from AutoCAD. For example, you might use a LaserJet printer for word processing documents and a BubbleJet for AutoCAD drawings.

For best results, use the Windows system printer and AutoCAD plotter drivers as follows:

- Use the Autodesk HDI driver appropriate to your printer/plotter in preference to the Windows system printer, unless you have an Océ TDS/TCS printer or a Hewlett-Packard DesignJet plotter. Océ and HP have supplied system printer drivers optimized for AutoCAD use.
- Use the Windows system printer for output devices without pens, such as laser printers.

Setting up the Windows system printer for AutoCAD consists of two parts:

- Configuring the system printer in Windows (see the Microsoft documentation for your operating system)
- Configuring the system printer as the AutoCAD plotter using the Add-a-Plotter Wizard shortcut icon

To create a plotter configuration for the system printer

- 1 From the File menu, choose Plotter Manager.
- 2 Double-click the Add-a-Plotter Wizard shortcut icon.
- 3 On the Begin page, select System Printer. Choose Next.
- 4 On the System Printer page, select the system printer for which you want to create a plotter configuration file. Choose Next.
- 5 On the Import PCP or PC2 page, choose Import File and select a PCP or PC2 file to import (optional). Choose Import. Then choose Next.
- 6 On the Plotter Name page, enter a name for the plotter configuration file. Choose Next.
- 7 On the Finish page, choose Finish.
A new plotter configuration file (PC3) is created.

 **Command entry:** *PLOTTERMANAGER*

Quick Reference

Commands

PLOTTERMANAGER

Displays the Plotter Manager, where you can add or edit a plotter configuration.

System Variables

No entries

Utilities

No entries

Command Modifiers

No entries

Configure for File Output

5

Configure for File Output

You can configure drivers for different file types including, Adobe PostScript and raster file formats.

AutoCAD® provides plotter drivers to create the following types of files:

- Autodesk ePlot (DWF)
- Adobe PDF
- Adobe PostScript
- DXB file format
- Raster file formats

Configure ePlot to Create DWF Files

With ePlot, you can generate electronic drawing files that are optimized for either plotting or viewing. The files you create are stored in Design Web Format (DWF). DWF files can be opened, viewed, and plotted by anyone using the DWF file viewer. With the DWF file viewer, you can also view DWF files in Microsoft® Internet Explorer 5.01 or later. DWF files support real-time panning and zooming and the display of layers and named views.

Configure the Adobe PDF Driver

If you configure a PDF driver in the Add-a-Plotter wizard, you can output your drawings in Portable Document Format (PDF). To configure the PDF driver, in

the Add-a-Plotter wizard, select Autodesk ePlot (PDF) from the Manufacturers list, and select PDF from the Models list.

Configure the Adobe PostScript Driver

If you configure a PostScript driver in the Add-a-Plotter wizard, you can output your drawings in PostScript format. To configure the PostScript driver, in the Add-a-Plotter wizard, select Adobe from the Manufacturer list, and select a PostScript level from the Model list.

AutoCAD supports three levels of PostScript. Level 1 works with most devices but does not support color images and produces larger plot files than the newer PostScript levels. Level 1 Plus is for Level 1 devices that also support color images. Level 2 is for newer printers and produces smaller files and faster output on Level 2 devices.

AutoCAD supports PostScript printers and plotters using a Centronics-type parallel I/O port, an RS-232C serial I/O port, or plotting across a network. If you use a serial port, configure the printer to match the settings you select in the Configure Port dialog box in the Add-a-Plotter wizard, Ports page.

Configure DXB File Formats

DXB (drawing interchange binary) file formats are supported using the AutoCAD DXB nonsystem file driver.

The output is compatible with the DXBIN command and with the ADI DXB driver delivered with earlier releases. The DXB driver shares the following limitations of the ADI driver:

- The driver produces 16 bit integer DXB files containing only vectors.
- DXB output is monochrome; all vectors are color 7.
- Raster images and embedded OLE objects are not supported.
- The driver ignores object and plot style lineweights.

Configure Raster File Formats

AutoCAD can view drawings that contain raster images such as TIFF or JPEG.

With the raster file format driver, AutoCAD can also export raster files in the formats listed in the Add-a-Plotter wizard. To configure a raster format driver, select Raster File Formats from the Manufacturer list.

See also:

- “Plot Files to Other Formats” in the User's Guide

To configure a plotter driver for DWF file output

- 1 From the File menu, choose Plotter Manager.
- 2 Double-click the Add-a-Plotter Wizard shortcut icon.
- 3 On the Begin page, select My Computer. Choose Next.
- 4 On the Plotter Model page, under Manufacturers, select Autodesk ePlot (DWF). Under Model, select the type of DWF that you want to create. Choose Next.
- 5 On the Import PCP or PC2 page, choose Import File and select a PCP or PC2 file to import (optional). Choose Import. Then choose Next.
- 6 On the Ports page, select Plot to File. Choose Next.
- 7 On the Plotter Name page, enter a name for the plotter configuration file. Choose Next.
- 8 On the Finish page, choose Finish.
A new plotter configuration file (PC3) is created.

 **Command entry:** *PLOTTERMANAGER*

To configure a plotter driver for PDF file output

- 1 From the File menu, choose Plotter Manager.
- 2 Double-click the Add-a-Plotter Wizard shortcut icon.
- 3 On the Begin page, select My Computer. Choose Next.
- 4 On the Plotter Model page, under Manufacturers, select Autodesk ePlot (PDF).
- 5 On the Import PCP or PC2 page, choose Import File and select a PCP or PC2 file to import (optional). Choose Import. Then choose Next.
- 6 On the Ports page, select Plot to File. Choose Next.
- 7 On the Plotter Name page, enter a name for the plotter configuration file. Choose Next.
- 8 On the Finish page, choose Finish.

A new plotter configuration file (PC3) is created.

 **Command entry:** *PLOTTERMANAGER*

To configure a plotter driver for PostScript file output

- 1 From the File menu, choose Plotter Manager.
- 2 Double-click the Add-a-Plotter Wizard shortcut icon.
- 3 On the Begin page, select My Computer. Choose Next.
- 4 On the Plotter Model page under Manufacturers, select Adobe. Under Model, select the level of PostScript file that you want to create. Choose Next.
- 5 On the Import PCP or PC2 page, choose Import File and select a PCP or PC2 file to import (optional). Choose Import. Then choose Next.
- 6 On the Ports page, select Plot to File. Choose Next.
- 7 On the Plotter Name page, enter a name for the plotter configuration file. Choose Next.
- 8 On the Finish page, choose Finish.
A new plotter configuration file (PC3) is created.

 **Command entry:** *PLOTTERMANAGER*

To configure a plotter driver for DXB file output

- 1 From the File menu, choose Plotter Manager.
- 2 Double-click the Add-a-Plotter Wizard shortcut icon.
- 3 On the Begin page, select My Computer. Choose Next.
- 4 On the Plotter Model page, under Manufacturers, select AutoCAD DXB File. Under Model, select DXB File. Choose Next.
- 5 On the Import PCP or PC2 page, choose Import File and select a PCP or PC2 file to import (optional). Choose Import. Then choose Next.
- 6 On the Ports page, select Plot to File. Choose Next.
- 7 On the Plotter Name page, enter a name for the plotter configuration file. Choose Next.
- 8 On the Finish page, choose Finish.

A new plotter configuration file (PC3) is created.

 **Command entry:** *PLOTTERMANAGER*

To configure a plotter driver for raster file output

- 1 From the File menu, choose Plotter Manager.
- 2 Double-click the Add-a-Plotter Wizard shortcut icon.
- 3 On the Begin page, select My Computer. Choose Next.
- 4 On the Plotter Model page under Manufacturers, select Raster File Formats. Under Model, select the type of raster file that you want to create. Choose Next.
- 5 On the Import PCP or PC2 page, choose Import File and select a PCP or PC2 file to import (optional). Choose Import. Then choose Next.
- 6 On the Ports page, select Plot to File. Choose Next.
- 7 On the Plotter Name page, enter a name for the plotter configuration file. Choose Next.
- 8 On the Finish page, choose Finish.
A new plotter configuration file (PC3) is created.

 **Command entry:** *PLOTTERMANAGER*

To view the custom properties Help

- 1 From the File menu, choose Plotter Manager.
- 2 In the Autodesk Plotter Manager, double-click to open the PC3 file whose custom properties help you want to view.
- 3 Choose the Device and Document Settings tab.
- 4 Select the Custom Properties node.
- 5 Choose Custom Properties.
- 6 In the Custom Properties dialog box for the configured device, choose Help.
Help provides specific configuration information.

 **Command entry:** *PLOTTERMANAGER*

Quick Reference

Commands

PLOTTERMANAGER

Displays the Plotter Manager, where you can add or edit a plotter configuration.

System Variables

No entries

Utilities

No entries

Command Modifiers

No entries

Configure External Databases

6

Configure External Databases

Before you can access external databases from AutoCAD®, you must configure them using the Microsoft® external ODBC and OLE DB programs.

NOTE The 64-bit release of AutoCAD does not support the use of Microsoft Jet 4.0 OLE DB Provider (for MDB connectivity) and Microsoft OLE DB Provider for ODBC Drivers (for XLS connectivity). For more information, see Substituting the use of SQL Server instead of OLE DB with DbConnect.

Once you have configured your databases, you can access their data from AutoCAD, even if you don't have the database system that created the data installed on your system. AutoCAD can access data from the following applications:

- Microsoft Access
- dBase
- Microsoft Excel
- Oracle
- Paradox
- Microsoft Visual FoxPro®
- SQL Server

NOTE With MDAC versions 2.1 and higher, you can't edit dBase files unless you have a Borland DataBase Engine (BDE) installed on your computer.

Once you have successfully configured a database to use with AutoCAD, a configuration file with the extension UDL is created. This configuration file contains the information AutoCAD needs to access the configured database. By default, UDL files are stored in the *Data Links* folder of AutoCAD. You can specify a different location for UDL files from the Options dialog box.

The following topics demonstrate how to set up a data source using ODBC, and how to configure data sources so that you can use them with AutoCAD. For detailed information about ODBC and OLE DB, refer to the following online Microsoft resources:

- OLE DB Help
- ODBC Help
- ODBC Microsoft Desktop Database Drivers

Bypass ODBC Using an OLE DB Direct Driver

Several database management systems supported by AutoCAD have direct drivers available for OLE DB. If you use these direct drivers, you don't need to set up configuration files from within both ODBC and OLE DB; you only need a single OLE DB configuration file.

Direct database drivers are available for the following database systems:

- Microsoft Access
- Oracle
- Microsoft SQL Server

Use ODBC to Create a Configuration File

ODBC is an intermediary program that makes data from one application available to other applications.

Configure a Data Source with OLE DB

You can use OLE DB to establish a UDL configuration file that points to an external database table.

Substituting SQL Server for OLE DB

If you are using the 64-bit release of AutoCAD and DbConnect with a connection that accesses a Microsoft Access database or a Microsoft Excel spreadsheet using one of the two following methods, you need to change your connections to use Microsoft SQL Server. Microsoft does not supporting a 64-bit version of these technologies.

- Microsoft Jet 4.0 OLE DB Provider (for MDB connectivity)
- Microsoft OLE DB Provider for ODBC Drivers (for XLS connectivity)

Microsoft SQL Server comes in three different editions. If you are accessing data from an MDB or XLS file today, you might find that using Microsoft SQL Server Express Edition is adequate for your needs. Microsoft also offers Standard and Enterprise editions of SQL Server. For additional information about SQL Server, visit Microsoft's website at <http://www.microsoft.com/sql>.

NOTE You can purchase inexpensive third-party utilities to help automate the conversion of data stored in a MDB to a MDF file that can be used with SQL Server. Many of these utilities also allow you to export data from a MDF to a MDB file.

To specify a new location for UDL files

- 1 Click Tools menu ► Options.
- 2 In the Options dialog box, Files tab, select Data Source Location, and then click Browse.
- 3 In the Browse for Folder dialog box, locate and select the folder you want. Click OK.
- 4 Click OK.

 **Command entry:** *OPTIONS*

To set up a direct Microsoft Access configuration using OLE DB

- 1 Click dbConnect menu ► Data Sources ► Configure.
- 2 At the Configure a Data Source prompt, select from the possible data sources you would like to use.
- 3 In the Data Link Properties dialog box, the Provider tab, select Microsoft Jet 4.0 OLE DB Provider. Click Next.

- 4 In Select or Enter a Database Name, enter the name and path to the database you want to configure.
- 5 Click Test Connection to verify that your configuration is working properly.
If the connection fails, verify that the settings are correct. For example, spelling errors and case sensitivity may be the cause of a failed connection.
- 6 In the Microsoft Data Link dialog box, click OK.
- 7 Click OK.

 **Command entry:** *DBCONNECT*

To set up a direct Oracle configuration using OLE DB

- 1 Click dbConnect menu ► Data Sources ► Configure.
- 2 In the Data Link Properties dialog box, the Provider tab, select Microsoft OLE DB Provider for Oracle. Click Next.
- 3 Enter the Oracle server name in Enter a Server Name.
- 4 Enter a valid user name and password.
- 5 Click Test Connection to verify that the settings are correct. For example, spelling errors and case sensitivity may be the cause of a failed connection.
- 6 In the Microsoft Data Link dialog box, click OK.
- 7 Click OK.

 **Command entry:** *DBCONNECT*

To set up a direct SQL Server configuration using OLE DB

- 1 Click dbConnect menu ► Data Sources ► Configure.
- 2 In the Data Link Properties dialog box, the Provider tab, select Microsoft OLE DB Provider for SQL Server. Click Next.
- 3 Enter the server name in Select or Enter a Server Name.
- 4 Enter a valid user name and password.
- 5 Select the database to configure in Select the Database on the Server.
- 6 Click Test Connection to verify that the settings are correct. For example, spelling errors and case sensitivity may be the cause of a failed connection.

- 7 In the Microsoft Data Link dialog box, click OK.
- 8 Click OK.

 **Command entry:** *DBCONNECT*

To set up a Microsoft Access data source using ODBC

- 1 Click Start menu (Windows) ► Settings ► Control Panel.
- 2 Double-click the ODBC icon.
- 3 In the ODBC Data Source Administrator dialog box, do one of the following:
 - Choose the User DSN tab to create a data source that is visible only to you and can be used only on the computer you create it in.
 - Choose the System DSN tab to create a data source that is visible to all users who have access rights to the computer.
 - Choose the File DSN tab to create a data source that can be shared with other users who have the same ODBC drivers installed on their systems.
- 4 Click Add.
- 5 Select the Microsoft Access Driver, and then click Finish.
- 6 Enter a name for your data source in Data Source Name.
- 7 Click Select, and then locate and select the database that you want to configure. Click OK.
- 8 In the ODBC Microsoft Access dialog box, click OK.
- 9 In the ODBC Data Source Administrator dialog box, click OK.

To set up a dBase data source using ODBC

- 1 Click Start menu (Windows) ► Settings ► Control Panel.
- 2 Double-click the ODBC icon.
- 3 In the ODBC Data Source Administrator dialog box, do one of the following:
 - Choose the User DSN tab to create a data source that is visible only to you and can be used only on the computer you create it in.

- Choose the System DSN tab to create a data source that is visible to all users who have access rights to the computer.
 - Choose the File DSN tab to create a data source that can be shared with other users who have the same ODBC drivers installed on their systems.
- 4 Click Add.
 - 5 Select the Microsoft dBase Driver, and then click Finish.
 - 6 Enter a name for your data source in Data Source Name, and select the appropriate version of dBase from the Version list.
 - 7 Make sure that Use Current Directory is cleared.
 - 8 Click Select Directory, and then locate and select the directory that contains the database tables you want to configure. Click OK.
 - 9 In the ODBC dBase Setup dialog box, click OK.
 - 10 In the ODBC Data Source Administrator dialog box, click OK.

To set up a Microsoft Excel spreadsheet to use with AutoCAD

- 1 In Microsoft Excel, open the workbook or spreadsheet that you want to access from AutoCAD.
- 2 Select a range of cells to function as a database table.
- 3 Enter a name for the range of cells in the Name Box, then press ENTER.
- 4 Repeat steps 2 and 3, if desired, to specify additional database tables.
- 5 Click File menu ► Save.

NOTE Microsoft Excel is not a true database management system. In order to access Excel data from within AutoCAD, you must first specify at least one named range of Excel cells to function as a database table. Each named range of cells that you specify within a spreadsheet is treated as an individual table by AutoCAD.

To set up a Microsoft Excel data source using ODBC

- 1 Click Start menu (Windows) ► Settings ► Control Panel.
- 2 Double-click the ODBC icon.

- 3 In the ODBC Data Source Administrator dialog box, do one of the following:
 - Choose the User DSN tab to create a data source that is visible only to you and can be used only on the computer you create it in.
 - Choose the System DSN tab to create a data source that is visible to all users who have access rights to the computer.
 - Choose the File DSN tab to create a data source that can be shared with other users who have the same ODBC drivers installed on their systems.
- 4 Click Add.
- 5 Select the Microsoft Excel Driver, and then click Finish.
- 6 Enter a name for your data source in Data Source Name, and select the appropriate version of Excel from the Version list.
- 7 Make sure that Use Current Directory is cleared.
- 8 Click Select Workbook, and then locate and select the workbook or spreadsheet you want to configure. Click OK.
- 9 In the ODBC Microsoft Excel dialog box, click OK.
- 10 In the ODBC Data Source Administrator dialog box, click OK.

To set up an Oracle data source using ODBC

- 1 Click Start menu (Windows) ► Settings ► Control Panel.
- 2 Double-click the ODBC icon.
- 3 In the ODBC Data Source Administrator dialog box, do one of the following:
 - Choose the User DSN tab to create a data source that is visible only to you and can be used only on the computer you create it in.
 - Choose the System DSN tab to create a data source that is visible to all users who have access rights to the computer.
 - Choose the File DSN tab to create a data source that can be shared with other users who have the same ODBC drivers installed on their systems.
- 4 Click Add.

- 5 Select Microsoft ODBC for Oracle, and then click Finish.
- 6 Enter a name for your data source in Data Source Name.
- 7 Enter your user name.
- 8 Enter the name of the Oracle Server in Server.
- 9 Click OK.
- 10 In the ODBC Data Source Administrator dialog box, click OK.

To set up a Paradox data source using ODBC

- 1 Click Start menu (Windows) ► Settings ► Control Panel.
- 2 Double-click the ODBC icon.
- 3 In the ODBC Data Source Administrator dialog box, do one of the following:
 - Choose the User DSN tab to create a data source that is visible only to you and can be used only on the computer you create it in.
 - Choose the System DSN tab to create a data source that is visible to all users who have access rights to the computer.
 - Choose the File DSN tab to create a data source that can be shared with other users who have the same ODBC drivers installed on their systems.
- 4 Click Add.
- 5 Select the Paradox Driver, and then click Finish.
- 6 Enter a name for your data source in Data Source Name, and select the appropriate version of Paradox from the Version list.
- 7 Make sure that User Current Directory is cleared.
- 8 Click Select Directory, and then locate and select the database you want to configure. Click OK.
- 9 In the ODBC Paradox Setup dialog box, click OK.
- 10 In the ODBC Data Source Administrator dialog box, click OK.

To set up a Microsoft Visual FoxPro data source using ODBC

- 1 Click Start menu (Windows) ► Settings ► Control Panel.

- 2 Double-click the ODBC icon.
- 3 In the ODBC Data Source Administrator dialog box, do one of the following:
 - Choose the User DSN tab to create a data source that is visible only to you and can be used only on the computer you create it in.
 - Choose the System DSN tab to create a data source that is visible to all users who have access rights to the computer.
 - Choose the File DSN tab to create a data source that can be shared with other users who have the same ODBC drivers installed on their systems.
- 4 Click Add.
- 5 Select the Microsoft Visual FoxPro Driver, and then click Finish.
- 6 Enter a name for your data source in Data Source Name, and select a type in Database Type.
- 7 Click Browse, and then locate and select the database you want to configure. Click Open.
- 8 In the ODBC Visual FoxPro Setup dialog box, click OK.
- 9 In the ODBC Data Source Administrator dialog box, click OK.
For additional information about setting up a Microsoft Visual FoxPro data source, see the Microsoft Visual FoxPro ODBC Driver documentation.

To set up an SQL Server data source using ODBC

- 1 Click Start menu (Windows) ► Settings ► Control Panel.
- 2 Double-click the ODBC icon.
- 3 In the ODBC Data Source Administrator dialog box, do one of the following:
 - Choose the User DSN tab to create a data source that is visible only to you and can be used only on the computer you create it in.
 - Choose the System DSN tab to create a data source that is visible to all users who have access rights to the computer.
 - Choose the File DSN tab to create a data source that can be shared with other users who have the same ODBC drivers installed on their systems.

- 4 Click Add.
- 5 Select SQL Server, and then click Finish.
- 6 Follow the instructions in the wizard to complete the data source setup. Microsoft provides additional Help topics describing the interface components of each page in the wizard. To view Help for a wizard page, click Help.
- 7 In the ODBC Data Source Administrator dialog box, click OK.

To configure a data source using OLE DB

You can use OLE DB to establish a UDL configuration file that points to an external database table.

- 1 Use Microsoft ODBC to set up a data source (see [Use ODBC to Create a Configuration File](#) on page 70).
- 2 Click dbConnect menu ► Data Sources ► Configure.
- 3 In the Data Link Properties dialog box, the Provider tab, select Microsoft OLE DB Provider for ODBC Drivers. Choose Next.
- 4 Enter the name of the data source you want to configure in Use Data Source Name.
- 5 Click Test Connection to verify that your configuration is working properly.
If the connection fails, verify that the settings are correct. For example, spelling errors and case sensitivity may be the cause of a failed connection.
- 6 In the Microsoft Data Link dialog box, click OK.
- 7 Click OK.

 **Command entry:** *DBCONNECT*

Quick Reference

Commands

DBCONNECT

Provides an interface to external database tables.

OPTIONS

Customizes the program settings.

System Variables

No entries

Utilities

No entries

Command Modifiers

No entries

Driver Custom Properties Reference

7

You can change the custom properties of the plotter driver assigned to a plotter configuration.

Autodesk-Supplied Plotter Drivers

Plotter drivers that are created by Autodesk for use with AutoCAD.

DWF Driver Custom Properties

Specifies custom properties for plotted Design Web Format (DWF) files.

Overview of the DWF Driver Custom Properties

You can use the DWF6 ePlot driver to plot or publish DWF files. You can open, view, and print DWF files with a DWF file viewer. DWF files support real-time panning and zooming as well as control over the display of layers and named views.

NOTE By default, AutoCAD plots are plotted with lineweights. If you haven't specified lineweight values in the Layer Properties Manager, a default lineweight of .01 inches is applied to all graphical objects when you plot a drawing. This can cause areas of your plotted DWF files to look significantly different from how they appear in the AutoCAD drawing area when viewed in an external viewer or Internet browser, particularly during zoom operations. To avoid this, clear the Plot with Lineweights option from the Plot Settings tab in the Plot dialog box.

NOTE All references to AutoCAD, unless otherwise noted, refer to all AutoCAD-based products.

Vector and Gradient Resolution (DWF)

Specifies the resolution (in dots per inch) for vector graphics and gradients for DWF files. When you set a higher resolution, the file is more precise, but the file size is also larger.

When you create DWF files intended for plotting, select a resolution to match the output of your plotter or printer. High resolutions (over 2,400 dpi) are for viewing. For example, when you create DWF files of drawings that contain a lot of detail, such as a topographical map of a large region, these files use a higher resolution setting for greater detail in the DWF file. Use extreme resolutions (over 40,000 dpi) only when necessary; they may produce very large files. As you increase the resolution setting, raster image quality increases, the speed of printing decreases, and memory requirements increase.

Vector Resolution

Sets the resolution for vector graphics in the DWF file in dots per inch. The default setting is 1,200 dpi. Select Custom to enter a custom vector graphic resolution.

Custom Vector Resolution

Specifies a custom resolution for vector graphics in the DWF file in dots per inch. You must select Custom under Vector Resolution to specify a custom vector graphic resolution. The default setting is 40,000 dpi.

Gradient Resolution

Sets the resolution for gradients in the DWF file in dots per inch. The default setting is 200 dpi. Select Custom to enter a custom gradient resolution. This setting cannot exceed the current vector resolution setting.

Custom Gradient Resolution

Specifies a custom resolution for gradients in the DWF file in dots per inch. You must select Custom under Gradient Resolution to specify a custom gradient resolution. The default setting is 200 dpi. This setting cannot exceed the current vector resolution setting.

Raster Image Resolution (DWF)

Specifies the resolution (in dots per inch) for raster images for DWF files. When you set a higher resolution, the file is more precise, but the file size is also larger.

When you create DWF files intended for plotting, select a resolution to match the output of your plotter or printer. High resolutions (over 2,400 dpi) are for viewing. For example, when you create DWF files of drawings that contain a lot of detail, such as a topographical map of a large region, these files use a higher resolution setting for greater detail in the DWF file. Use extreme resolutions (over 40,000 dpi) only when necessary; they may produce very large files. As you increase the resolution setting, raster image quality increases, the speed of printing decreases, and memory requirements increase.

Color and Grayscale Resolution

Sets the resolution for raster image colors and grayscale in the DWF file in dots per inch. The default setting is 200 dpi. Select Custom to enter a custom color and grayscale resolution. This setting cannot exceed the current vector resolution setting.

Custom Color Resolution

Specifies a custom resolution for color raster images in the DWF file in dots per inch. You must select Custom under Color and Grayscale Resolution to specify a custom color resolution. This setting cannot exceed the current vector resolution setting.

Black and White Resolution

Sets the resolution for black and white raster images in the DWF file in dots per inch. The default setting is 400 dpi. Select Custom to enter a custom black and white resolution. This setting cannot exceed the current vector resolution setting.

Custom Black and White Resolution

Specifies a custom resolution for black and white raster images for the DWF file in dots per inch. You must select Custom under Black and White Resolution to specify a custom black and white resolution. This setting cannot exceed the current vector resolution setting.

Font Handling (DWF)

Specifies the inclusion and handling of fonts in DWF files.

NOTE The size of a DWF file can be affected by the font-handling settings, the amount of text, and the number and type of fonts used in the file. If the size of your DWF file seems too large, try changing the font-handling settings.

Capture None (All Viewer Supplied)

Specifies that no fonts will be included in the DWF file.

In order for the fonts used in the source drawing for the DWF file to be visible in the DWF file, the fonts must be present on the DWF viewer's system. If the fonts used to create the DWF file are not present on the viewer's system, other fonts will be substituted.

Capture Some (Recommended)

Specifies that fonts used in the source drawing for the DWF file that are selected in the Available True Type Fonts dialog box will be included in the DWF file.

The selected fonts do not need to be available on the DWF viewer's system in order for them to appear in the DWF file.

Edit Font List Opens the Available True Type Fonts dialog box, where you can edit the list of fonts eligible for capture in the DWF file.

By default, fonts installed with AutoCAD, Windows, and the DWF file viewer are not selected.

Selecting Restore Defaults resets the list to the default setting. This action is completed and saved before you click OK and cannot be undone.

The settings in the Available True Type Fonts dialog box are saved in the registry, not in the current PC3 file. These settings remain in effect for all DWF files until they are changed.

Capture All

Specifies that all fonts used in the drawing will be included in the DWF file.

NOTE This may increase the size of the DWF file.

As Geometry (Largest File Size) Specifies that all fonts used in the drawing will be included as geometry in the DWF file. If you select this option, you

should plot your drawing at a scale factor of 1:1 or better to ensure good quality in the output file.

This option is only available for DWF files created with the DWF6 ePlot model.

NOTE This may increase the size of the DWF file.

Additional Output Settings (DWF)

Specifies additional output settings for DWF files.

DWF Format

Specifies the compression format for DWF files.

Compressed Binary (Recommended) Plots the DWF file in a compressed, binary format; compression does not cause data loss. This is the recommended file format for most DWF files.

Zipped ASCII encoded 2D stream (Advanced) Plots the DWF file in zipped ASCII Encoded 2D Stream (plain text) format. You can use WinZip to unzip the files.

Background Color Shown in Viewer

Controls the background color that is applied to DWF files.

NOTE DWF files intended for plotting should be configured with a white background color. If the AutoCAD background color is set to black, color 7 objects will be plotted as white. For all other background colors, color 7 objects will be plotted as black.

Include Layer Information

Specifies the inclusion of layer information in plotted DWF files. If this option is selected, any layers that are turned on and thawed when the plot is created are available for manipulation in the plotted DWF file. If this option is cleared, no layer information is available when the DWF is viewed in an external viewer or browser.

In some cases, such as in drawings that include nested xrefs, turning this option off may significantly improve performance.

Show Paper Boundaries

Specifies the inclusion of a paper boundary in plotted DWF files similar to what is displayed with drawings in a layout tab.

NOTE For DWF6 ePlot, the Show Paper Boundaries option is checked by default and is unavailable for editing.

Save Preview In DWF

Specifies that a preview of the DWF file will be saved in the DWF file.

NOTE A small thumbnail of the DWF file is always saved. You should only use the Save Preview in DWF setting if the recipient will use *Buzzsaw.com* to access the preview.

Virtual Pen Set (DWF)

Opens the Edit Pen Set dialog box, where you can edit the ePlot (optimized for plotting) plotter configuration (PC3) file pen set and patterns.

You must have 255 Virtual Pens selected in the Plotter Configuration Editor, Vector Graphics node, Color Depth area to use this option. When 255 Virtual Pens is selected, the settings in the plot style table associated with the drawing are ignored except the virtual pen number and plot style linetype. You can edit the settings for these virtual pens in the Edit Pen Set dialog box. These settings are then saved to the PC3 file that you are editing.

NOTE When you have 255 Virtual Pens selected as your color depth, changing the resolution of the DWF file will change the width of your lines. Adjust the line width values in your pen set to compensate for this.

In the Edit Pen Set dialog box, you can make changes to the current pen set, which are saved to the PC3 file when you click OK. Selecting Defaults resets the pen set to the default settings. By selecting Import, you can import a pen set from a PEN file.

NOTE If you want to use pen sets from Buzzsaw, use the *Buzzsaw DWF.ctb* plot style table. However, when you want to edit your pen set, edit the pen set stored in the DWF PC3 file, not the *Buzzsaw DWF.ctb* plot style table.

In the Edit Pen Set dialog box, you can change pen weights (width), patterns, shapes, and effects by right-clicking a field in the dialog box to display a menu

of common settings. From the menu, you can copy settings to other pens or select Properties to display the Pen Properties dialog box.

Unchecked pens (indicated by a red strike-through line) in the Edit Pen Set dialog box will be ignored when you apply settings to the entire pen set.

Patterns

Provides 107 predefined pen patterns. Pen patterns can be used to alter the appearance of the geometry of a drawing. Many of the patterns provide a grayscale equivalent of a color. These patterns are commonly used for area fills in drawings for different percentages of black. There are also miscellaneous patterns such as boxes, tiles, slants, and diamonds that can be used to provide different effects.

Width

Sets the line width of the pen. Line widths are measured in pixels. These widths can also be represented in millimeters, centimeters, and inches. You set line widths in pixels (from 0 to 400). When you change the type of units, equivalent measurements in millimeters, centimeters, or inches for a 400 dpi printer are displayed.

Shape

Sets the end shape and join style of the pen.

Effect

Controls the appearance of the background pixels in a pattern. This effect works on monochrome, grayscale, and color plotters.

Transparent Allows underlying objects to be visible through the pattern.

Opaque Prevents underlying objects from appearing through the pattern.

All Pens

Applies scaling and width limitations to all pens in the pen set.

NOTE The Scale Pen Widths settings are only visible when using viewing and plotting tools from Buzzsaw.

Controls

The effects of these settings are only visible when using viewing and plotting tools from Buzzsaw.

Allow Drawing to Manipulate These settings are not supported for DWF files.

Map Pen Colors to a Shaded Half-Tone Specifies that pen colors will be converted to the equivalent shades of gray.

Use Alternate Fill Instead of Winding Fill for Polygons Specifies that an alternate fill will be used for polygons instead of a winding fill.

Use only if the fill pattern in a polygon does not appear to print correctly for a vector file. The modes differ only in cases where a complex, overlapping polygon must be filled (for example, a five-sided polygon that forms a five-pointed star with a pentagon in the center). In such cases, alternate mode fills every other enclosed region within the polygon (such as the points of the star). Winding mode fills all regions (such as the points and the pentagon).

Use Error Diffusion for DWF Rasters Specifies that error diffusion will be used for DWF raster images.

To represent shades of gray in raster data, halftone diffusion is used by default. You may want to use error diffusion instead to improve the appearance of your image.

Configure a DWF6 Driver (Advanced)

You are not likely to change the settings in the DWF6 ePlot Properties dialog box often. However, when you need to make some subtle changes to your DWF6 ePlot configuration, you can do so through the DWF6 ePlot Properties dialog box. You can specify settings for color depth, display resolution, file compression, handling of fonts, pen settings, and other options. When you create DWF6 files, you use a plotter configuration file that uses a DWF6 driver model. You must use the *DWF6 ePlot.pc3* file to plot DWF6 files.

Overview of Creating or Modifying a DWF6 Configuration File

The *DWF6 ePlot.pc3* plotter configuration file is the default driver for the PUBLISH command. You can use the *DWF6 ePlot.pc3* plotter configuration file

as installed, or you can modify it using the Properties button in the Plot dialog box. This invokes the pc3 editor, where you can make changes directly to the *DWF6 ePlot.pc3* file. Although you can save *DWF6 ePlot.pc3* files under other names to use with the Plot command, no other name works with the PUBLISH command. Any changes you make to the *DWF6 ePlot.pc3* file are used whenever you plot or publish DWF6 files until you change the settings of your *DWF6 ePlot.pc3* file again.


NOTE If you are going to make changes to the *DWF6 ePlot.pc3* file, make a backup copy of the file first in case you want to use the default settings later. If necessary, the default *DWF6 ePlot.pc3* file can be re-created with the Add-A-Plotter wizard.

These settings may change file size and plot quality, depending on the content of the source drawing for the Design Web Format™ (DWF™) file. You can specify the following settings when you edit the *DWF6 ePlot.pc3* configuration file:

- Color depth
- Display resolution
- Compression options
- Inclusion and handling of fonts
- Background color
- Virtual pen settings and patterns
- Inclusion of layer information
- Inclusion of a paper boundary
- Inclusion of a saved preview

NOTE DWF files intended for plotting should be configured with a white background color. If the background color is set to black, color 7 objects are plotted as white. For all other background colors, color 7 objects are plotted as black.


To create a plotter configuration file for DWF file output

- 1 Click Output tab ► Plot panel ► Plotter Manager. 
- 2 Double-click the Add-A-Plotter wizard.



- 3 On the Add Plotter-Introduction page, click Next.
- 4 On the Add Plotter-Begin page, select My Computer. Click Next.
- 5 On the Plotter Model page, under Manufacturers, select Autodesk ePlot (DWF). Under Models, select the DWF6 ePlot file that you want to create. Click Next.
- 6 (Optional) If you want to import a pre-existing plotter configuration, on the Import PCP or PC2 page, click Import File. Select a PCP or PC2 file to import. Click Import.
- 7 Click Next.
- 8 On the Ports page, select Plot to File. Click Next.
- 9 On the Plotter Name page, enter a name for the plotter configuration file. Click Next.
- 10 On the Finish page, click Finish.
A new plotter configuration file (PC3) is created.

 **Command entry:** PLOTTERMANAGER


To specify or modify settings for plotted DWF files



- 1 Click Output tab ► Plot panel ► Plot. 
- 2 In the Plot dialog box, under Printer/Plotter, in the Name list, select a DWF plotting device. Click Properties.
- 3 In the Plotter Configuration Editor, Device and Document Settings tab, select Custom Properties in the tree window.
- 4 Click Custom Properties.
- 5 In the DWF6 ePlot Properties dialog box, select the options you want. Click OK.
- 6 In the Plotter Configuration Editor, click OK.
- 7 In the Changes to a Printer Configuration dialog box, do one of the following. Then click OK.
 - Select Apply Changes for the Current Plot Only to specify a one-time override of the configuration settings that isn't saved to the ePlot configuration file.

- Select Save Changes to the Following File to save the configuration changes to the DWF configuration file.
- 8 In the Browse for Plot File dialog box, in the Save In location list, select a plotting location for the DWF file, and click Save. Click OK.

 **Toolbar:** Standard
 **Command entry:** PLOT

To set color depth for plotted DWF files

- 1 Click Output tab ► Plot panel ► Plot. 
- 2 In the Printer/Plotter area, in the Name list, select a DWF plotting device. Click Properties.
- 3 In the Plotter Configuration Editor, Device and Document Settings tab, expand the Graphics node in the tree window.
- 4 Click Vector Graphics.
- 5 In the Color Depth area, select a color depth. Click OK.
- 6 In the Changes to a Printer Configuration dialog box, do one of the following. Then click OK.
 - Select Apply Changes for the Current Plot Only to specify a one-time override of the configuration settings that isn't saved to the DWF configuration file.
 - Select Save Changes to the Following File to save the configuration changes to the DWF configuration file.
- 7 In the Browse for Plot File dialog box, in the Save In location list, select a plotting location for the DWF file, and click Save. Click OK.

 **Toolbar:** Standard
 **Command entry:** PLOT

Quick Reference

Commands

PAGESETUP

Controls the page layout, plotting device, paper size, and other settings for each new layout.

PLOT

Plots a drawing to a plotter, printer, or file.

PLOTTERMANAGER

Displays the Plotter Manager, where you can add or edit a plotter configuration.

System Variables

No entries

Utilities

No entries

Command Modifiers

No entries

Set the DWF File Resolution

You can specify the pixel resolution for vector and raster graphics of the DWF6 files that you create. The higher the resolution, the greater the precision but the larger the file size.

WARNING Raster and gradient resolution settings can never exceed the vector setting.

The following list shows the default values for vector and raster resolutions:


- Vector resolution: 1200 dpi
- Custom vector resolution: 40000 dpi

- Gradient resolution: 200 dpi
- Custom gradient resolution: 200 dpi
- Color and grayscale resolution: 200 dpi
- Custom color and grayscale resolution: 200 dpi
- Black and white resolution: 400 dpi
- Custom black and white resolution: 400 dpi

When you create DWF files intended for plotting, select a resolution to match the output of your plotter or printer. High resolutions (over 2400 dpi) are for viewing. For example, when you create DWF files of drawings that contain a lot of detail, such as a topographical map of a large region, use a higher resolution setting for greater detail in the DWF file. Use extreme resolutions (over 40,000 dpi) only when necessary; they may produce very large files. As you increase the resolution setting, raster image quality increases, the speed of printing decreases, and memory requirements increase.




As an example of the difference between DWF resolution settings, consider a map of the world that you want to output as a DWF file for viewing. With a medium resolution setting, you might be able to zoom to a level of detail approximately the size of the state of California on the world map. With a high resolution setting, you might be able to zoom to a level of detail the size of a city. With an extreme resolution setting, you might be able to zoom to a level of detail the size of a building.

To specify the DWF file resolution

- 1 Click Output tab ► Plot panel ► Plot. 
- 2 In the Printer/Plotter area, in the Name list, select a DWF plotting device. Click Properties.
- 3 In the Plotter Configuration Editor, Device and Document Settings tab, select Custom Properties from the tree window.
- 4 In the Access Custom Dialog area, click Custom Properties.

NOTE You can enter any whole number between 150 and 100,000,000 for color and grayscale resolution settings as long as the number does not exceed the current vector resolution setting.

- 5 In the DWF6 ePlot Properties dialog box, in the Vector and Gradient Resolution (Dots Per Inch) area, select Vector and Gradient Resolution settings from the list, or select Custom and enter custom settings. Click OK.
- 6 In the DWF6 ePlot Properties dialog box, in the Raster Image Resolution (Dots Per Inch) area, select Color and Grayscale Resolution settings or Black and White Resolution settings from the list, or enter Custom settings. Click OK.
- 7 In the Plotter Configuration Editor, click OK.
- 8 In the Changes to a Printer Configuration dialog box, do one of the following. Then click OK.
 - Select Apply Changes for the Current Plot Only to specify a one-time override of the configuration settings that isn't saved to the DWF configuration file.
 - Select Save Changes to the Following File to save the configuration changes to the DWF configuration file.
- 9 In the Browse for Plot File dialog box, in the Save In location list, select a plotting location for the DWF file, and click Save. Click OK.

 **Toolbar:** Standard 
 **Command entry:** PLOT

Quick Reference

Commands

PAGESETUP

Controls the page layout, plotting device, paper size, and other settings for each new layout.

PLOT

Plots a drawing to a plotter, printer, or file.

PLOTTERMANAGER

Displays the Plotter Manager, where you can add or edit a plotter configuration.

System Variables

No entries

Utilities

No entries

Command Modifiers


No entries

Set the DWF File Compression


By default, the DWF files that you create are in a compressed binary format. This is the recommended output for most DWF files.

The compression does not result in any loss of data; this is the recommended output for most DWF files. You can also create zipped ASCII encoded 2D stream (plain text) files. You specify these settings when you create or edit a DWF configuration file.

To specify the DWF file compression

- 1 Click Output tab ► Plot panel ► Plot. 
- 2 In the Printer/Plotter area, in the Name list, select a DWF plotting device. Click Properties.
- 3 In the Plotter Configuration Editor, Device and Document Settings tab, select Custom Properties from the tree window.
- 4 In the Access Custom Dialog area, click Custom Properties.
- 5 In the DWF6 ePlot Properties dialog box, in the Additional Output Settings and in the DWF Format area, specify a file compression option. Click OK.
- 6 In the Plotter Configuration Editor, click OK.

- 7 In the Changes to a Printer Configuration dialog box, do one of the following. Then click OK.
 - Select Apply Changes for the Current Plot Only to specify a one-time override of the configuration settings that isn't saved to the DWF6 configuration file.
 - Select Save Changes to the Following File to save the configuration changes to the DWF configuration file.
- 8 In the Browse for Plot File dialog box, in the Save In location list, select a plotting location for the DWF file, and click Save. Click OK.



Quick Reference

Commands

PAGESETUP

Controls the page layout, plotting device, paper size, and other settings for each new layout.

PLOT

Plots a drawing to a plotter, printer, or file.

PLOTTERMANAGER

Displays the Plotter Manager, where you can add or edit a plotter configuration.

System Variables

No entries

Utilities

No entries

Command Modifiers

No entries

Set Font Handling for the DWF File

When you create DWF files, you can specify how fonts are handled and included in the DWF6 file.

By default, font handling is set to Capture Some in the DWF6 ePlot Properties dialog box; you can specify which fonts are eligible for capture in your DWF file. This is the recommended option.

NOTE DWF file size can be affected by the font-handling settings as well as by the amount of text and the number and type of fonts used in the DWF file. If the size of your DWF file seems too large, try changing the font-handling settings.

To specify font handling for the DWF file

1 Click Output tab ► Plot panel ► Plot.



2 In the Printer/Plotter area, in the Name list, select a DWF plotting device. Click Properties.


3 In the Plotter Configuration Editor, Device and Document Settings tab, select Custom Properties from the tree window.

4 In the Access Custom Dialog area, click Custom Properties.

5 In the DWF6 ePlot Properties dialog box, in the Font Handling area, select a font capture option. Click OK.

6 In the Plotter Configuration Editor, click OK.

- 7 In the Changes to a Printer Configuration dialog box, do one of the following. Then click OK.
 - Select Apply Changes for the Current Plot Only to specify a one-time override of the configuration settings that isn't saved to the DWF6 configuration file.
 - Select Save Changes to the Following File to save the configuration changes to the DWF configuration file.
- 8 In the Browse for Plot File dialog box, in the Save In location list, select a plotting location for the DWF file, and click Save. Click OK.





To edit the list of fonts eligible for capture in the DWF file

- 1 Click File menu ► Plot.
- 2 In the Printer/Plotter area, in the Name list, select a DWF plotting device. Click Properties.
- 3 In the Plotter Configuration Editor, Device and Document Settings tab, select Custom Properties from the tree window.
- 4 In the Access Custom Dialog area, click Custom Properties.
- 5 In the DWF6 ePlot Properties dialog box, in the Font Handling area, select Capture Some.
- 6 Select Edit Font List.

NOTE Capturing fonts in the DWF file causes the file size to increase. To minimize file size, the TrueType fonts that are common to all Microsoft® Windows® platforms are by default not selected in the list. Even though these fonts have no check marks beside them, they are shown in the DWF6 file if you are using a Windows operating system. You should select all other TrueType fonts that you have installed to ensure that they are captured for embedding in the DWF6 file. Only the fonts that are needed are embedded in the file.

- 7 In the Available TrueType Fonts dialog box, select the fonts that you want to be eligible for capture in the DWF file. Click OK.

- 8 In the DWF6 ePlot Properties dialog box, click OK.
- 9 In the Plotter Configuration Editor dialog box, click OK.
- 10 In the Browse for Plot File dialog box, in the Save In location list, select a plotting location for the DWF file, and click Save. Click OK.

 **Toolbar:** Standard
 **Command entry:** PLOT

Quick Reference

Commands

PAGESETUP

Controls the page layout, plotting device, paper size, and other settings for each new layout.

PLOT

Plots a drawing to a plotter, printer, or file.

PLOTTERMANAGER

Displays the Plotter Manager, where you can add or edit a plotter configuration.

System Variables

No entries

Utilities

No entries

Command Modifiers

No entries

Edit Pen Patterns for the DWF File

In the Edit Pen Set dialog box, you can specify pen pattern, width, shape, effect, and other settings such as scaling and global pen widths.



The changes you make in the Edit Pen Set dialog box are saved in the plotter configuration file.

NOTE To edit pen patterns when using DWF6 ePlot, you must select 255 Virtual Pens as your color depth.

To edit the Edit Pen Set dialog box for the DWF file

- 1 Click File menu ► Plot.
- 2 In the Printer/Plotter area, in the Name list, select a DWF plotting device. Click Properties.
- 3 In the Plotter Configuration Editor, Device and Document Settings tab, expand the Graphics node in the tree window. Select Vector Graphics. In the Color Depth Area, select 255 Virtual Pens as your color depth, and then select Custom Properties from the tree window.
- 4 In the Access Custom Dialog area, click Custom Properties.
- 5 In the DWF6 ePlot Properties dialog box, click Virtual Pen Set.
- 6 In the Edit Pen Set dialog box, right-click a field.
- 7 Select from the menu of common settings, or click Properties to display the Pen Properties dialog box where you can modify the attributes for each individual pen set.

- 8 In the Pen Properties dialog box, click OK.
- 9 In the Edit Pen dialog box, click OK.
- 10 In the DWF6 ePlot Properties dialog box, click OK.
- 11 In the Plotter Configuration Editor dialog box, click OK.
- 12 In the Changes to a Printer Configuration File dialog box, click one of the following:
 - Apply Changes for the Current Plot Only.
 - Save Changes to the Following File. (Enter the file name.)
- 13 In the Browse for Plot File dialog box, in the Save In location list, select a plotting location for the DWF file, and click Save. Click OK.

 **Toolbar:** Standard
 **Command entry:** PLOT

Quick Reference

Commands

PAGESETUP

Controls the page layout, plotting device, paper size, and other settings for each new layout.

PLOT

Plots a drawing to a plotter, printer, or file.

PLOTTERMANAGER

Displays the Plotter Manager, where you can add or edit a plotter configuration.

System Variables

No entries

Utilities

No entries

Command Modifiers

No entries

DWFx Driver Custom Properties

Specifies custom properties for plotted DWFx files.

Overview of the DWFx Driver Custom Properties

You can use the DWFx ePlot driver to plot or publish DWFx files. You can open, view, and print DWFx files with Autodesk Design Review. DWFx files support real-time panning and zooming as well as control over the display of layers and named views.

By default, AutoCAD plots are plotted with lineweights. If you haven't specified lineweight values in the Layer Properties Manager, a default lineweight of .01 inches is applied to all graphical objects when you plot a drawing. This can cause areas of your plotted DWFx files to look significantly different from how they appear in the AutoCAD drawing area when viewed in an external viewer or Internet browser, particularly during zoom operations. To avoid this, clear the Plot with Lineweights option from the Plot Settings tab in the Plot dialog box.

NOTE All references to AutoCAD, unless otherwise noted, refer to all AutoCAD-based products.

DWFx Driver Graphics Properties

Specifies settings for printing vector graphics and merge control.

Vector Graphics

Provides options for specifying the color depth of vector output.

Color Depth	Displays a list for choosing color depth for the configured plotter for DWFX files.
-------------	---

Merge Control

Controls the appearance of lines that cross in DWFX files.

Lines Overwrite	Uses the last plotted line to obscure the lines under it. Only the topmost line is visible at the intersection.
-----------------	---

Lines Merge	Merges the colors of crossing lines.
-------------	--------------------------------------

DWFX Driver Custom Properties

Specifies custom properties for plotted DWFX files.

Vector and Gradient Resolution (Dots Per Inch)

Specifies the resolution (in dots per inch) for vector graphics and gradients for DWFX files. When you set a higher resolution, the file is more precise, but the file size is also larger.

When you create DWFX files intended for plotting, select a resolution to match the output of your plotter or printer. High resolutions (over 2,400 dpi) are for viewing. For example, when you create DWFX files of drawings that contain a lot of detail, such as a topographical map of a large region, these files use a higher resolution setting for greater detail in the DWFX file. Use extreme resolutions (over 40,000 dpi) only when necessary; they may produce very large files. As you increase the resolution setting, raster image quality increases, the speed of printing decreases, and memory requirements increase.

Vector Resolution

Sets the resolution for vector graphics in the DWfx file in dots per inch. The default setting is 1,200 dpi. Select Custom to enter a custom vector graphic resolution.

Custom Vector Resolution

Specifies a custom resolution for vector graphics in the DWfx file in dots per inch. You must select Custom under Vector Resolution to specify a custom vector graphic resolution. The default setting is 40,000 dpi.

Gradient Resolution

Sets the resolution for gradients in the DWfx file in dots per inch. The default setting is 200 dpi. Select Custom to enter a custom gradient resolution. This setting cannot exceed the current vector resolution setting.

Custom Gradient Resolution

Specifies a custom resolution for gradients in the DWfx file in dots per inch. You must select Custom under Gradient Resolution to specify a custom gradient resolution. The default setting is 200 dpi. This setting cannot exceed the current vector resolution setting.

Raster Image Resolution (Dots Per Inch)

Specifies the resolution (in dots per inch) for raster images for DWfx files. When you set a higher resolution, the file is more precise, but the file size is also larger.

When you create DWfx files intended for plotting, select a resolution to match the output of your plotter or printer. High resolutions (over 2,400 dpi) are for viewing. For example, when you create DWfx files of drawings that contain a lot of detail, such as a topographical map of a large region, these files use a higher resolution setting for greater detail in the DWfx file. Use extreme resolutions (over 40,000 dpi) only when necessary; they may produce very large files. As you increase the resolution setting, raster image quality increases, the speed of printing decreases, and memory requirements increase.

Color and Grayscale Resolution

Sets the resolution for raster image colors and grayscale in the DWfx file in dots per inch. The default setting is 200 dpi. Select Custom to enter a custom

color and grayscale resolution. This setting cannot exceed the current vector resolution setting.

Custom Color Resolution

Specifies a custom resolution for color raster images in the DWFX file in dots per inch. You must select Custom under Color and Grayscale Resolution to specify a custom color resolution. This setting cannot exceed the current vector resolution setting.

Black and White Resolution

Sets the resolution for black and white raster images in the DWFX file in dots per inch. The default setting is 400 dpi. Select Custom to enter a custom black and white resolution. This setting cannot exceed the current vector resolution setting.

Custom Black and White Resolution

Specifies a custom resolution for black and white raster images for the DWFX file in dots per inch. You must select Custom under Black and White Resolution to specify a custom black and white resolution. This setting cannot exceed the current vector resolution setting.

Additional Output Settings

Specifies additional output settings for DWFX files.

Background Color Shown in Viewer

Controls the background color that is applied to DWFX files.

DWFX files intended for plotting should be configured with a white background color. If the DWFX background color is set to black, color 7 objects will be plotted as white. For all other background colors, color 7 objects will be plotted as black.

Include Layer Information

Specifies the inclusion of layer information in plotted DWFX files. If this option is selected, any layers that are turned on and thawed when the plot is created are available for manipulation in the plotted DWFX file. If this option is cleared,

no layer information is available when the DWfx is viewed in an external viewer or browser.

In some cases, such as in drawings that include nested xrefs, turning this option off may significantly improve performance.

Configure a DWfx Driver (Advanced)

Use the DWfx ePlot (XPS Compatible) Properties dialog box to make changes to your DWfx ePlot plotter configuration file. For example, you can specify settings for color depth, display resolution, and other options.

When you create DWfx files, you must use the DWfx ePlot (XPS Compatible).pc3 file as it uses the DWfx driver model.

Overview of Creating or Modifying a DWfx Configuration File

The PUBLISH command uses the *DWfx ePlot (XPS Compatible).pc3* plotter configuration file to create DWfx files.

Although you can save *DWfx ePlot (XPS Compatible).pc3* files under other names for use with the PLOT command, no other name will work with the PUBLISH command.

To make changes directly to the *DWfx ePlot (XPS Compatible).pc3* file, use the Properties button in the Plot dialog box. This action invokes the pc3 editor.

Any changes you make to the *DWfx ePlot (XPS Compatible).pc3* file are used whenever you plot or publish DWfx files until you change the settings of your *DWfx ePlot (XPS Compatible).pc3* file again.

NOTE Create a backup before you make any changes to the *DWfx ePlot (XPS Compatible).pc3* file. Alternately, you can re-create the default *DWfx ePlot (XPS Compatible).pc3* file with the Add-A-Plotter wizard.

You can specify the following settings when you edit the *DWfx ePlot (XPS Compatible).pc3* configuration file:

- Color depth
- Display resolution

- Background color
- Inclusion of layer information


NOTE DWfx files intended for plotting should be configured with a white background color. If the background color is set to black, color 7 objects are plotted as white. For all other background colors, color 7 objects are plotted as black.




To create a plotter configuration file for DWfx file output

- 1 Click File menu ► Plotter Manager.
- 2 In the Autodesk Plotter Manager, double-click the Add-a-Plotter Wizard shortcut icon.
- 3 In the Add-a-Plotter wizard, click Next.
- 4 On the Add Plotter - Begin page, click My Computer. Click Next.
- 5 On the Add Plotter - Plotter Model page, select the following values, and click Next:
 - Manufacturers: Autodesk ePlot (DWfx)
 - Models: DWfx ePlot (XPS Compatible)The list includes all installed plotters.
- 6 On the Import PCP or PC2 screen, click Next.
- 7 On the Add Plotter - Ports page, select the port to use when plotting. Click Next.
 - By default, the Plot to File option is selected.
- 8 On the Add Plotter - Plotter Name page, enter a name to identify the currently configured plotter. Click Next.
- 9 On the Add Plotter - Finish page, click the Edit Plotter Configuration button to change the default settings for the plotter.
 - For more information on the graphics and custom properties of the DWfx driver (Device and Document Settings tab), see DWfx Driver Properties.
- 10 After you finish configuring the plotter, click Finish.
- 11 On the Finish page, click Finish.
 - A new plotter configuration file (PC3) is created.

 **Command entry:** PLOTTERMANAGER

To specify or modify settings for plotted DWfx files



- 1 Click Output tab ► Plot panel ► Plot. 
- 2 In the Plot dialog box, under Printer/Plotter, in the Name list, select the DWfx plotter configuration file you want to edit. Click Properties.
- 3 In the Plotter Configuration Editor, Device and Document Settings tab, select Custom Properties in the tree window.
- 4 In the Access Custom Dialog group, click the Custom Properties button.
- 5 In the DWfx ePlot Properties dialog box, select the options you want. Click OK.
- 6 In the Plotter Configuration Editor, click OK.
- 7 In the Changes to a Printer Configuration dialog box, do one of the following:
 - Select Apply Changes for the Current Plot Only — to specify a one-time override of the configuration settings that is not saved to the ePlot configuration file.
 - Select Save Changes to the Following File — to save the configuration changes to the current DWfx configuration file.
- 8 Click OK twice.
- 9 In the Browse for Plot File dialog box, navigate to the folder location you want to save. Click Save.
- 10 Click OK.

 **Toolbar:** Standard 
 **Command entry:** PLOT

To set color depth for plotted DWfx files

- 1 Click Output tab ► Plot panel ► Plot. 

- 2 In the Printer/Plotter area, in the Name list, select a DWFX plotter configuration file. Click Properties.
- 3 In the Plotter Configuration Editor, click the Device and Document Settings tab
- 4 Click the (+) sign to expand the Graphics node in the tree window.
- 5 Click Vector Graphics.
- 6 In the Color Depth area, select a color depth. Click OK.
- 7 In the Changes to a Printer Configuration dialog box, do one of the following:
 - Select Apply Changes for the Current Plot Only — to specify a one-time override of the configuration settings that isn't saved to the DWF configuration file.
 - Select Save Changes to the Following File — to save the configuration changes to the DWF configuration file.
- 8 Click OK.
- 9 In the Browse for Plot File dialog box, navigate to the folder location you want to save. Click Save.

 **Toolbar:** Standard
 **Command entry:** PLOT

Quick Reference

Commands

PAGESETUP

Controls the page layout, plotting device, paper size, and other settings for each new layout.

PLOT

Plots a drawing to a plotter, printer, or file.

PLOTTERMANAGER

Displays the Plotter Manager, where you can add or edit a plotter configuration.

System Variables

No entries

Utilities

No entries

Command Modifiers

No entries

Set the DWFX File Resolution

You can specify the pixel resolution for vector and raster graphics of the DWFX files that you create. The higher the resolution, the greater the precision but the larger the file size.

IMPORTANT Raster and gradient resolution settings can never exceed the vector setting.

The following list shows the default values for vector and raster resolutions:

- Vector resolution: 1200 dpi
- Custom vector resolution: 40000 dpi
- Gradient resolution: 200 dpi
- Custom gradient resolution: 200 dpi
- Color and grayscale resolution: 200 dpi
- Custom color and grayscale resolution: 200 dpi
- Black and white resolution: 400 dpi
- Custom black and white resolution: 400 dpi

When you create DWFX files intended for plotting, select a resolution to match the output of your plotter or printer. High resolutions (over 2400 dpi) are for viewing. For example, when you create DWFX files of drawings that contain a lot of detail, such as a topographical map of a large region, use a higher resolution setting for greater detail in the DWFX file.

Use extreme resolutions (over 40,000 dpi) only when necessary; they may produce very large files. As you increase the resolution setting, raster image quality increases, the speed of printing decreases, and memory requirements increase.

As an example of the difference between DWFX resolution settings, consider a map of the world that you want to output as a DWFX file for viewing. With a medium resolution setting, you might be able to zoom to a level of detail approximately the size of the state of California on the world map. With a high resolution setting, you might be able to zoom to a level of detail the size of a city. With an extreme resolution setting, you might be able to zoom to a level of detail the size of a building.

To specify the DWFX file resolution




- 1 Click Output tab ► Plot panel ► Plot.
- 2 In the Printer/Plotter area, in the Name list, select a DWFX plotter configuration file. Click Properties.
- 3 In the Plotter Configuration Editor, click the Device and Document Settings tab.
- 4 Click to select Custom Properties from the tree window.
- 5 In the Access Custom Dialog group, click the Custom Properties button.

NOTE You can enter any whole number between 150 and 100,000,000 for color and grayscale resolution settings as long as the number does not exceed the current vector resolution setting.

The DWFX ePlot Properties dialog box appears.

- 6 In the Vector and Gradient Resolution (Dots Per Inch) group, do one of the following:
 - Select Vector and Gradient Resolution settings from the list.
 - Select Custom from the list, and enter custom values.
- 7 Click OK.

- 8 In the Raster Image Resolution (Dots Per Inch) area, do one of the following:
 - Select Color and Grayscale Resolution settings.
 - Select Black and White Resolution settings from the list.
 - Select Custom from the list, and enter custom values.
- 9 Click OK.
- 10 In the Plotter Configuration Editor, click OK.
- 11 In the Changes to a Printer Configuration dialog box, do either of the following.
 - Select Apply Changes for the Current Plot Only — to specify a one-time override of the configuration settings that isn't saved to the DWF configuration file.
 - Select Save Changes to the Following File — to save the configuration changes to the DWF configuration file.
- 12 Click OK.
- 13 In the Browse for Plot File dialog box, navigate to the folder location you want to save. Click Save.

 **Toolbar:** Standard

 **Command entry:** PLOT



Quick Reference

Commands

PAGESETUP

Controls the page layout, plotting device, paper size, and other settings for each new layout.

PLOT

Plots a drawing to a plotter, printer, or file.

PLOTTERMANAGER

Displays the Plotter Manager, where you can add or edit a plotter configuration.

System Variables

No entries

Utilities

No entries

Command Modifiers

No entries

DXB Driver Custom Properties

Specifies custom properties for plotted DXB files.

This nonsystem driver plots to DXB (drawing interchange binary) files, a file format that has only vector capabilities. The output is compatible with the AutoCAD DXBIN command and with the ADI DXB driver delivered with earlier AutoCAD releases. It shares the following limitations of the ADI driver:

- It produces 16-bit integer DXB files containing only vectors.
- DXB output is monochrome; all vectors are color 7.
- Raster images and embedded OLE objects are not supported.
- The driver ignores object and plot style lineweights.

Use the Custom Properties dialog box to set the maximum resolution of the DXB output. Because 16-bit DXB files have a limited coordinate space, the highest resolution settings are only available for smaller "paper" sizes. If you select a high value for maximum resolution and then select a large paper size (for example, ANSI E), a warning is issued indicating the resolution was reduced to accommodate the large plot size.

The resolution control primarily influences the tessellation level of objects. If you set the resolution to a low level, arcs, circles, text, and so on, will be drawn with less tessellation, while at higher resolution settings, more tessellation segments are generated, which creates a larger plot file.

Entities such as solids and lines with thickness are stroked with line segments that have a single-dot width. Decreasing the resolution decreases the number of segments needed to fill these entities and reduces the DXB file size.

This DXB file driver does not plot raster-image entities. The driver plots an outline rectangle instead.

NOTE All references to AutoCAD, unless otherwise noted, refer to all AutoCAD-based products.

HP-GL Driver Custom Properties

Specifies custom properties for plotted HP-GL (PLT) files.

Controls custom properties for the HP-GL driver. For more information about configuration requirements for plotters that use the HP-GL driver, see [HP-GL Configuration Information \(HP-GL\)](#) on page 114.

NOTE All references to AutoCAD, unless otherwise noted, refer to all AutoCAD-based products.

HP-GL Configuration Information (HP-GL)

Specifies configuration information for HP-GL driver.

For information specifying custom properties for the HP-GL driver, see [HP-GL Driver Custom Properties](#) on page 114. You can also choose Help in the HP-GL Custom Properties dialog box in the Plotter Configuration Editor.

NOTE All references to AutoCAD, unless otherwise noted, refer to all AutoCAD-based products.

Overview of HP-GL Configuration Information

This nonsystem driver supports HP-GL, a pen plotter language that has vector-only capabilities.

Raster objects are not supported by the HP-GL device driver. The Microsoft HP-GL Windows System Printer driver cannot be used with AutoCAD. Use this nonsystem driver instead.

Before you plot, you need to provide information about the color and width of each pen in your plotter. Information about specifying physical pen configuration for pen plotters is provided in the Help system.

Different HP-GL models use different coordinate systems. If you are using an emulated device, be sure to choose the HP-GL model your device is emulating; otherwise, your plot could be rotated, offset, or mirrored. If your device doesn't exactly emulate any of the HP devices, you might try one of the two Generic models. These models allow user-defined paper sizes of up to 100 x 100 feet. Also, if the "simplified HPGL" custom property is selected for the Generic models, the HPGL RO instruction will not be sent to the plot file.

Generic SHPGL produces HPGL output that assumes that the coordinate origin is at the lower left corner of the page. Generic LHPG produces output that assumes that the coordinate origin is in the center of the page.

If you are using an emulated device that has a parallel port, select Show All Ports on the Ports page of the Add-a-Plotter wizard or in the Plotter Configuration Editor to access available ports on your computer.

The officially supported HP-GL devices connect by RS232 serial ports. If you are using an emulated device that has a parallel port, select Show All Ports on the Ports page of the Add-a-Plotter wizard or in the Plotter Configuration Editor to access available ports on your computer.

Supported Plotters

List of Hewlett-Packard pen plotters are configured using the HP-GL device driver.

The following Hewlett-Packard pen plotters are configured using the HP-GL device driver:

- 7475A
- 7550A
- 7580B
- 7585B
- 7586B
- Draftmaster 1 (7595A)
- Draftmaster 2 (7596A)
- Draftpro (7570A)
- Draftpro-DXL (7575A)

- Draftpro-EXL (7576A)
- DraftPro-Plus (C3170A)
- DraftPro-Plus (C3171A)

Specifying Switch Settings

Specifies the switches used for the plotter driver.

The switch settings that follow are for the default serial protocol: 9600 baud, 7 data bits, even parity, and one stop bit. If you select another protocol, consult the Hewlett-Packard documentation for the correct settings. For the 7475, set the switches as shown in the following table to configure the plotter for the default settings of 9600 baud, 7 data bits, even parity, and one stop bit. If you select another protocol, consult the Hewlett-Packard documentation for the correct settings.

HP-GL switch settings		
Switch	1	0
B1		X
B2	X	
B3		X
B4	X	
S1	X	
S2		X
DY		D

To configure the 7550 and DraftMaster plotters for default settings, follow the Hewlett-Packard instructions for using the Enter and Next Display keys on the front panel to specify the following settings: monitor mode off, remote mode, stand-alone mode, XON/XOFF or hardware handshaking, direct mode, full duplex, 7-bit data, parity on, even parity, and 9600 baud. Automatic sheet

feed is enabled on the 7550 when an asterisk (*) is displayed below the Sheet Feed key.

To configure the 7580, 7585, 7586, and all DraftPro models for default settings, set the RS-232C speed selector to 9600 and set parity on, even parity, and eavesdrop off. Set the emulate and expand switches to normal. If the plotter doesn't respond, wires 2, 3, or 7 might be strung incorrectly, or the plotter might be improperly configured. With a 7580, 7585, or a 7586, the remote light might be off. If the plotter's error light turns on, the speed or parity switches are probably incorrect.

Configuring Media for Long Axis Plots

Specifies custom paper sizes and the plottable area for both custom and standard media sizes.

Each supported model has a set of standard supported paper sizes, each with a corresponding printable area. You can add custom paper sizes, and you can modify the printable area for standard sizes in the Plotter Configuration Editor. Many HP-GL plotters measure the size of the page when using sheet-fed paper. If your sheet sizes are slightly smaller than standard sizes, and if your plotter configuration tells AutoCAD to request hard clip limits from the plotter, you might see a warning message during plots. The message alerts you that your plot might be clipped and tells you how to avoid clipping. You can enable or disable the query for hard clip limits in the HP-GL Custom Properties dialog box in the Plotter Configuration Editor. If enabled, this query is only made when plotting directly to a locally connected device.

The 7986B and 7596A plotters can create long axis plots. Use the Custom Paper Sizes wizard (on the Calibration and User Defined Paper Sizes node of the Plotter Configuration Editor) to create a custom paper size for your long axis plot. You can configure a delay between long axis plot frames to allow the ink to dry. By default, this is set to 30 seconds, but you can modify the delay time in the HP-GL Custom Properties dialog box in the Plotter Configuration Editor. If your plotter supports both roll-fed and sheet-fed paper, be sure to select the right media source when you configure the plotter. If you select a roll-fed source, be sure to configure the roll width to match the media loaded in the plotter.

Long Plotting (HP-GL)

Specifies the settings for long axis plotting.

Long plotting controls long axis plotting. If you are performing long axis plotting, you need to install a black pen in stall 8 in order to print registration marks at the edge of the paper. The marks at the edge of the paper represent the end of each frame in a long plot.

Do Not Warn at Plot Time

Disables the display of the Long Plot Warning dialog box at plot time. The warning message alerts you that you've selected a long plot paper size and provides further information about long plots.

Pause Between Frames

Causes AutoCAD to pause between frames when performing a long plot. The pause provides time for the ink to dry before the next frame is plotted.

Seconds to Pause Between Frames

Specifies the amount of time to pause between frames of a long plot.

Simplified HPGL (HP-GL)

Specifies the use of a simplified version of the HPGL language for use with devices that do not support the full version of the HPGL language.

You can use the Simplified HPGL option to produce verbose but simplified HPGL for use by non-HP devices that don't support the full HPGL language. Plot files become larger when this option is selected because every HPGL instruction will be terminated and every new coordinate pair will cause a fresh command to be emitted. Also, the HPGL RO instruction is not produced.

Request Hard Clip Limits from Plotter (HP-GL)

Specifies the use of hard clip limits.

The 7580, 7585, 7586, DraftPro DXL/EXL, DraftMaster I, 7586B, and 7596A plotters return hard clip limits to AutoCAD. This requires two-way communication between AutoCAD and the plotter. The plotter sends AutoCAD the installed paper's exact plot area; AutoCAD positions the plot on the paper based on the actual sheet size. If you clear the Request for Hard Clip Limits from Plotter options, AutoCAD positions the plot based on the configured

paper size. In most cases, you need to adjust the configured paper size to reflect the actual printable area of the device. Otherwise, your plot might be clipped. You can adjust the location of the plot on the paper by changing the plot origin.

Handshaking Instructions for Network Plotting and Plotting to a File (HP-GL)

Specifies the type of handshaking used for plotting across a network or to a file.

Handshaking Instructions specifies the method of handshaking for plotting across a network or to a file. When plotting across the network or to a file, you need to specify the type of handshaking so the HP-GL driver can send the correct instructions to the plotter. If you are plotting to a locally configured plotter, use the handshaking controls on the Ports tab in the Plotter Configuration Editor.

Use XON and XOFF Handshaking

Sends HP-GL instructions over the network or to the file to use XON and XOFF handshaking.

Use Hardware Handshaking


Sends HP-GL instructions over the network or to the file to use hardware handshaking.

If you are plotting across a network, you also need to configure the computer connected to the plotter so the Windows system driver port settings are set to the same handshaking method. Also, the plotter must be connected with the appropriate cable.


Set the Windows system driver port settings in the *Printers* folder in the Windows Control Panel. Select the printer that is sharing the plotter on the network, and configure the printer's port settings for handshaking.

If the plotter is connected locally but uses the Windows Print Manager spooler due to a conflict with a Windows system printer, adjust the port settings in the Windows Control Panel.

If you are using XON and XOFF handshaking, the computer must be connected to the plotter with an appropriate cable, as illustrated in the following diagram:



If you are using hardware handshaking, the computer must be connected to the plotter with an appropriate cable, as illustrated in the following diagram:



HP-GL/2 Driver Custom Properties

Specifies custom properties for the HP-GL/2 driver.

The HP-GL/2 Custom Properties dialog box controls custom properties for the HP-GL/2 driver. For more information about configuring HP-GL/2 devices, see [HP-GL/2 Configuration Information \(HP-GL/2\)](#) on page 120.

NOTE All references to AutoCAD, unless otherwise noted, refer to all AutoCAD-based products.

HP-GL/2 Configuration Information (HP-GL/2)

Specifies the configuration information for HP-GL/2 driver.

For more information about specifying custom properties for the HP-GL/2 driver, see [HP-GL/2 Driver Custom Properties](#) on page 120.

NOTE All references to AutoCAD, unless otherwise noted, refer to all AutoCAD-based products.

Overview of HP-GL/2 Configuration Information

The nonsystem HP-GL/2 driver supports a variety of HP-GL/2 pen plotters and ink jet plotters.

This is a generic HP-GL/2 driver that is not optimized for any particular manufacturer's devices. For example, it does not send PJI commands to devices, as a true Hewlett-Packard driver would. The HP-GL/2 driver supports obsolete pen plotters and newer devices made by manufacturers other than Hewlett Packard.

If you have a Hewlett-Packard DesignJet, you should select the System Printer option in the Add-a-Plotter wizard. Hewlett-Packard has redesigned its print path to use the Windows system printer. You can get excellent print speed and quality through the system printer.

NOTE Versions 4.00 and later of the HP-GL/2 & RTL DesignJet Windows System Printer drivers have been optimized for printing. New versions of the drivers are posted on Hewlett Packard's website (<http://www.hp.com>).

You can use this HDI driver if you use a device that emulates an HP plotter and uses HP-GL/2. Follow the device manufacturer's recommendations for switching your plotter to the correct emulation mode. You can also shift your plotter to HP-GL/2 mode by providing a pre-initialization string in the Plotter Configuration Editor.

Supported Plotters

List of emulated and obsolete Hewlett-Packard pen plotters and printers that can be configured using a HP-GL/2 device driver.

The following plotters can be emulated using the HP-GL/2 driver:

- HP DesignJet 750C Plus model C4708A (24")
- HP DesignJet 750C model C3196A (36")
- HP DesignJet 750C model C3195A (24")
- HP DesignJet 650C model C2859A (36")
- HP DesignJet 650C mode C2858B (24")
- HP DesignJet 350C model C4700A (36")

- HP DesignJet 350C model C4699A (24")
- HP DesignJet 250C model C3191A (36")
- HP DesignJet 250C model C3190A (24")
- HP DesignJet 700 monochrome model C4706B (36")
- HP DesignJet 700 monochrome model C4705B (24")
- HP DesignJet 600 model C2848A (36")
- HP DesignJet 600 model C2847A (24")
- HP DesignJet 330 model C4702A (36")
- HP DesignJet 330 model C4701A (24")
- HP DesignJet 230 model C4695A (36")
- HP DesignJet 230 model C4694A (24")
- HP DesignJet 220 model C3188A (36")
- HP DesignJet 220 model C3187A (24")
- HP DesignJet 200 (36")
- HP DesignJet 200 (24")
- HP DesignJet 430 monochrome model C4714A (36")
- HP DesignJet 430 monochrome model C4713A (24")
- HP DesignJet 450C color model C4716A (36")
- HP DesignJet 450C color model C4715A (24")

The HP-GL/2 driver also supports the following obsolete plotters:

- HP DraftMaster Rx model 7596B
- HP DraftMaster Mx model 7599
- HP DraftMaster Sx Plus Sheet Feed-NR model 7595C
- HP DraftMaster Rx Plus NR model 7596C
- HP DraftMaster Mx Plus NR model 7599B
- HP DraftPro Plus-NR model C3171A (36")

- HP DraftPro Plus-NR model C3170A (24")
- HP 7600 250
- HP 7600 255
- HP 7600 355
- HP 7600 240D (vector only, no raster)
- HP 7600 240E (vector only, no raster)
- LaserJet 4
- LaserJet 4M
- LaserJet 4MV
- LaserJet 4Si
- LaserJet 4SiMx
- LaserJet 4V
- LaserJet 5
- LaserJet 5M
- LaserJet 5Si
- LaserJet 5Si Mopier
- LaserJet 5SiMX
- LaserJet III
- LaserJet IIID
- LaserJet IIISi

For most of these devices you have a choice of a serial or parallel port connection. When this choice is available, the parallel port is recommended because it is faster and simpler. Pen plotters are only supported using serial connection.

Cabling Instructions

Specifies the type of handshaking used for plotting across a network or to a file.

Handshaking Instructions specifies the method of handshaking for plotting across a network or to a file. When plotting across the network or to a file, you need to specify the type of handshaking so the HP-GL/2 driver can send the correct instructions to the plotter. If you are plotting to a locally configured plotter, use the handshaking controls on the Ports tab in the Plotter Configuration Editor.

Use XON and XOFF Handshaking

Sends HP-GL/2 instructions over the network or to the file to use XON and XOFF handshaking.

Use Hardware Handshaking


Sends HP-GL/2 instructions over the network or to the file to use hardware handshaking.

If you are plotting across a network, you also need to configure the computer connected to the plotter so the Windows system driver port settings are set to the same handshaking method. Also, the plotter must be connected with the appropriate cable.


Set the Windows system driver port settings in the Printers folder in the Windows Control Panel. Select the printer that is sharing the plotter on the network, and configure the printer's port settings for handshaking.

If the plotter is connected locally but uses the Windows Print Manager spooler due to a conflict with a Windows system printer, adjust the port settings in the Windows Control Panel.

If you are using XON and XOFF handshaking, the computer must be connected to the plotter with an appropriate cable as illustrated in the following diagram.



If you are using hardware handshaking, the computer must be connected to the plotter with an appropriate cable as illustrated in the following diagram.



Switch Settings

Specifies the switches used for the plotter driver.

The following table displays the DIP switch settings for the 7600 240D plotter.

Switch settings for HP 7600 240D plotter		
Switch Bank	1	0
Parallel Left	2	1, 3-10
Parallel Right	3	1, 2, 4-10
Serial Left	1	2-10
Serial Right	3, 6, 7, 9	1, 2, 4, 5, 8, 10

The following table displays the DIP switch settings for the 7600 240E plotter.

Switch settings for HP 7600 240E plotter		
Switch Bank	1	0
Parallel Left	2	1, 3-10
Parallel Right		1-10
Serial Left	1	2-10
Serial Right	6, 7, 9	1-5, 8, 10

For the DraftMaster and 7600 series plotters, follow the Hewlett-Packard instructions for turning off the monitor mode or turning on the remote mode, stand-alone mode, XON/XOFF handshake, direct mode, full duplex, 7-bit data, and parity settings. Choose settings for zero parity and 9600 baud. Be sure the plotter is in HP-GL/2 emulation mode.

DesignJet Plotters

Specifies which Hewlett-Packard DesignJet plotter models AutoCAD supports through serial or a parallel port.

AutoCAD supports the Hewlett-Packard DesignJet plotter models 200/220, 250C, 330, 600, 650C, 700, 750C, 750C Plus, 755, and 755CM through a serial or a parallel port. It is recommended that you use the parallel port. If you use a serial port, set the DesignJet at 9600 baud, with 8 data bits, 1 stop bit, no parity, and hardware handshaking XON/XOFF.

All DesignJet roll-feed models can produce long-axis plots. Both the 600 and 650C have an optional expanded mode for page formats and margins. You set the Expanded mode on the plotter's front panel. By choosing Advanced Media Options from the Plotter Configuration menu, you can select options that match your plotter's settings.

HP-GL/2 Long-Axis Plots

Specifies the settings for long axis plotting.

The 7600 series plotter, DesignJets, DraftPro Plus, and the DraftMaster with roll feed can do long-axis plots.

To perform a long plot

- 1 Select any size greater than 64 inches along the X axis.
The following prompt is displayed:
Long axis plot is selected. Plotter steps/inch = nnn
- 2 Plot in the normal manner.
For best results, plot to extents, do not rotate the plot, and use an explicit one-to-one scale (not Scale to Fit).
- 3 To stop your plotter after AutoCAD has finished sending all the vectors, clear the plotter memory using the plotter's control panel.
- 4 To stop a long-axis plot while AutoCAD is sending vectors to the plotter, press ESC.
- 5 Clear the plotter memory as indicated for the following devices:
 - **DraftMaster X series.** Press the plotter Cancel button.
 - **HP 7600 240D/E.** Press the plotter Reset button.
 - **HP 7600 250/255/355.** Press the Plot Management key. Select Queuing Operations, and then select the plot and delete it from the queue.
 - **HP DesignJet Series.** Press the plotter Cancel button.
 - **HP DraftPro Plus.** Press the plotter Cancel button.

Plot Quality (HP-GL/2)

Specifies the override plot quality setting at the plotter.

Override Quality Defaults on Device

Overrides the plot quality setting at the plotter. Many plotters provide this option in the plotter control panel.

Plot Quality

Specifies the plot quality to use when overriding the plot quality specified at the plotter. The number you enter here is plotter dependent. The valid range is 1 to 100.

Long Plotting (HP-GL/2)

Specifies the display of the long plot warning message.

The warning message alerts you that you've selected a long plot paper size and provides further information about long plots.

Do Not Warn at Plot Time

Disables the display of the Long Plot Warning dialog box at plot time.

Merge Control (HP-GL/2)

Specifies the merging of colors when plotting vectors that cross.

For example, if a red line and a yellow line cross, their intersection is orange if they are merged.

Lines Merge

Specifies that colors should be merged when vectors cross.

Lines Overwrite

Specifies that when crossing vectors are plotted, the color of the last plotted vector is printed. For example, if a yellow line is plotted and then a red line is plotted that crosses the yellow line, the intersection will be red.

Gamma Correction (HP-GL/2)

Specifies the color brightness of an image.

Gamma Correction is available for all plotters that support raster output. You can specify an amount to increase the red, green, and blue intensity levels of raster data and, to a lesser extent, vector data.

The Raster Gamma Correction value is set to 1 by default, which applies no correction. As you increase this value, you incrementally increase the brightness.

Raster Gamma Correction

Specifies the raster gamma correction value. The valid range of values is integers from 1 to 5.

Nonsystem Driver Custom Properties

Specifies custom properties for nonsystem plotters.

The quality of your plot depends on the specific contents of your drawing and the configuration settings for your plotter. You can adjust the configuration for your plotter using one of the following methods:

- Use the Plotter Configuration Editor. Click Properties in the Plot dialog box, or double-click the PC3 file for that plotter in your product's *Plotters* folder.
- For some drivers, use the Custom Properties dialog box, available from the Custom Properties node in the Plotter Configuration Editor.

If you have difficulty printing to a laser printer, try using another driver.

PDF Driver Custom Properties

Specifies custom properties for plotted Adobe PDF files.

You can use the DWG to PDF ePlot driver to plot or publish PDF files. You can open, view, and print PDF files with Adobe Reader, versions 6 or later.

NOTE All references to AutoCAD, unless otherwise noted, refer to all AutoCAD-based products.

Vector and Gradient Resolution (PDF)

Specifies the resolution (in dots per inch) for vector graphics and gradients for PDF files.

When you set a higher resolution, the file is more precise, but the file size is also larger.

When you create PDF files intended for printing from Adobe Reader, select a resolution to match the output of your plotter or printer. High resolutions (over 2,400 dpi) are for viewing. For example, when you create PDF files of drawings that contain a lot of detail, such as a topographical map of a large region, use a higher resolution setting for greater detail in the PDF file. As you increase the resolution setting, raster image quality increases, the speed of printing decreases, and memory requirements increase.

Vector Resolution

Sets the resolution for vector graphics in the PDF file in dots per inch. The default setting is 400 dpi. The maximum dpi you can set is 4,800 dpi.

Custom Vector Resolution

Specifies a custom resolution for vector graphics in the PDF file in dots per inch. You must select Custom under Vector Resolution to specify a custom vector graphic resolution. The default setting is 40,000 dpi.

Gradient Resolution

Sets the resolution for gradients in the PDF file in dots per inch. The default setting is 400 dpi. This setting cannot exceed the current vector resolution setting.

Custom Gradient Resolution

Specifies a custom resolution for gradients in the PDF file in dots per inch. You must select Custom under Gradient Resolution to specify a custom gradient resolution. The default setting is 200 dpi. This setting cannot exceed the current vector resolution setting.

Raster Image Resolution (PDF)

Specifies the resolution (in dots per inch) for raster images for PDF files.

When you set a higher resolution, the file is more precise, but the file size is also larger.

When you create PDF files intended for plotting, select a resolution to match the output of your plotter or printer. High resolutions (over 2,400 dpi) are for viewing. For example, when you create PDF files of drawings that contain a lot of detail, such as a topographical map of a large region, use a higher resolution setting for greater detail in the PDF file. As you increase the resolution setting, raster image quality increases, the speed of printing decreases, and memory requirements increase.

Color and Grayscale Resolution

Sets the resolution for raster image colors and grayscale in the PDF file in dots per inch. The default setting is 400 dpi. This setting cannot exceed the current vector resolution setting.

Custom Color and Grayscale Resolution

Specifies a custom resolution for color and grayscale raster images in the PDF file in dots per inch. You must select Custom under Color and Grayscale Resolution to specify a custom color resolution. The default setting is 200 dpi. This setting cannot exceed the current vector resolution setting.

Black and White Resolution

Sets the resolution for black and white raster images in the PDF file in dots per inch. The default setting is 400 dpi. This setting cannot exceed the current vector resolution setting.

Custom Black and White Resolution

Specifies a custom resolution for black and white raster images for the PDF file in dots per inch. You must select Custom under Black and White Resolution to specify a custom black and white resolution. The default setting is 400 dpi. This setting cannot exceed the current vector resolution setting.

PostScript Driver Custom Properties

Specifies custom properties for plotted PostScript files.

NOTE All references to AutoCAD, unless otherwise noted, refer to all AutoCAD-based products.

Overview of PostScript Driver Custom Properties

You can use the PostScript driver to plot drawings to PostScript printers and PostScript files. Use the PS file format for printers and the EPS file format for files. If you plot to a hardware port, PS output is automatic. If you plot to a file and plan to copy it to a printer, configure for PS output.

The PostScript driver supports three types of PostScript.

Supported PostScript Formats

PostScript Format	Description
Level 1	Use for most plotters.
Level 1.5	Use for plotters that support color images.
Level 2	If your plotter supports Level 2 PostScript, use to produce smaller files that print more rapidly.

The Tokenize PostScript Code and Compression options in the PostScript Custom Properties dialog box reduce output file size and improve printing speed on devices that support these options. If you have problems printing, try clearing all the options. If you successfully print with no optimizations, you can try turning them back on one at a time to determine the options your printer supports.

Some desktop publishing applications only support Level 1 PostScript. If you have problems using your EPS files, try a lower PostScript level and turn off the optimizations just described.

Including a preview thumbnail in your EPS file makes the file substantially larger but allows quick preview by many applications. The WMF preview is for Windows; the EPSF preview is for Macintosh and other platforms.

NOTE Including both preview images can triple your file size.

The PostScript Custom Settings dialog box controls the custom settings for the PostScript driver.

Printer Control (PostScript)

Printer controls specify the codes to send to the plotter.

Send ^D at End of Plot

Sends a ^D code to the printer when the plot is completed. Select this option if you are using a communication channel that uses Adobe Standard Protocol. If you are porting to another platform, remove this code; otherwise, you receive an error message when printing the file.

You probably need a ^D code to avoid a time-out error if you are plotting to a network PostScript plotter. You also need a ^D if you are plotting to a locally connected PostScript plotter through the Windows Print Manager spooler (because of a conflict with a Windows system printer).

Send ^Z at End of Plot

Sends a ^Z code to the printer when the plot is completed. Some PostScript plotters require a ^Z at the end of the file.

Send PostScript Error Handler to Plotter

Sends an error message to the plotter. The error message prints after the plot and describes the error that occurred.

Tokenize PostScript Code

Converts PostScript code to a shorter binary sequence, compressing the output file significantly. If you are having problems using the PostScript driver, try clearing this option.

Preview Thumbnail in EPS Files (PostScript)

Specifies the controls for the type of preview image when plotting to an EPS file.

Controls the type of preview image when plotting to an EPS file. Programs such as Microsoft Word and Adobe PageMaker use preview images to show you what the final PostScript will look like when you insert the file into a document. Preview thumbnails can substantially increase your plot file size. For small plot files, turn off these options.

Include WMF Preview

Specifies that a Windows Metafile preview image is included when the drawing is plotted to a file.

Include EPSF Preview

Specifies that an Encapsulated PostScript preview image is included when the drawing is plotted to a file. Use this option with preview images for Macintosh applications.

Default Plot to File Extension and Format (PostScript)

Specifies the file extension to use when a drawing is plotted to a file.

If you plot directly to a plotter, this setting has no effect.

EPS

Uses the *.eps* extension when a drawing is plotted to a file. Use this setting if you plan to use the file in programs such as Microsoft Word or Adobe PageMaker.

PS

Uses the *.ps* extension when a drawing is plotted to a file. Use this setting if you plan to copy the file to a printer.

Raster Image Compression (PostScript)

Controls AutoCAD ^B and Run Length Encoding compression.

You do not need to configure the plotter to use this compression method.

Use ^B Compression

Enables ^B compression.

RLE

Enables RLE compression.

Custom PostScript Error Handler (PostScript)

Specifies a file for error messages.

You can specify a file for error messages. The file is downloaded to the printer instead of the AutoCAD default error handler. Do not modify this setting unless you are familiar with PostScript error handlers.

Raster Driver Custom Properties

Specifies custom properties for plotted raster format files.

The Raster-Custom Properties dialog box controls the custom settings for the Raster driver. For more information about configuring raster devices, see [Raster Configuration Information \(Raster\)](#) on page 135.

NOTE All references to AutoCAD, unless otherwise noted, refer to all AutoCAD-based products.

Raster Configuration Information (Raster)

Specifies information for configuring output to raster format files.

Overview of the Raster Driver Custom Properties

This section provides specific information for configuring output to raster format files.

This nonsystem driver supports several raster file formats including Windows BMP, CALS, TIFF, PNG, TGA, PCX, and JPEG. The Raster driver is most commonly used to plot to files for desktop publishing.

All but one of the formats supported by this driver produce "dimensionless" raster files that have size in pixels but do not have size in inches or millimeters. The Dimensional CALS format is for plotters that can accept CALS files. If your plotter accepts CALS files, you must specify a real paper size and resolution. Specify the resolution in dots per inch in the Vector Graphics pane of the Plotter Configuration Editor.

By default, this driver only plots to file. However, you can choose Show All Ports on the Ports page of the Add-a-Plotter wizard or the Ports tab in the Plotter Configuration Editor; all of the ports on your computer are then available for configuration. When configured for plotting to a port, this driver plots to a file and then copies that file to the specified port. To plot successfully, make sure that the device connected to the configured port can accept and process the file. For more information, refer to the documentation provided by the device manufacturer.

The type, size, and color depth of the raster file determines the final file size. If your computer has enough memory and disk space, you can produce a file thousands of megabytes in size that requires several days to plot. When selecting a raster size, reduce file size by using the lowest color depth you need. For more information, see [Required Memory and Disk Space for Temporary Files](#) on page 138.

You can configure the background color for raster plots in the Custom Properties dialog box in the Plotter Configuration Editor. If you change the background color, any objects plotted in that color are invisible.

Supported Raster Formats

Specifies the background color used when creating the raster image file.

The Autodesk Raster driver supports the following raster file formats:

- Uncompressed BMP
- Uncompressed TGA
- PCX - Zsoft packbits format
- Uncompressed TIFF
- Group 4 2D compressed bitonal TIFF
- CALS MIL-R-28002A Type 1 (CCITT G4 2D Compression)
- Dimensional CALS Type 1 (CCITT G4 2D Compression)

- JFIF - JPEG compressed
- PNG 1.0

Specify the file format on the Plotter Model page in the Add-a-Plotter wizard.

The Media node in the Plotter Configuration Editor provides a range of bitmap sizes for the raster driver. All of these sizes are plotted with an aspect ratio of 1:1. Some of the file formats offer a choice of color or monochrome and a choice of color depths (for example, 2 shades of gray, 256 colors, and so on). To specify graphics settings, choose the Graphics node in the Plotter Configuration Editor and select Vector Graphics.

The following table shows the supported raster file formats, the available color depth options, and the file extension of the relevant output file. In the Color Depth column, indexed is 8-bit, 256 colors, RGB is 24-bit True Color, and RGBA is 32-bit True Color.

Supported raster file formats

Format	Color depth	Extension
Uncompressed BMP	Bitonal, grayscale, indexed, RGB	<i>.bmp</i>
Uncompressed TGA	Indexed, grayscale, RGB, RGBA	<i>.tga</i>
PCX - Zsoft packbits	Indexed, RGB	<i>.pcx</i>
Uncompressed TIFF	Bitonal, indexed, grayscale, RGB, RGBA	<i>.tif</i>
TIFF - Group 4 Two-dimensional Bitonal Compression	Bitonal, indexed, grayscale, RGB, RGBA	<i>.tif</i>
CALS MIL-R-28002A Type 1	Bitonal	<i>.cal</i>
Dimensional CALS	Bitonal	<i>.cal</i>
JFIF 5.0 - JPEG	Gray, RGB	<i>.jpg</i>
PNG 1.0	Bitonal, grayscale, indexed, RGB, RGBA	<i>.png</i>

BMP File Format

BMP files are Microsoft Windows bitmap files. These files can be created in and read by Windows Paint; all Windows applications can import them.

PCX File Format

The PCX file format has evolved from the files written by the original PC Paintbrush program by Zsoft.

TIFF File Format

TIFF (tagged image file format) is a raster file format jointly defined by Adobe and Microsoft.

Required Memory and Disk Space for Temporary Files

Specifies settings that can affect performance of plotting large raster format files.

Large raster objects are expensive to plot because the files can be large. A 400 × 400 raster uses four times as much memory as a 200 × 200 raster. Color depth can also use a lot of memory, depending on the file format. True Color can use up to 32 times more memory than bitonal rasters. Keep memory issues in mind when configuring a large raster plot.

When you plot a large drawing or a large raster image, several types of temporary files may be created. Make sure you have enough space on your disks for temporary files in the following areas:

- **Windows temporary directory:** Windows uses this directory for temporary files. The TEMP Windows environment variable determines its location.
- **AutoCAD temporary directory:** AutoCAD temporary files are stored in a temporary file directory. This directory is specified in Options on the Files tab.
- **System directory:** The system spooler uses this directory. When a plot is spooled, a copy of the data may be in this directory temporarily.
- **Swap space:** Windows uses this swap space when an operation uses more RAM than is available. You can configure the location of Windows swap space in the System dialog box in the Windows Control Panel. Allow at

least five times as much swap space as RAM. For example, ACIS models or large raster images need more swap space.

Depending on the situation, you may need thousands of megabytes of disk space for these temporary files.

Background Color

Specifies the background color used when creating the raster image file.

The raster plotter driver is independent of the background color you have selected for the drawing area. You can select the background color for raster plots in the Custom Properties node in the Plotter Configuration Editor. Any objects you plot with the same color as the background color are invisible in the raster image. If you are plotting to a grayscale format, your selected color is converted to a grayscale value when plotted.

Background Color (Raster)

Specifies the background color used when creating the raster image file.

Background Color displays a list of colors - black, red, yellow, green, cyan, blue, magenta, white, and "other." Other represents indexed and True Color (24-bit and 32-bit) output depths. The options are black, white, and other for grayscale, and black and white for monochrome. Select Other to display the AutoCAD Select Color dialog box.

If you are creating grayscale output, you must select a color from the Select Color dialog box.

Rotate Raster Scanlines 90 Degrees (Raster)

Specifies the way scan lines run when configuring the device for CALS raster format files.

This option is available if you are configuring the CALS raster file format. Select this option to output this file to a CalComp plotter. You can specify the way the scan lines run so you can align them with the print head movement and significantly improve output time.

System Driver Custom Properties

Specifies custom properties for system printers and plotters.

The quality of your plot depends on the specific contents of your drawing and the configuration settings for your plotter. You can adjust the configuration for your plotter using one of the following methods:

- Use the Plotter Configuration Editor. Select Properties in the Plot dialog box, or double-click the PC3 file for that plotter in your product's *Plotters* folder.
- For Windows system printers, use the Custom Properties dialog box, available from the Custom Properties node in the Plotter Configuration Editor. The entire tree view is displayed to facilitate cutting and pasting between PC3 files, and to provide access to plotter calibration, printable area, and raster controls.

If you have difficulty printing to a laser printer, try using another driver.

Third-Party Plotter Drivers

Plotter drivers that are created by third-parties for use with AutoCAD

CalComp Driver Custom Properties

Specifies custom properties for plots created with the CalComp driver.

This nonsystem driver supports the CalComp 907/PCI/CCGL plot language in vector-only mode. It does not support raster objects. You can modify the connection parameters, and control color merging and the CalComp Device Control Language (CDCL) through the Custom Properties dialog box provided with the driver.

NOTE All references to AutoCAD, unless otherwise noted, refer to all AutoCAD-based products.

Supported Plotter Families (CalComp)

Specifies the plotters that are supported by the driver.

This CalComp plotter driver supports five CalComp plotter families, Drawing Master, Electrostatic, Solus LED, TechJet inkjet, and pen plotters. Many plotters provide serial and parallel ports. For faster plotting results, use the parallel port.

DrawingMaster

List of plotters in the DrawingMaster family.

DrawingMaster plotters use direct imaging (thermal) technology to produce monochrome plots. DrawingMaster plotters have serial and parallel ports. Available resolutions include 200, 300, and 400 dots per inch (DPI). DrawingMaster plotters can product plot lengths equal to the length of the roll.

Supported Models		
Model Number and Name	Width	Resolution
53436 DrawingMaster DM800	36"	400 DPI
53336 DrawingMaster DM600	36"	300 DPI
52436 DrawingMaster Plus	36"	400 DPI
52424 DrawingMaster Plus	24"	400 DPI
52236 DrawingMaster Plus	36"	200 DPI
52224 DrawingMaster Plus	36"	200 DPI

Electrostatic

List of plotters in the Electrostatic family.

Electrostatic plotters use a dielectric coated paper that is charged to attract a toner particle producing the plot. Monochrome and color models are available with widths ranging from 24" to 44". Plot lengths produced by Electrostatic plotters range from 12 to 25 feet depending on the model. All come with serial and parallel ports. All have 400 DPI resolution.

Autodesk will no longer test or fix problems with the following Electrostatic plotters. The device drivers are still available, but are not supported in this release.

Model	Width
68444 Color	44"
68436 Color	36"
58444 Color	44"
58436 Color	36"
58424 Color	24"
57444 Monochrome	44"
57436 Monochrome	36"
57424 Monochrome	24"

Solus LED Plotters

List of plotters in the Solus LED Plotters family.

Solus LED plotters use light-emitting diodes to create a charge on a drum that attracts toner particles producing the monochrome plots on plain paper. These plotters operate very similarly to desktop laser printers. Two models are available. Both models have 400 DPI resolution and two paper supply rolls for different sizes and types of paper. The plotter can automatically select the

paper roll by size, or you can specify a roll. The 54436 model can also receive cut-sheet paper. Both models come with serial and parallel ports.

Model	Width
54436	36"
54424	24"

TechJet Inkjet Plotters

List of plotters in the TechJet Inkjet Plotters family.

The TechJet plotters were built from Canon bubble jet technology. All but the 720 Series plotters are considered dual mode plotters, meaning they can accept roll or cut-sheet paper. The inkjets come in full color, monochrome, and color capable models. All use 360 DPI resolution.

Autodesk will no longer test or fix problems with the following TechJet plotters. The device drivers are still available, but are not supported in this release.

Model	Width
5536 TechJet Color	36"
5524 TechJet Color	24"
5336i TechJet 175i Max Ink	36"
5336GT TechJet Color	36"
5324GT TechJet Color	24"
5336 TechJet Color	36"
5324 TechJet Color	24"
5636 TechJet 720c	36"

Model	Width
5624 TechJet 720c	24"
5436 TechJet 720	36"
5424 TechJet 720	24"

Pen Plotters

List of plotters in the Pen Plotters family.

Autodesk will no longer test or fix problems with the following CalComp pen plotters. The device drivers are still available, but are not supported in this release.

Model	Width
3024 DesignMate	24"
3036 DesignMate	36"
4036 PaceSetter Classic	36"
2036 PaceSetter	36"
2024 PaceSetter	24"
1023 Artisan	24"
1025 Artisan	36"
1026 Artisan	36"

Configuring the Plotters (CalComp)

Specifies the settings to configure the driver.

The following sections provide information to help you configure your plotter. Your plotter configuration settings should agree with your plot configuration settings.

DrawingMaster and Electrostatic Configuration

Specifies configurations for configure DrawingMaster and Electrostatic plotters.

To configure DrawingMaster and Electrostatic plotters, you need an RS-232 terminal. Configure the terminal for 19,200 baud, 8 data bits, 1 stop bit and no parity. With an RS-232 terminal, you can configure your plotter for either a parallel or a serial connection to AutoCAD. Generally, a parallel connection will produce faster plots. Use a standard Centronics parallel cable.

DrawingMaster and Electrostatic parallel port configuration

Parameter	Setting
Input monitor dump	NO
I/F type	CET
Print	N
Dead job time-out (SEC)	90
Time-out action	FORCE
Plot command language	907
Steps per inch	400
Beginning of record sync character	\$16
Number of sync characters	2

Parameter	Setting
End of record character	\$0D
Checksum	Y
DrawingMaster and Electrostatic serial port configuration	
Parameter	Setting
Input monitor dump	NO
Baud rate	9600
Character framing (bits, parity, stop bits)	7,E,1
Host to plotter CDCL protocol	XONXOFF
Plotter to host CDCL protocol	XONXOFF
Dead job time-out (SEC)	90
Time-out action	FORCE
Plot command language	907
Steps per inch	400
Beginning of record sync character	\$16
Number of sync characters	2
End of record character	\$0D
Checksum	Y

DrawingMaster and Electrostatic plotters communicate with AutoCAD at 9600 baud, 7 data bits, 1 stop bit, and even parity, when an RS232 serial connection is used.

DrawingMaster RS232 serial cabling

Specifies configurations for configure DrawingMaster RS232 by serial cabling.

To connect a CalComp DrawingMaster plotter, use a straight-through RS-232 cable:

Plotter end	Computer end
1	1
2	2
3	3
...	...
25	25

Pacesetter Configuration

Specifies configurations for configure a Pacesetter plotter.

To connect the Pacesetter plotter, use either a Centronics parallel port or a straight-through RS-232 cable, then use the following configuration. See the Pacesetter documentation for instructions about how to change or inspect the plotter's configuration.

Parameter	Setting
Plot mode	Final plot
Velocity	350 mmps 13ips

Parameter	Setting
Acceleration	0.7g
Orientation	Auto
Scale	[1/1]
Pen grouping	Off
Plot limits	Normal
Plot Manager	No
Port Type	RS-232C
Protocol	PCI
Baud rate	9600
#of bits, parity	7, even
Handshake	XON/XOFF
Sync # EOM CHK	A : 22 2 13 ON
EOP timer	30 seconds
Language	English
Internal plot	Off
Clear plot data	No
Save as user	Yes

For all other CalComp pen plotters, set the plotter controller for 9600 baud, even parity, 7 data bits, 1 stop bit, no hardware handshake, and checksum on. Set the end-of-message character to 13 decimal, double sync on, and set the sync to 22 decimal.

Setting Custom Properties (CalComp)

Specifies the custom properties that can be changed for the driver.

You can set custom properties using the Custom Properties dialog box. The dialog box is divided into Connection, Plot Color Merge Control, and CalComp Device Control Language sections.

Connections

Specifies the connection type.

CalComp stores plot data as records. Each record starts with one or two specific characters called SYNC codes, and each record ends with one specific character called an EOB/EOM code. You can use a checksum character to validate the plot record. You must set up the plotter to expect SYNC codes, EOB/EOB codes, and checksumming in the plot data. If the plotter setup does not match the driver, the plotter ignores the plot. If you use the CalComp Device Control Language commands, this driver will set up the plotter automatically.

Connection Fields

Dialog Box Field	Description
Number of SYNC Codes	Sets the number of SYNC codes.
SYNC Code	Precedes each CalComp plot record. This code can have a value ranging from 2 through 127, inclusive. These codes directly relate to an ASCII character. If you are not using CDCL, the plotter SYNC code settings must match the driver SYNC codes.
EOB/EOM Code	Indicates the end of a CalComp plot record. The End of Buffer (EOB) or End of Message (EOM) codes directly relate to an ASCII character and can have a value ranging from 2 through 31 inclusive.

Dialog Box Field	Description
Timeout	Defines an amount of time the plotter waits for data. If the plot data sent to a plotter stops, the plotter will wait for the timeout period set here. After that time is reached, it terminates the plot and force plots the data it received.
Enable Checksumming	Adds a checksum character in front of the EOB/EOM code to verify a plot record. The plotter driver calculates the character and the plotter uses it to validate the plot record. Using serial XON-XOFF protocol or Centronics parallel protocol, the plotter can detect a checksum error but cannot recover from it. In these two physical connection modes, checksumming has no value.
Add Pad Characters	Adds padding characters to the plot record in the event the plotter encounters a buffer overflow error.

Plot Color Merge Control

Specifies the settings for plot color merge control.

This information pertains only to raster plotters. For overlapping lines, merging two different color lines creates a third color. For example, merging a magenta line with a yellow line produces red where the lines intersect. Whatever line is received last by the plotter will cover any line it intersects.

Select your Merge control option by going to the Merge Control leaf of the Graphics branch of the Device and Document Settings page of the PC3 Editor.

CalComp Device Control Language

Specifies the plotter operating parameters of the CalComp Device Control Language (CDCL).

The CalComp Device Control Language (CDCL) is a text language appended to the front or back of a plot file. You use CDCL to change the plotter operating parameters.

Plot Quality Settings

To change plot quality settings, select a setting from the Plot Quality combo box.

Plotter Use the value selected on the plotter.

Draft One pass bi-directional plotting.

Normal One pass uni-directional plotting.

Enhanced Two or three pass uni-directional plotting. Each band, InkJet headwidth of inking, requires two passes of the head to image the band. Plotting speed is similar to Normal mode, but the plotting time is twice as long.

Enhanced Fast Three pass bi-directional plotting.

Graphics Four or five pass, random pattern, uni-directional plotting. This mode reduces banding and produces the highest plot quality for high-density images, such as graphic elements, fills, halftone, etc.

Graphics Fast Four or five pass, random pattern, bi-directional plotting. The quality is not as good as Graphics, but this mode provides a good balance of plot speed and quality.

Hi-Res Mono Two pass, double resolution, uni-directional plotting.

Ink-Saver One pass, 25% of the dots, uni-directional plotting. Reduces ink by 75% at the same plotting speed as the Normal mode. Ink-Saver is used for quick or preview plots to check size and layout with reduced ink usage.

Quick Half resolution in media feed direction.

Draft Half resolution in media feed direction.

Norm Normal resolution in media feed direction.

Qual Double resolution in media feed direction.

Dual Red/Black color mode (requires special media).

Color_Sep Color separation mode.

TechJet 720c 5600 Color Modes Plotter, Draft, Normal, Enhanced (Requires color head)

TechJet 720c 5600 Grey Modes Plotter, Draft, Normal, Enhanced, Hi-Res Mono (Requires mono head)

TechJet 5500 Modes Plotter, Draft, Quality, Enhanced, Enhanced Fast, Graphics, Graphics Fast, Hi-Res Mono (1, 3, and 5 pass)

TechJet Designer 720 5400 Modes Plotter, Draft, Normal, Enhanced, Hi-Res Mono

TechJet 5300 Modes Plotter Draft, Normal, Enhanced, Graphics, Graphics Fast, Hi-Res Mono, Ink-Saver (1, 2, and 4 pass)

Solus Modes Plotter

DrawingMaster 53000 Modes Plotter, Draft, Norm, Qual (Resolution)

DrawingMaster Plus 52000 Modes Plotter, Quick, Norm, Qual, Dual (Resolution)

Electrostatic 68000 Modes Plotter, Draft, Norm, Mono, Color_Sep (Resolution)

Electrostatic 58000 Modes Plotter

Pen Plotter Modes Plotter

CDCLBegin and CDCLEnd

CDCLBegin and CDCLEnd have dual purposes. You can enter multiple CDCL commands by separating them with a semi-colon (;). You can use any of the CDCL commands provided in the CalComp Device Control Language documentation provided with each CalComp plotter. To insert a CDCL file into the plot file, specify the path and file name preceded by a less than sign (<). You can combine multiple CDCL commands with the use of a CDCL file.

Example 1: multiple CDCL commands

```
USER_NAME(User1);JOB_NAME(Job1);ROTATE(90)
```

Example 2: CDCL Files

```
<C:\Temp\CDCLFile1.cdl
```

Example 3: Combining Multiple CDCL Commands with a CDCL file

```
USER_NAME(User1 A);<C:\Temp\CDCLFile2.cdl;JOB_NAME(Job1 B)
```

Plot Cutting (CalComp)

Specifies how to configure the plotter to handle plot cutting.

CalComp plotters control their cutters in a variety of ways. Because this driver does not issue a cut command to the plotter, you must configure the plotter to handle plot cutting.

The 36" version of the Solus LED plotter has a cut sheet feeder (Solus Model 54436 Cut Sheet Feeder). To use this type of input, configure the plotter to use the cut sheet feeder. This driver cannot issue a command forcing the Solus to use the cut sheet feeder.

Virtual Pens(CalComp)

Specifies how to configure the virtual pens and fill colors.

If you used Virtual Pens with a CalComp plotter in Release 14, you simply defined "Pens" in your CDCL file. With AutoCAD 2000, you must define "Colors" because they are used for area fills such as wide Plines and True Type text. Some CalComp devices allow you to define both Colors and Pens in CDCL. These include the TechJet Color GT and GT/PS, the TechJet Designer, the 68000 series EPPs, the DrawingMaster series, Solus 4, and the Econografix. Other CalComp plotters only allow you to define Colors at the plotter's control panel. These include the EconoPro, the TechJet Designer 720, and the TechJet color. If you have one of these plotters, don't try to define Colors in the software, as the plotter will ignore the definitions.

A Microsoft(R) Word document, *CalComp_Virtual_Pens.doc*, located in the driver directory in which the CalComp HDI driver is installed, explains how to define Colors in software, using CDCL. The following is a brief summary of the document.

You must create a color (RGB_COLOR) for each pen you define. First define the color, then define a pen (COLOR_PEN) mapped to the color you just defined.

RGB_COLOR(color#, R, G, B)

color# Same as physical pen number

R Red value 0-100 percent saturation

G Green value 0-100 percent saturation

B Blue value 0-100 percent saturation

COLOR_PEN(pen#, width, color#, line type)

pen# Virtual pen number used by AutoCAD

width Width of pen in plotter units (pixels)

For example, for a 400 DPI raster plotter a 2mm line is 31 plotter units
(2/25.4)*400 = 31

color# Color number to map to, as defined above

line type MAJOR, FLAT, ROUNDED, or SQUARE

The following is an example CDCL file.

```
&&&&CALCOMP DEVICE CONTROL
```

```
* Universal PIN number
```

```
USER_PIN(8378)
```

```
* Color 1 is RED
```

```
RGB_COLOR(1, 100, 0, 0)
```

```
* Pen 1 is mapped to color 1, 4 pixels wide, rounded end
```

```
COLOR_PEN(1, 4, 1, ROUNDED)
```

```
* Color 2 is Yellow
```

```
RGB_COLOR(2, 100, 100, 0)
```

```
* Pen 2 is mapped to color 2, 31 pixels wide, major end
```

```
COLOR_PEN(2, 31, 2, MAJOR)
```

```
* Color 3 is a 25% gray
```

```
RGB_COLOR(3, 25, 25, 25)
```

```
* Pen 3 is mapped to color 3, 10 pixels wide, flag end
```

```
COLOR_PEN(3, 10, 3, FLAT)
```

```
^^^^END OF FILE
```

NOTE Other possibilities are available. Please refer to your CalComp CDCL manual.

Xerox Driver Custom Properties

Specifies custom properties for plots created with the Xerox Wide Format Print System HDI driver.

Xerox Wide Format Plotter Configuration Information (Xerox)

Specifies the configuration information for Xerox Wide Format plotters.

Overview (Xerox)

The Xerox driver supports Xerox Wide Format Print Systems with AccXES™ controller with firmware version 6.0 or later. Advanced features such as accounting, media mismatch actions, and nesting require firmware 6.0 or later.

New versions of the driver and firmware are posted on the Xerox website, <http://www.xerox.com>.

For more detailed information, click the Help button in the Xerox AccXES Custom Properties dialog box. In the Plotter Configuration Editor, click the Device and Settings tab. Select the Custom Properties node. Then click Custom Properties. The Custom Properties dialog box offers settings for labels, raster stamps, merge control, banners, folder control, accounting, nesting, media mismatch, mirror image, and gamma correction.

Supported Printers (Xerox)

Specifies the supported Xerox plotters.

The Xerox Wide Format Print System HDI driver supports Xerox Wide Format Print System printers. To configure the driver from AutoCAD, use the Add-a-Plotter wizard, select Xerox as the manufacturer, and then select a specific printer model.

You may configure the driver as a locally connected printer or as a network printer.

You can use the Custom Properties node of the Plotter Configuration Editor to configure custom features of the Xerox Wide Format Print System printer.

Standard Features for Xerox Wide Format Print System 8825 (Xerox)

Specifies standard features for the Xerox Wide Format Print System 8825.

NOTE You can obtain current technical specifications from the Xerox website, <http://www.xerox.com>.

The Xerox Wide Format Print System 8825 is an LED wide-format printer with a powerful PowerPC 603ev-based embedded controller. It can be directly connected to your network, and the client software suite supports multiple platforms and operating systems. It offers true 400 dpi resolution, three IPS imaging speed, a high performance controller, one or two roll media capability, an optional manual sheet bypass, and several finishing options. The Xerox Wide Format Print System 8825 is capable of producing up to four D-size or two E-size prints per minute and includes a complete suite of client software, along with multiple printer drivers.

Standard features include:

- Xerographic LED process and imaging
- Organic photoreceptor
- One 500-foot roll; optional second 500-foot roll; optional manual sheet bypass
- Bond, vellum, and film media types
- Output sizes from A to E
- Long plots up to 48 feet standard and 80 feet with 128 MB SDRAM or optional hard drive configuration
- 400 DPI imaging
- 64 MB SDRAM
- High-performance controller
- Three inch per second processing speed
- Electronic collation
- Remote printer and job queue management
- Autoport sensing

- Data format recognition
- Scaling and rotation
- Size detection
- Roll selection
- Justification and margin control
- Plot labeling
- Banner pages
- Page composition
- Plot stamping
- Nine pen pallets (256 pens each)
- Sixty-four pen patterns
- Ten user setups
- Microsoft® Windows and AutoCAD drivers
- Engineering Document Exchange
- TCP/IP network protocol
- Interfaces: RS232, bi-directional Centronics IEEE 1284, 10/100 Base TX Ethernet
- Standard data formats: HP-GL, HP-GL/2, HP-RTL, CGM (Level 1 with ATA ext.), C4, FileNet, VDS, Calcomp 906/907/951/PCI, TIFF 6.0, NIRS, CALS 1 & 2
- Compression types—CCITT-G4, G3-1D, G3-2D, Packbits, RLE, Seed Row, Adaptive

Standard Features for Xerox Wide Format Print System 8830 (Xerox)

Specifies standard features for the Xerox Wide Format Print System 8830.

NOTE You can obtain current technical specifications from the Xerox website, <http://www.xerox.com>.

The Xerox Wide Format Print System 8830 is an LED wide-format printer with a powerful PowerPC 603e-based embedded controller. It can be directly connected to your network, and the client software suite supports multiple platforms and operating systems. It offers true 400 DPI resolution, three IPS imaging speed, a high performance controller, three roll media capability, manual sheet bypass and several finishing options. The Xerox Wide Format Print System 8830 is capable of producing up to six D-size or three E-size prints per minute, and 8830 includes a complete suite of client software, along with multiple printer drivers.

Standard features include:

- Xerographic LED process and imaging
- Organic photoreceptor
- Three 500-foot rolls and media sheet bypass
- Bond, vellum, and film media types
- Output sizes from A to E
- Long plots up to 40 feet standard and 80 feet with 104 MB SDRAM or optional hard drive configuration
- 400 DPI imaging
- 64 MB SDRAM
- High-performance controller
- Three inches per second processing speed
- Electronic collation
- Remote printer and job queue management
- Autoport sensing
- Data format recognition
- Scaling and rotation
- Size detection
- Roll selection
- Justification and margin control
- Plot labeling

- Banner pages
- Page composition
- Plot stamping
- Nine pen pallets (256 pens each)
- Forty-eight pen patterns
- Ten user setups
- Microsoft® Windows and AutoCAD drivers
- Engineering Document Exchange
- TCP/IP, Novell 3.X and 4.X, and Net-BEUI network protocol
- Interfaces: RS232, bi-directional Centronics IEEE 1284, 10/100 Base TX Ethernet
- Standard data formats: HP-GL, HP-GL/2, HP-RTL, CGM (Level 1 with ATA ext.), C4, FileNet, VDS, Calcomp 906/907/951/PCI, TIFF 6.0, NIRS, CALS 1 & 2
- Compression types—CCITT-G4, G3-1D, G3-2D, Packbits, RLE, Seed Row, Adaptive

Installation (Xerox)

Specifies how to physically set up the plotter.

Arrange physical installation of the printer with your Xerox customer service engineer.

Xerox Wide Format Custom Properties Dialog Box (Xerox)

Controls custom properties for the Xerox Wide Format Print System HDI driver.

Overview of the AccXES Configuration Dialog Box

The following options are available in the AccXES Configuration (Custom Properties) dialog box:

Override Device Settings Overrides the label, option, stamp, and advanced settings on the printer. When this option is selected, the Edit Custom Properties button is enabled, so that you can change the label, option, stamp, and advanced settings.

Edit Custom Properties Opens the Xerox Wide Format HDI Driver AccXES Configuration (Custom Properties) dialog box, which contains the following tabs:

- Labels
- Options
- Stamps
- Advanced

You use the settings on these tabs to control the output of the Xerox Wide Format Print System.

Gamma Correction Specifies the gamma correction value. Valid values are integers from 1 through 5.

Gamma correction adjusts the brightness of an image. You can specify an amount to increase the intensity levels of raster data and, to a lesser extent, vector data. The gamma correction value is set to 1 by default, which applies no correction. As you increase this value, the brightness increases.

Firmware Version Specifies the version of controller firmware in your Xerox Wide Format Print System.

The tabs in the Custom Properties dialog box vary depending on the firmware version you select. If you are not sure of the version of firmware in your Xerox Wide Format Print System, see your system administrator for help.

Use Metric Units Specifies that the positional units in the Raster Stamp Placement X Position and Y Position fields and the Nesting Margin field are in millimeters instead of inches. When this check box is clear, the default positioning unit is inches.

Click Edit Custom Properties to configure the following options:

- [Labels tab](#) on page 161

- [Options tab](#) on page 162
- [Raster Stamp tab](#) on page 164
- [Edit Stamp Names dialog box](#) on page 166
- [Advanced tab](#) on page 166

Labels Tab (Xerox)

Specifies the settings if labels are used when outputting.

Determines whether or not the label is printed on the output and specifies the settings for labels. The Labels tab contains the following options:

Label Choice

Controls plot labels.

No Labels No label is output on the plot.

Printer Default Labels The current printer settings control the label output.

User Labels The fields in the dialog box that allow user label definition are enabled.

User Label Includes

Specifies items to be included on user labels.

Owner Name The owner from the Options tab is included in the user label.

Drawing Filename The drawing name is included in the user label.

Date/Time Printed The date and time (as set on the printer at time of output, in printer defined-format) are included in the user label.

Driver Info The information that identifies the version of the driver generating the printer output is included in the user label.

User Label Position

Specifies the location where the user label is placed on the printed output.

Image Lower Right The user label is printed at the lower-right of the image.

Media Trailing Edge The user label is printed at the trailing edge of the printed output.

Printer Default Position The user label position is determined by the printer setting.

Left Edge The user label is printed on the left edge.

Right Edge The user label is printed on the right edge.

Label Size

Defines the font size in points (6 through 72) for label output.

Label Shading

Specifies the percentage of shading to apply to the user label. The label shading allows a grayscale (0 through 100 percent) to be defined for the appearance of a user-defined label. A 100 percent setting defines a black user label. A 10 percent setting defines a very light user label.

Other Comments to Include on Plot

Allows other comments to be included on the user label. These comments are appended after the information selected in the User Label Includes area.

Options Tab (Xerox)

Specifies settings that show the owner of the output, if a banner is placed on the output, among other options.

The Options tab contains the following options:

Owner

Identifies the owner of the printer output. The contents of the Owner field may be included on a user label.

Banner

Controls banner page selection and output position.

No Banner No banner page is output.

First Page A banner page is output before the plot.

Last Page A banner page is output after the plot.

Mirror Image

Flips the image about one axis. Use this option when the output is to film media, so that the image is on the back of the media, and the front can be marked up with a marking tool.

Document Type

Controls image processing on the AccXES controller to improve image quality for a given document. You can set the document type to Auto Select, Graphics, Lines & Text, or Photo.

Finishing

Controls the operation of an optional finisher. You can control the finisher type by specifying a FIN file that defines the finisher type and the programs that are known to the finisher.

Three default FIN files are distributed with this AutoCAD driver (*8830ANSI.FIN*, *8830ARCH.FIN*, and *8830ISO.FIN*). See the Xerox website for a FIN file generator that you can use to generate your own FIN files.

Finisher Type Specifies the type of finisher as specified in the FIN file.

Not Installed	No finishing information is included in the plot.
Finisher Bypass	The finisher is bypassed (the plot is not folded).
Printer Default	The printer default behavior for finishing is used.
<Add Finisher>	A dialog box is shown in which you can specify which FIN file to add.

When you add or select a finisher, the FIN file is read, and any finisher programs defined in the file are added to the Program drop-down list.

Program Specifies the finisher program to be used. When you add or select a finisher program, the Sort Bin drop-down list is displayed with valid bin selections.

Sort Bin Specifies the valid bin selection.

Title Block Provides a list of available title block override settings. Options are:

- No Preference
- Upper Left
- Upper Right
- Lower Left
- Lower Right

Intelligent Title Block

- For folding documents with title blocks in standard corners, this option adjusts the location of the title block for proper folding if you selected an incorrect title block location for the fold style.
- For folding documents with title blocks that are not in an expected standard corner, leave the Intelligent Title Block box clear.

Depending on the finisher program, you may be able to modify the selections for

- Cross Fold
- Margin (binding margin)
- Punch
- Tab/Reinforcement strip

Raster Stamp Tab (Xerox)

Specifies the raster stamp printed during output.

The Raster Stamp tab controls the raster stamp printed on the output print.

You can load the printer with predefined raster stamps, which are identified by stamp names. You define stamp names for this driver by using the Edit

Stamp Names dialog box. The stamp names that you define should match the names that are defined in the printer.

When you define a stamp name in the Edit Stamp Names dialog box, the name appears in the Raster Stamp Selection drop-down list.

When you select a user-defined stamp name, fields on the Raster Stamp tab are enabled that allow you to select stamp scaling, scaling type, and placement.

The Raster Stamp tab contains the following options:

Raster Stamp Selection

Controls which raster stamp (if any) to be used on printed output.

No Raster Stamp Overrides the printer raster stamp setting. No raster stamp is output.

Printer Default Stamp Specifies that the printer defines the control for raster stamp output.

<Stamp name 1 - 8> Specifies the names that are defined through the Edit Stamp Names dialog box.

Edit Stamp Names

Opens the Edit Stamp Names dialog box, in which you can define raster stamp names for the driver. The names should match those defined in the printer. Once defined, the names are available on the Raster Stamp Selection drop-down list.

Scaling Factor

Specifies the output size of a loaded raster stamp. You can specify a scaling factor of 10 through 999. The scaling factor can be either Relative to Drawing or Absolute.

Raster Stamp Placement

Controls the printed location of a raster stamp.

X Position You can set the X position to Left, Center, Right, or Absolute in inches or millimeters.

Y Position You can set the Y position to Top, Center, Bottom, or Absolute in inches or millimeters.

Rotation You can set the rotation to 0, 90, 180, or 270 degrees.

Edit Stamp Names Dialog Box (Xerox)

Specifies the names of the stamps that are defined for the driver and loaded in the printer.

The Edit Stamp Names dialog box specifies the names of the stamps that are defined for the driver and loaded in the printer. The stamp names defined in the Edit Stamp Names dialog box should match the names defined in the printer.

Stamp names can be up to 48 characters in length. You can define up to eight raster stamp names. Stamp names that you define in this dialog box are available in the Raster Stamp Selection drop-down list on the Stamps tab.

Advanced Tab (Xerox)

Specifies settings for printer accounting, media mismatch mode action, and print nesting control.

The Advanced tab provides control over printer accounting, media mismatch mode action, and print nesting control. Advanced features require AccXES printer firmware, version 4.0 or later.

The following options are available on the Advanced tab:

Printer Accounting

The following options are available in the Printer Accounting area:

Enable Turns on printer accounting.

Settings Opens the Printer Accounting dialog box.

If you previously selected a printer firmware version earlier than 6.2, you are asked to enter an account number and a subaccount number.

If you have selected a printer firmware version 6.2 or later, you are asked to enter a user ID and an account ID.

Both dialog boxes allow you to save the information. If you do not save the information and accounting is enabled, you are prompted for the accounting information at plot time.

Mismatch Mode

Defines what is output if the media or media size requested does not match the media loaded.

Scale to Fit The printer uses the largest media of the type selected that fits your printer. If all the installed media of the selected type are smaller than the print job, the largest media is used and the job is scaled to fit. If no media of the selected type is installed, the printer holds your job until the proper media is installed.

Block Printing The printer holds your job until the proper media is installed.

Substitute Media The printer substitutes the media type selected and prints on the size specified if it exists. If the size specified does not exist, the plot is set to Scale to Fit with the media type installed in the printer.

Plot Nesting

Nesting Margin Specifies the space between the nested copies. Valid values are 0 mm through 25 mm (0 through 0.98425 inches). This option is available only when Nest Copies is selected.

Mode Multiple copies of a print can be nested (printed together). Plot Nesting modes are

Off	No nesting.
Printer Default	Nest according to the printer settings.
Nest Copies	Nest multiple copies in a single print.

Rendering

Raster Halftone Method Allows the selection of the binarization method used on multibit raster images.

Screen	Offers faster printing but may produce prints with a grainy appearance.
Error Diffusion	Generally produces a smoother print image.

Vector Minimum Line Width Improves the visibility of fine lines. Depending on your printer's resolution, lines that are only a few pixels wide may appear light and be difficult to see. This setting allows you to set the minimum width of drawn lines from one to 10 pixels. Lines that are wider are not accommodated by Fineline Pixel Threshold. This setting has no impact on raster images.

Enter Account Numbers

When accounting is turned on and you have selected a firmware version of 6.1 or earlier, you use this dialog box to obtain your account number and subaccount number.

The account number and subaccount number must match values known by your printer. Your plotter administrator may add account and subaccount numbers using the printer's front panel.

If you select Save Account Numbers, you are not prompted at plot generation time for these values. If Save Account Numbers is not selected, then you are prompted every time you generate a plot for the account and subaccount numbers.

Account Number The account number must be in the range of 0 through 999999.

Sub-Account Number The subaccount number must be in the range of 0 through 9999.

See your plotter administrator for your account number and subaccount number.

XES Synergix 8825/8830/8855 Driver Custom Properties

Specifies custom properties for plots created with the XESystems, Inc. system printer driver.

You should use the current XESystems, Inc. (XES) AccXES™ optimized system printer driver (version 5.01 or later) instead of any of the older XES AccXES HDI drivers that you may have added previously with the Add-a-Plotter wizard.

Although HDI drivers that you add through the Add-a-Plotter wizard support XES AccXES printers, it is recommended that you use the AccXES optimized system printer driver from XESystems, Inc. for plotting. The AccXES optimized system printer driver provides significant performance improvement and

reduces the amount of data generated. This is especially true if your drawings contain raster images.

NOTE All references to AutoCAD, unless otherwise noted, refer to all AutoCAD-based products.

Use the AccXES Optimized System Printer Driver (XES)

Specifies how to use the AccXES optimized system printer driver.

To use the AccXES optimized system printer driver

- 1 Download the current version of the XES AccXES optimized system printer driver (version 5.01 or later) from <http://www.xes.com>.
- 2 Install the AccXES optimized system printer driver as a normal Microsoft® Windows system printer driver.
- 3 Open an AutoCAD drawing.
- 4 Click File menu ► Plot.
- 5 Select one of the following plotters:
 - AccXES 8830
 - AccXES 8825
 - AccXES 8855

Do not confuse these plotters with *XES 88xx.pc3* configurations, which are the older HDI driver configurations. When you have selected the correct XES AccXES optimized driver, the following is shown as part of the plotter name in the Plot and Page Setup dialog boxes in the Printer/Plotter area under Plotter:

Optimized Driver – by XESystems, Inc.

If you do not want the HDI driver plotter configuration files for your XES printers (*XES 88xx.pc3 files*) to be included in the Plotter drop-down list, use the Plotter Manager to delete them.

What's New in the AccXES Optimized System Printer Driver (XES)

List of recent changes to the AccXES optimized system printer driver.

The following changes have been made in the XES AccXES optimized system printer driver:

- Media source and size are controlled through the Custom Properties dialog box instead of through the Plotter Configuration editor.
- Options for vector graphics resolution are available on the Rendering tab in the Custom Properties dialog box.
- The Raster Graphics Image slider controls in the Plotter Configuration editor can be used for both HDI and the optimized driver to control raster image processing.
- A True Type Text setting is available in the Plotter Configuration editor.
- When you click Custom Properties in the Plotter Configuration editor, the Custom Properties dialog box for the system printer opens.

File Changes in the AccXES Optimized System Printer Driver (XES)

Overview of the file changes in the AccXES optimized system printer driver.

The older HDI driver (*xes7.hdi*) that was located in the *Drv* directory generated HP-GL/2 and RTL data directly for the AccXES printer (models 8825, 8830, and 8855). When you selected a XESystems, Inc. AccXES printer through the Add-a-Plotter wizard, *xes7.hdi* was used.

The new optimized system driver uses the XES AccXES system printer driver (version 5.01 or later), along with *xesgdi8.hdi*, which is located in your *Drv* directory. The *xesgdi8.hdi* file receives graphics calls and makes GDI calls to the XES optimized system driver. The AccXES optimized system printer driver generates HP-GL/2 & RTL data for the XES AccXES printer.

Benefits of Using the AccXES Optimized System Printer Driver (XES)

List of the benefits of using the AccXES optimized system printer driver.

The benefits of using the XESystems, Inc. AccXES optimized system printer driver are:

- You install a single driver rather than one for AutoCAD and one for your other applications.
- Advanced feature controls, such as nesting, banners, and finishing, are controlled the same way through all applications.
- You need to learn only one interface for the XES AccXES printer control.
- The XES AccXES optimized system printer driver processes significantly faster than the HDI driver, especially when your drawings include raster images.
- The XES AccXES optimized system printer driver generates significantly less data than the HDI driver when plotting raster images.

Available Settings for the AccXES Optimized Printer (XES)

List of the settings that can be configured for the AccXES optimized system printer driver.

In the Plotter Configuration Editor, click the Custom Properties button to change any of the following settings for the AccXES optimized printer:

- Media size
- User-defined media size
- Paper orientation
- Media type
- Media source
- Copy count

- Margins and justification
- Banner pages
- Plot labeling
- Raster stamps
- Finishing (folding)
- Plot nesting
- Actions on media mismatch
- Additional scaling
- Additional image scaling
- Mirroring
- Additional rotation
- Output resolution

Troubleshooting Hints (XES)

Overview of some problems that can cause issues when using the system driver.

You are probably using an older, nonoptimized version of an XES system printer driver if:

- You cannot plot long plots
- Print processing is slower than the HDI driver
- The amount of data is larger than when generated by the HDI driver

If “Optimized Driver – by XESystems, Inc.” is not shown as part of the plotter name in the Plot and Page Setup dialog boxes in the Printer/Plotter area under Plotter, you are not using the XES AccXES optimized system printer driver.

Index

A

- acceleration 7
- Access databases
 - configuring 69
- AccXES controller (Xerox) 155
- Add-a-Plotter wizard 11, 27
- ADI DXB driver 64, 113
- Adobe PDF driver 63
- Adobe PostScript driver
 - configuring 64
- applications
 - remote access applications 7
- attaching
 - PMP files to PC3 files 27
- Autodesk HDI system printer driver 59
- AutoSpool feature 36, 38

B

- batch plots
 - AutoSpool feature 39
- baud rate 45
- bitmaps (BMP images)
 - plotting to 135
- BMP files (bitmaps)
 - plotting to 135

C

- CalComp plotters
 - configuring 145
 - custom properties 149
 - drivers for 140
 - supported models 141
- Calibrate Plotter wizard 26
- calibrating
 - digitizing tablets 5
 - plotters 26
- calibration utilities 26
- CALS files 135, 139

- CDCL language 140
- collating settings 18
- color depth 22
- colors
 - plot settings 22
 - plotter configuration files and 88, 106
- compression
 - DWF files 95
- configuration files (databases) 70
- configuration files (plotters)
 - attaching PMP files 27
 - custom properties 23, 81
 - file output 63
 - graphics settings 22
 - initialization strings 25
 - pen settings 20
 - port settings 35
- configured plot files 10
- configuring
 - digitizing tablets 5
 - DWF6 driver settings 88
 - DWFx driver settings 106
 - external databases 69
 - file format drivers 63
 - nonsystem plotters 10
 - pen settings 20
 - plot spooling 36, 39
 - plotters 10, 15, 49
 - ports 35–36, 45
 - printers 10
 - Windows system printers 10, 60
- copying
 - plotter configuration settings 15
- Custom Paper Size wizard 27
- custom properties
 - plotter drivers 81
 - plotters 23
- customizing
 - paper size 27
 - right-clicking 2

cutting
 paper settings 18

D

data sources
 configuring 69
databases
 configuring 69
dBase databases 69
DesignJet plotters 49
desktop publishing 135
detaching
 PMP files 27
digitizing tablets 5
Dimensional CALS format 136
dithering 22
duplex printing 18
DWF files (Design Web Format)
 configuring ePlot for 63
 DWF6 driver configuration 88
 plotter drivers 81
DWF6 driver
 configuring 88
 custom properties 81
DWF6 ePlot pc3 plotter configuration
 files 81, 88
DWFx driver
 configuring 106
 custom properties 102
DWFx ePlot pc3 plotter configuration
 files 102, 106
DWFx files
 DWFx driver configuration 106
 plotter drivers 102
 plotting 106
DWG to PDF driver 129
DXB files
 configuring drivers for 64
 custom properties 113

E

editing
 pen settings 100
 plotter configuration files 11, 15

ePlot driver 63
Excel spreadsheets
 configuring external data sources 69
exporting
 configuring drivers for 63
 export file formats 63
 files 63
external databases 69

F

file formats
 configuring drivers for 63
 export file formats 63
 raster formats 135
files
 compressing 95
 exporting 63
 plotting to 39, 63
flow control in plotting 46
fonts
 DWF font-handling 97
FoxPro databases 69
frames
 plotting 51

G

graphics plot settings 22
graphics systems 7

H

handshaking in plotting 46
hard clip limits 50
hardware
 acceleration 7
 handshaking 46
HDI drivers (Heidi Device Interface)
 about 9
 Autodesk system printer driver 59
 resolving driver conflicts 34
 updating 11
Hewlett-Packard DesignJet plotters 49
Hewlett-Packard HP-GL plotters 50, 115

- Hewlett-Packard HP-GL/2 plotters 53, 121
 - Hewlett-Packard Windows system printer driver 49
 - Houston Instrument plotters 58
 - HP-GL driver
 - configuring 50
 - custom properties 114
 - Simplified HPGL plotting 118
 - HP-GL/2 driver
 - configuring 49, 53
 - custom properties 120
- I**
- initialization strings (plotters) 25
 - Intellimouse 2
- J**
- JFIF files 136
 - joystick panning 2
 - JPEG files
 - configuring raster driver 64
 - plotting to 135
- L**
- local nonsystem plotters
 - configuring 10
 - port settings 36
 - resolving conflicts 34
 - long-axis plots
 - Hewlett-Packard DesignJet plotters 49
 - Hewlett-Packard HP-GL plotters 51
 - HP-GL/2 driver 53
- M**
- MDB files (Access) 71
 - MDF files 71
 - media settings (plotting) 18
 - memory (RAM)
 - plot options and 22
 - Microsoft Access databases
 - configuring 69
 - Microsoft Excel spreadsheets
 - configuring external data sources 69
 - Microsoft Jet OLE DB Provider 71
 - Microsoft ODBC 70
 - Microsoft OLE DB Provider for ODBC Drivers 71
 - Microsoft Visual FoxPro databases 69
 - Microsoft Windows Netmeeting 7
 - modifying
 - pen settings 100
 - plotter configuration files 11, 15
 - monochrome settings
 - plot settings 22
 - mouse
 - buttons 1
 - wheel mouse 2
 - multiframe long-axis plots 51
- N**
- naming
 - plotters 39
 - Netmeeting 7
 - network nonsystem plotters
 - configuring 10–11
 - port settings 37
 - nonsystem plotter drivers
 - CalComp drivers 140
 - custom properties 129
 - DXB driver 113
 - HP-GL driver 50, 114
 - HP-GL/2 driver 53, 120
 - PDF driver 129
 - plotting to files 10
 - raster driver 135
 - settings 10
 - XES Synergix driver 168
 - nonsystem plotters
 - configuring 10
 - custom properties 129
 - device-specific configurations 49
 - initialization strings 25
 - media settings 18
 - paper sizes 27

- port settings 35
 - timeout values 44
- O**
- ODBC (Microsoft) 70
 - OLE DB (Microsoft) 70
 - Oracle databases 69
 - Out of Limit light 51
- P**
- pages
 - paper settings 18
 - paper options 18
 - paper size
 - customizing 27
 - nonsystem plotters 18
 - Paradox databases 69
 - parallel ports
 - default setting 36
 - device-specific configurations 49
 - pc3 editor 88, 106
 - PC3 files (plotter configuration)
 - attaching PMP files 27
 - creating 11
 - custom properties 23
 - device settings 18
 - document settings 18
 - DWF6 plotter configuration files 88
 - DWFx plotter configuration files 106
 - editing 15
 - file information in 17
 - file output 63
 - graphics settings 22
 - initialization strings 25
 - pen settings 20
 - port settings 35
 - saving configurations 10
 - PCX files
 - plotting to 135
 - PDF driver
 - configuring 63
 - custom properties 129
 - pen plotters
 - settings 20
 - pen settings
 - configuring 20
 - DWF files 100
 - multiframe long-axis plots 51
 - pick button (mouse) 1
 - plot files 10
 - plot model parameter files (PMP) 10, 27
 - plot spooling
 - AutoSpool 38
 - configuring 39
 - Windows system spooler 36
 - plot style tables
 - pen settings 20
 - Plotter Configuration Editor
 - device settings 18
 - document settings 18
 - editing PC3 files 15
 - port settings 35
 - plotter configuration files
 - attaching PMP files 27
 - custom properties 23, 81
 - device and document settings 18
 - editing 10
 - file information 17
 - file output 63
 - graphics settings 22
 - initialization strings 25
 - pen settings 20
 - Plotter Configuration Editor 15
 - port settings 35
 - plotter drivers
 - AccXES driver 168
 - CalComp driver 140
 - custom properties 81
 - DXB files 113
 - HP-GL (PLT) files 114
 - HP-GL/2 driver 120
 - PDF driver 129
 - port settings 35
 - raster driver 135
 - resolving conflicts 34
 - system driver 140
 - Xerox driver 155
 - XES Synergix driver 168

- Plotter Manager
 - configuring plotters 49
 - creating PC3 files 11
- plotters
 - calibrating 26
 - configuring 10, 49
 - connection options 36
 - custom properties 23
 - descriptions 17
 - device names 39
 - driver custom properties 81
 - DWF6 configuration files 88
 - DWFX configuration files 106
 - graphics settings 22
 - nonsystem drivers 10
 - pen settings 20
 - Plotter Configuration Editor 15
 - port settings 35
 - PostScript plotters 64
 - resolving driver conflicts 34
 - timeout values 44
- plotting
 - AutoSpool 38
 - batch files 39
 - color depth 22
 - dithering 22
 - exporting files 63
 - file formats 63
 - flow control 46
 - handshaking 46
 - port settings 35–36
 - resolution 22
 - resolving driver conflicts 34
 - spooling 36
- PLT files 114
- PMP files (plot model parameter) 10, 27
- PNG files (Portable Network Graphics)
 - plotting to 135
- pointing devices
 - buttons 1–2
 - digitizing tablets 5
 - mouse buttons 1
 - wheel mouse 2
- ports
 - configuring 45
 - device-specific configurations 49
 - output options 36
 - plot options 36
 - resolving conflicts 34, 36
 - settings 35
 - types 36
- PostScript driver
 - configuring 64
 - levels supported 64
- PostScript printers 64
- pre-configured plotters 10
- Print Manager conflicts 34
- printer drivers
 - port settings 35
 - resolving conflicts 34
- printers
 - configuring 10, 49
 - connection options 36
 - device names 39
 - driver custom properties 81
 - Plotter Configuration Editor 15
 - port settings 35
 - PostScript printers 64
 - resolving driver conflicts 34
 - timeout values 44
- printing
 - AutoSpool 38
 - port settings 35
 - spooling 36
- properties
 - plotter drivers 81
 - plotters 23
- protocol for serial ports 45
- publishing
 - DWF6 settings 88
 - DWFX settings 106

R

- RAM
 - plot options and 22
- raster driver
 - configuring 64
 - custom properties 135
- raster images
 - resolution 93, 110
- remote access applications 7

- resolution
 - DWF6 files 93
 - DWFx files 110
 - plotting 22
- right mouse button 1
- right-click menus 2

S

- serial ports
 - configuring 35–36, 45
 - default setting 36
 - device-specific configurations 49
- SHPGL plotting 118
- simplified HPGL plot files 118
- software acceleration 7
- software handshaking 46
- spooling plot jobs 36, 38
- spreadsheets
 - configuring external data sources 69
- SQL Server 69
- stapling pages 18
- system printer drivers 59, 140

T

- TARGA files 135
- TGA files
 - plotting to 135
- TIFF files
 - configuring raster driver 64
 - plotting to 135
- timeout values for plotters 44

U

- UDL configuration files 70
- updating
 - HDI drivers 9, 11

V

- vector graphics
 - plot options 22
 - resolution 93, 110
- Visual FoxPro databases 69

W

- wheel mouse 2
- Windows Netmeeting 7
- Windows Print Manager conflicts 34
- Windows system printer drivers
 - resolving driver conflicts 34
 - spooling and 36
- Windows system printers
 - configuring 10, 60
 - custom settings 23
 - paper sizes 27
 - timeout values 44
- Windows system spooler 36

X

- Xerox HPGL/2 optimized Windows system driver 55
- Xerox plotters
 - configuring 55
 - custom properties 155
 - supported models 155
- XES Synergix driver 168
- XLS files (spreadsheets) 71
- XON/XOFF handshaking 46

Z

- zooming
 - wheel mouse and 2